

OPERATING INSTRUCTIONS

**Flow Computer System
ERZ 9000**

ERZ 9004M Mass Flow Computer

Status: August 18, 1998
Subject to change

CONTENTS

| | | |
|---------|---|----|
| 1 | Introduction to the ERZ 9004 M | 3 |
| 2 | ERZ 9004 M Front Panel | 4 |
| 3 | Operating the ERZ 9004 M | 5 |
| 4 | ID Display / Device Data | 7 |
| 5 | Display Fault / Clear Fault Function | 8 |
| 6 | "TEST" Key Special Function: Freeze / Calibration During Operation | 9 |
| 7 | Summary of Coordinates for the ERZ 9004 M | 11 |
| 7.1 | Coordinates from A to L | 11 |
| 7.2 | Coordinates from M to T | 12 |
| 7.3 | Coordinates from U to Y | 13 |
| 8 | Summary of Device Functions to Be Called up with Function Keys | 14 |
| 8.1 | Description of the matrix structure | 14 |
| 8.2 | Device-specific functions | 15 |
| 8.2.1 | Pressure at actual conditions | 15 |
| 8.2.2 | Temperature at actual conditions (PT100) | 16 |
| 8.2.3 | Volume flow rate at actual conditions | 17 |
| 8.2.4 | Standard volume flow rate | 18 |
| 8.2.5 | Analysis | 19 |
| 8.3 | Outputs | 20 |
| 8.3.1 | Current outputs | 20 |
| 8.3.2 | Dispatcher outputs | 21 |
| 8.3.3 | Data interface | 22 |
| 8.4 | Totalizer | 23 |
| 8.5 | Test | 24 |
| 8.6 | ID display | 25 |
| 8.7 | Mode | 26 |
| 8.8 | Clear / Fault | 27 |
| Annex A | Function Chart for the ERZ 9004 M Mass Flow Computer | 28 |
| Annex B | Block Diagram for the ERZ 9004 M | 29 |
| Annex C | Survey of Equations Used | 30 |
| Annex D | Operating Examples (setting indexes, enabling user levels, etc.) | 31 |
| Annex E | Technical Data | 35 |
| Annex F | Pin Assignment Diagrams | 42 |
| Annex G | Fault List | 46 |

1 Introduction to the ERZ 9004 M

The operating concept:

The operating concept has been chosen in such a way that the operator can easily use the device without wasting too much time reading a manual.

The function keys:

The most important data for the operator can be directly selected via function keys. There are function keys for

Pressure

Temperature

Analysis values

Flow rates

Index readings

Outputs (currents, dispatcher, interfaces)

Identification / device data

Storing measured values (freeze) / calibration during operation.

The system of coordinates:

A system of coordinates makes it easy for the operator to access all configuration data, measured values and operands by means of a table.

The system of coordinates is based on 24 columns and 46 lines. Columns are marked **A** to **Y**, while lines run from **1** to **46**. The operator can reach every value in this system of coordinates via cursor keys (arrows).


The display field:

An alphanumeric 2-line display with 20 characters per line enables data and measured values to be indicated together with their short designations and units. The display field consists of a fluorescent display in blue and is easily readable even from a distance.

The system:

A complete Flow Computer System has been developed taking the size of a Eurocard as a basis and using the most advanced SMD technology with large-scale integrated components. A fully assembled printed circuit board incorporates all inputs required for a complex corrector. The range extends from simple volume correctors through density correctors to calorific value correctors. The type of the individual device essentially depends on the software used. Therefore, all conceivable special versions, such as density computers or calorific value computers, are possible.

Thanks to large-scale integrated components, fewer parts are required and this also contributes to making the device reliable.



- LED's
- Sealable slide switch
- RS 232 C port
- 2-line display with 20 characters per line
- Keypad for directly accessing the various device functions
- ID plate with basic data; all other data can be accessed via the **ID** function key
- Main stamp

3 Operating the ERZ 9004 M

Description of function keys

| | |
|----------------------|---|
| Pressure | Indication of the PRESSURE and when pressing the ↑ ↓ keys all pressure-related values. |
| Temp. | Indication of the TEMPERATURE and when pressing the ↑ ↓ keys all temperature-related values. |
| C. Factor | Indication of the COMPRESSIBILITY FACTOR and the VOLUME CORRECTION FACTOR and when pressing the ↑ ↓ keys all the other gas-analysis values. |
| Density | This function is not available with the ERZ 9004 M mass flow computer |
| Output | Indication of all outputs of the device: ANALOG, DIGITAL or DATA INTERFACES. |
| Test | Activation of the FREEZE and CALIBRATION DURING OPERATION functions. This key initiates a dual function (see Chapter 6). |
| Totalizer | Indication of V_a and V_n totalizers. |
| Flow Rate | Indication of the VOLUME AT ACTUAL CONDITIONS and when pressing the ↑ ↓ keys all values related to the volume at actual conditions. |
| S. Density | This function is not available with the ERZ 9004 M mass flow computer. |
| Cal. Value | This function is not available with the ERZ 9004 M mass flow computer. |
| ID ⇒ Mode | Indication of DEVICE DATA and OPERATING MODES. |

Special function keys

↑ ↓ ← →

Clear

Enter

Select

Arrow up / down



To scroll up or down by lines within a column. If you press ↑ at the beginning of a line of a column, you jump to the freeze table, namely to the last value of this table. Now you can select the fourth, third or second value by pressing ↑. If you press ↓ at the end of the freeze table, the display returns to the standard indication of the function key.

Arrow to the right / left



To scroll to the right or left by columns within a line. If you press ←, you can jump via the first column to the last column. If you press →, you can jump via the last column to the first column.

**The following applies to cursor keys in general:
Unoccupied line fields within a column and unoccupied columns within a line are automatically skipped. If the column jumped to is occupied but the line field is empty, the line number is automatically increased until an occupied field is found. When you jump to the next column, the initial line number is selected again.**

Clear / Fault



- a) To clear incorrect inputs in the programming mode. The state prior to inputting the first digit is restored.
- b) To indicate and clear fault messages.
- c) To close user inputs (locking by means of the code number).

Enter

To initiate and complete a data input. All data inputted are accepted.

Select



To switch over from short designations to coordinates and vice versa. Switching over is possible in almost all fields (also in the programming mode).

4 ID Display / Device Data

Press the **ID / Mode** key

| | | | |
|----------|--------------------------------------|---------------------------|----------|
| p | ID lines 0.9 .. 4.5 | 1-17 bar | 1 |
|----------|--------------------------------------|---------------------------|----------|

Press

| | | | |
|----------|--------------------------------------|--------------------------|----------|
| t | ID lines -10 ... 50 | 1-17 °C | 2 |
|----------|--------------------------------------|--------------------------|----------|

← Line numbering

etc.

The ID display comprises a field with 17 data lines, a header line and a bottom line. When you press the **ID / MODE** key, the header line overlays the upper line of the display field. This header line will always remain in the upper part of the display field as long as the ID mode is active. The first data line of the ID data field is shown in the lower part of the display field. You can now scroll in the 17 data lines by pressing the ↑ or ↓ key. The bottom line appears at the end of the data field.

Depiction of the complete ID data field:

| Header line → | ID | lines | | 1-17 |
|---------------|------------------|--------------|-------|------|
| | p | 0.9 ... 4.5 | bar | 1 |
| | t | -10 ... 50 | °C | 2 |
| | Meter G | 6500.0 | | 3 |
| | q | 200 .. 10000 | m3/h | 4 |
| | PV | 600.315 | pm3 | 5 |
| | Fault corr | G7 | yes | 6 |
| ID contents → | Meter type | TRZ | | 7 |
| | PT type | G1151AP | | 9 |
| | PT No. | 634711 | | 10 |
| | TT type | AGG Ex | | 11 |
| | TT No. | 664711 | | 12 |
| | QminHP | 0.0 | m3/h | 13 |
| | Rho<HP | 0 | kg/m3 | 14 |
| | Rho>HP | 0 | kg/m3 | 15 |
| | Gas type: | Natural gas | | 16 |
| | Comp. No. | 604711 | | 17 |
| Bottom line → | ***End of ID *** | | | |

Programming the ID display

Set the switch to "Input" and make your changes after the bottom line "***End of ID***" has been displayed. The values are transferred to the electronic ID display after the device has been disconnected from the power supply.

5 Display Fault / Clear Fault Function

Display fault

The occurrence of a fault is indicated by the **Fault** LED on the front panel of the device or by an isolated contact at the terminal block. The LED flashes if faults are pending. If faults are no longer pending, the LED turns to steady light.

To display fault texts, you must press the **CLEAR / FAULT** key. After you have pressed this key, the display field shows **Fault indication** and the bottom line shows the fault texts at 3-second intervals. All messages are consecutively shown in the display field. As long as the Fault LED flashes, there is still at least one fault pending. If the Fault LED shows steady light, all indicated fault messages are no longer valid and the device has returned to fault-free operation.

Clear fault

There are two operating modes for clearing fault messages: **DIRECT CLEARING** and **INDIRECT CLEARING**. You can select the desired operating mode under **CLEAR / FAULT** in the field Y 17.

- a) Direct clearing
In the fault indication mode you can clear fault messages directly via the **CLEAR / FAULT** key.
- b) Indirect clearing
You cannot clear fault messages unless you have selected the **CLEAR FAULT ?** field (Y 5) using the **ENTER** key.

The time and date of the fault occurred are shown in the fields Y3 and Y4. If there is more than one fault pending, the time and date of the first fault occurred are shown.

The time and date of the last fault acknowledgment are shown in the field Y6.

6 "TEST" Key Special Function: Freeze / Calibration During Operation

The **TEST** key comprises two functions:

1. Freeze function (storage of measured values and operands)
2. Calibration during operation (start / stop function of indexes)

Freeze

Manual freezing

If the freeze mode is set to manual, a freeze operation is performed every time you press the **TEST** key. The frozen values can be read in the columns A ... V, lines 43 ... 46.

Example:

Press the **TEST** key. The display will show the indexes for calibration during operation. At the same time, all freeze coordinates are written with the current values at this moment. Press the **FLOW RATE** key and the display will show the frozen value for the volume at actual conditions. The following is displayed for example:

current value
current value

| | | |
|----|---------|-----|
| qa | 1622.70 | m3h |
| fm | 450.75 | Hz |

Press ↑ four times
current value
frozen value

| | | |
|-----|---------|-----|
| qa | 1622.70 | m3h |
| Fqa | 1621.97 | m3h |

If you press the **TEST** key again, this will result in a repeated freezing of current values.

Automatic freezing

In the automatic freeze mode the desired parameters are preselected in the "Mode" column.

Example:

You want to freeze current values daily at 06:00:00 a.m. First input the code number to enable the change option for the appropriate fields.

Press the **MODE** key.

Press →
current time

| | |
|--------------|-----------------|
| | Mode |
| Time: | 13-28-56 |

Press ↓ four times

Manual freezing

Mode
F mod: Manual

Set the "F mode:" to daily freezing Day(s).

Press the **ENTER** key

Press the **MODE** key three times

Daily freezing

Mode
F mod: Day(s)

Press ↓

Start time

Mode
F time: hh:mm:ss

Input the desired time for the first freeze operation.

Press ↓

Start date

Mode
F date: dd-mm-yy

Input the desired date (no days of the past) for the first freeze operation.

Press ↓

Repetition rate

Mode
F rep.: xx

Input the desired repetition rate. For daily repetition, input "1".

Calibration during operation

Parallel to the indexes for official calibration, separate indexes for standard volume and corrected and uncorrected volumes at actual conditions can be started or stopped via the **TEST** key. At the same time the indexes are started, they are set to "0".

Attention! Each time the indexes are started or stopped, a freeze operation of the appropriate fields is performed in the "Manual" freeze mode. If the freeze mode is not set to "Manual", pressing the **TEST** key will not have any effect on freezing.

7 Summary of Coordinates for the ERZ 9004 M

7.1 Coordinates from A to L

| | | Pressure | | | | Temp. | | | | Flow rate 1 | Flow rate 2 | |
|----|-----------------|-----------------------|--------|--------|--------|-----------------------|--------|--------|--------|-------------|-----------------------|---------------|
| | | A / 01 | B / 02 | C / 03 | D / 04 | E / 05 | F / 06 | G / 07 | H / 08 | I / 09 | J / 10 | K / 11 |
| 1 | Meas. value 1 | bar | | | | ° C | | | | | qa | qn |
| 2 | Meas. value 2 | | | | | | | | | | qa corr | |
| 3 | On / Off 1 | mA | | | | ohm | | | | | f1 Hz | |
| 4 | On / Off 2 | | | | | | | | | | f2 Hz | |
| 5 | Min. range | <i>p min</i> | | | | <i>t min</i> | | | | | <i>qa min</i> | |
| 6 | Max. range | <i>p max</i> | | | | <i>t max</i> | | | | | <i>qa max</i> | |
| 7 | Min. limit | | | | | | | | | | | |
| 8 | Max. limit | | | | | | | | | | | |
| 9 | Default value | <i>p DF value</i> | | | | <i>t DF value</i> | | | | | <i>Difference (%)</i> | |
| 10 | Jump | <i>delta (%)</i> | | | | <i>delta (%)</i> | | | | | <i>delta (%)</i> | |
| 11 | Reference | <i>p stand.d</i> | | | | <i>t stand.</i> | | | | | | |
| 12 | Corr. factor | <i>Input</i> | | | | <i>Input</i> | | | | | | |
| 13 | Averaging | | | | | | | | | | <i>Input</i> | |
| 14 | Min. contact | <i>p min</i> | | | | <i>t min</i> | | | | | <i>qa min</i> | <i>qn min</i> |
| 15 | Max. contact | <i>p max</i> | | | | <i>t max</i> | | | | | <i>qa max</i> | <i>qn max</i> |
| 16 | | | | | | | | | | | | |
| 17 | Mode 1 | <i>Off / 0- / 4-</i> | | | | <i>Off / on</i> | | | | | <i>Off / on</i> | |
| 18 | Mode 2 | <i>Meas./DF value</i> | | | | <i>Meas./DF value</i> | | | | | <i>1 / 1:1 / x:y</i> | |
| 19 | Mode 3 | <i>pa / pe</i> | | | | | | | | | <i>Off / G7 corr</i> | |
| 20 | Last meas.val. | | | | | | | | | | | |
| 21 | Specif. value | | | | | | | | | | | |
| 22 | Delta limit | | | | | | | | | | <i>delta Kvc (%)</i> | |
| 23 | Delta act. val. | | | | | | | | | | Kvc (%) | |
| 24 | Measured val. | | | | | | | | | | | |
| 25 | Corr.meas.val. | | | | | | | | | | Kvc | |
| 26 | Corr. factor | | | | | | | | | | <i>Kv</i> | |
| 27 | Constants | | | | | | | | | | <i>Meas. wheel</i> | |
| 28 | Constants | | | | | | | | | | <i>Ref. wheel</i> | |
| 29 | Constants | | | | | | | | | | <i>Disturb.pulses</i> | |
| 30 | Constants | | | | | | | | | | <i>Ref. pulses</i> | |
| 31 | Constants | | | | | | | | | | <i>Startup pulses</i> | |
| 32 | Constants | | | | | | | | | | <i>f<L</i> | |
| 33 | Constants | | | | | | | | | | <i>t qa min</i> | |
| 34 | Constants | | | | | | | | | | <i>A -2</i> | |
| 35 | Constants | | | | | | | | | | <i>A -1</i> | |
| 36 | Constants | | | | | | | | | | <i>A 0</i> | |
| 37 | Special | | | | | | | | | | <i>A 1</i> | |
| 38 | Special | | | | | | | | | | <i>A 2</i> | |
| 39 | Special | | | | | | | | | | | |
| 40 | Special | | | | | | | | | | qa peak | qn peak |
| 41 | Special | | | | | | | | | | Date / time | Date / time |
| 42 | Special | | | | | | | | | | | |
| 43 | Freeze / CDO | 1st value | | | | 1st value | | | | | 1st value | 1st value |
| 44 | Freeze / CDO | 3rd value | | | | 3rd value | | | | | 2nd value | |
| 45 | Freeze / CDO | | | | | | | | | | 3rd value | |
| 46 | Freeze / CDO | | | | | | | | | | 4th value | |

Locked via calibration switch (E) ***Italic*** Locked via code number (B) ***Italic*** No locking (A)

7.2 Coordinates from M to T

| | | C. factor L / 12 | Analog 1 M / 13 | Analog 2 N / 14 | Analog 3 O / 15 | Analog 4 P / 16 | Digital 1 Q / 17 | Digital 2 R / 18 |
|----|-----------------|----------------------|-------------------------|-------------------------|-------------------------|-------------------------|----------------------|----------------------|
| 1 | Meas. value 1 | VCF | Phys. value | Phys. value | Phys. value | Phys. value | Designation | Designation |
| 2 | Meas. value 2 | K | | | | | | |
| 3 | On / Off 1 | | I 1 (mA) | I 2 (mA) | I 3 (mA) | I 4 (mA) | | |
| 4 | On / Off 2 | | | | | | | |
| 5 | Min. range | | <i>Phys. value</i> | <i>Phys. value</i> | <i>Phys. value</i> | <i>Phys. value</i> | | |
| 6 | Max. range | | <i>Phys. value</i> | <i>Phys. value</i> | <i>Phys. value</i> | <i>Phys. value</i> | | |
| 7 | Min. limit | | | | | | | |
| 8 | Max. limit | | | | | | | |
| 9 | Default value | <i>K DF value</i> | <i>Cal. curr.</i> | <i>Cal. curr.</i> | <i>Cal. curr.</i> | <i>Cal. curr.</i> | <i>Pulse width</i> | <i>Pulse width</i> |
| 10 | Jump | | | | | | | |
| 11 | Reference | | <i>Selection</i> | <i>Selection</i> | <i>Selection</i> | <i>Selection</i> | <i>Selection</i> | <i>Selection</i> |
| 12 | Corr. factor | | <i>Input</i> | <i>Input</i> | <i>Input</i> | <i>Input</i> | | |
| 13 | Averaging | <i>Input</i> | <i>Input</i> | <i>Input</i> | <i>Input</i> | <i>Input</i> | | |
| 14 | Min. contact | | | | | | | |
| 15 | Max. contact | | | | | | | |
| 16 | | | | | | | | |
| 17 | Mode 1 | <i>B&B / K=c</i> | <i>Off / 0- /4- /CC</i> | <i>Off / 0- /4- /CC</i> | <i>Off / 0- /4- /CC</i> | <i>Off / 0- /4- /CC</i> | <i>Off / on</i> | <i>Off / on</i> |
| 18 | Mode 2 | <i>Type of gas</i> | | | | | | |
| 19 | Mode 3 | | | | | | | |
| 20 | Last meas.val. | | | | | | | |
| 21 | Specif. value | | | | | | | |
| 22 | Delta limit | Density calc. | | | | | | |
| 23 | Delta act. val. | Stand. dens. | | | | | | |
| 24 | Measured val. | Z | | | | | | |
| 25 | Corr.meas.val. | Zn | | | | | | |
| 26 | Corr. factor | | | | | | | |
| 27 | Constants | | | | | | <i>Pulse value 1</i> | <i>Pulse value 2</i> |
| 28 | Constants | | | | | | | |
| 29 | Constants | | | | | | | |
| 30 | Constants | | | | | | | |
| 31 | Constants | | | | | | | |
| 32 | Constants | | | | | | | |
| 33 | Constants | | | | | | | |
| 34 | Constants | | | | | | | |
| 35 | Constants | | | | | | | |
| 36 | Constants | | | | | | | |
| 37 | Special | | | | | | | |
| 38 | Special | | | | | | | |
| 39 | Special | | | | | | | |
| 40 | Special | Zn | | | | | | |
| 41 | Special | Z | | | | | | |
| 42 | Special | | | | | | | |
| 43 | Freeze / CDO | 1st value | | | | | | |
| 44 | Freeze / CDO | 2nd value | | | | | | |
| 45 | Freeze / CDO | | | | | | | |
| 46 | Freeze / CDO | | | | | | | |

Locked via calibration switch (E) ***Italic*** Locked via code number (B) ***Italic*** No locking (A)


7.3 Coordinates from U to Y

| | | Data 1 S / 19 | Data 2 T / 20 | Totalizer U / 21 | Test V / 22 | ID W / 23 | Mode X / 24 | Fault Y / 25 |
|----|--------------|------------------|------------------|------------------------|----------------|--------------|-------------------------|-------------------|
| 1 | Special | Designation | Designation | Vn | Vn | Designation | Designation | Designation |
| 2 | Special | | | Vac | Va corr | ID | <i>Time</i> | Indication |
| 3 | Special | | | Va | Va | ID | <i>Date</i> | Fault time |
| 4 | Special | | | M | | ID | <i>Code No.</i> | Fault date |
| 5 | Special | | | LVa | | ID | <i>Operat. hrs</i> | Clear fault |
| 6 | Special | | | HVa | | ID | <i>Freeze mode</i> | Last clearing |
| 7 | Special | | | tp setpoint | | ID | <i>Freeze time</i> | |
| 8 | Special | | | | | ID | <i>Freeze rep.</i> | |
| 9 | Special | | | | | ID | <i>Freeze date</i> | |
| 10 | Special | | | | | ID | <i>Last freeze</i> | |
| 11 | Special | | | | | ID | <i>Clock/external</i> | |
| 12 | Special | | | | | ID | <i>Auto / revision</i> | |
| 13 | Special | | | | | ID | <i>Manu./channel</i> | |
| 14 | Special | | | | | ID | <i>Print time start</i> | |
| 15 | Special | | | | | ID | <i>Print interval</i> | |
| 16 | Special | | | | | ID | <i>Revis. interval</i> | |
| 17 | Special | <i>Off / on</i> | <i>Off / on</i> | <i>Oper./malfunct.</i> | | ID | <i>Last print</i> | <i>Fault mode</i> |
| 18 | Special | | <i>Mode</i> | | | ID | <i>Limit. contacts</i> | |
| 19 | Special | | | | | Designation | <i>Display mode</i> | |
| 20 | Special | | | <i>If Va</i> | | | <i>Comp. type</i> | |
| 21 | Special | | | <i>If Vn</i> | | | <i>Version</i> | |
| 22 | Special | | | | | | <i>Comp. No.</i> | |
| 23 | Special | | | | | | <i>AD corr.</i> | |
| 24 | Special | | | | | | <i>RTC corr.</i> | |
| 25 | Special | | | <i>Setting Vac</i> | | | <i>System fr. fV</i> | |
| 26 | Special | | | <i>Setting Vn</i> | | | <i>System fr. fD</i> | |
| 27 | Special | <i>Baud</i> | <i>Baud</i> | <i>Setting M</i> | | | <i>Lamp test b.</i> | |
| 28 | Special | | | <i>Setting Va</i> | | | <i>Lamp test t.</i> | |
| 29 | Special | | | <i>Setting VacD</i> | | | | |
| 30 | Special | | | <i>Setting VnD</i> | | | | |
| 31 | Special | | | <i>Setting MD</i> | | | | |
| 32 | Special | | | <i>Setting VaD</i> | | | | |
| 33 | Special | | | <i>Setting LVn</i> | | | | |
| 34 | Special | | | <i>Setting HVn</i> | | | | |
| 35 | Special | | | | | | | |
| 36 | Special | | | | | | | |
| 37 | Special | | | VacD dist.quan | | | | |
| 38 | Special | | | VnD dist.quan. | | | | |
| 39 | Special | | | VaD dist.quan. | | | | |
| 40 | Special | | | | | | | |
| 41 | Special | | | | | | | |
| 42 | Special | | | | | | | |
| 43 | Freeze / CDO | | | Va corr | VacD dist.quan | | | |
| 44 | Freeze / CDO | | | Vn | VnD dist.quan. | | | |
| 45 | Freeze / CDO | | | Va | VaD dist.quan. | | | |
| 46 | Freeze / CDO | | | | | | | |

Locked via calibration switch (E) ***Italic*** Locked via code number (B) ***Italic*** No locking (A)


8. Summary of Device Functions to Be Called up with Function Keys

8.1 Description of the matrix structure



8.2 Device-specific functions

8.2.1 Pressure at measuring conditions




↓ Direct access

| | A / 01 | Description of coordinates | Unit | Comment(s) | |
|----|--------|----------------------------|---|------------|-------|
| 1 | A | p | Measured value for pressure | bar a | |
| 3 | A | I | Measured value for input current | mA | |
| 5 | E | p< | Lower pressure transmitter adjusting value and fault limiting value | bar a/g | 2) |
| 6 | E | p> | Upper pressure transmitter adjusting value and fault limiting value | bar a/g | 3) |
| 9 | B | p DF | Default value (replacement value if a fault occurs) | bar a/g | |
| 10 | B | p JP | Max. permissible jump from measured value to measured value | % | |
| 11 | E | pn | Standard pressure | bar a | 4) |
| 12 | E | pc | Correction factor: balancing A/D converter offset | | |
| 14 | B | pmin | Min. limiting value contact | bar a/g | |
| 15 | B | pmax | Max. limiting value contact | bar a/g | |
| 17 | E | p mod1 | Mode 1: current input = off (default value) / 0-20mA / 4-20mA | | 1) |
| 18 | E | p mod2 | Mode 2: if a fault occurs = default value / measured value | | 1) |
| 19 | E | p mod3 | Mode 3: pressure transmitter = pabs / pe | | 1) 5) |
| 43 | A | Fp | Freeze: pressure | bar a | |
| 44 | A | FI | Freeze: input current | mA | |

- 1) Rolling texts! Press the **MODE** key to make your changes.
- 2) Assigning 0 mA or 4 mA to the lower adjusting value.
- 3) Assigning 20 mA to the upper adjusting value.
- 4) Reference quantity for standard conditions of the country concerned.

8.2.2 Temperature at measuring conditions (PT 100)



↓ Direct access

| | E / 05 | Description of coordinates | Unit | Comment(s) | |
|----|--------|----------------------------|--|------------|----|
| 1 | A | t | Measured value for temperature | °C | |
| 3 | A | R | Measured value for input resistance | ohm | |
| 5 | E | t< | Lower fault limiting value | °C | |
| 6 | B | t> | Upper fault limiting value | °C | |
| 9 | B | t DF | Default value (replacement value if a fault occurs) | °C | |
| 10 | B | t JP | Max. permissible jump from measured value to measured value | % | |
| 11 | E | tn | Standard temperature | °C | 2) |
| 12 | E | tc | Correction factor: balancing A/D converter offset | | |
| 14 | B | tmin | Min. limiting value contact | °C | |
| 15 | B | tmax | Max. limiting value contact | °C | |
| 17 | E | t mod1 | Mode 1: resistance input = off (default value) / on (PT 100) | | 1) |
| 18 | E | t mod2 | Mode 2: if a fault occurs = default value / measured value | | 1) |
| 43 | A | Ft | Freeze: temperature | °C | |
| 44 | A | FR | Freeze: input resistance | ohm | |

- 1) Rolling texts! Press the **MODE** key to make your changes.
- 2) Assigning 0 mA or 4 mA to the lower adjusting value.
- 3) Assigning 20 mA to the upper adjusting value.
- 4) Reference quantity for standard conditions of the country concerned.

8.2.3 Volume flow rate at actual conditions




Flow Rate


↓ Direct access

| | J / 10 | Description of coordinates | Unit | Comment(s) | |
|----|--------|----------------------------|--|------------|-------|
| 1 | A | qa | Calculated volume flow rate at actual conditions | m3/h | |
| 2 | A | qac | Calculated corrected volume flow rate at actual conditions | m3/h | 5) |
| 3 | A | fm | Measuring channel input value | Hz | |
| 4 | A | fr | Reference channel input value | Hz | |
| 5 | E | qa<L | Lower fault limiting value of volume meter | m3/h | |
| 6 | E | qa>L | Upper fault limiting value of volume meter | m3/h | |
| 9 | B | q D% | Max. permissible difference between qam and qar | % | 2) |
| 10 | B | q JP | Max. permissible jump from measured value to measured value | % | |
| 13 | B | q A | Averaging factor for flow rate calculation and display | | |
| 14 | B | qamin | Min. limiting value contact | m3/h | |
| 15 | B | qamax | Max. limiting value contact | m3/h | |
| 17 | E | Va mod1 | Mode 1: volume measurement = on / off | | 1) 3) |
| 18 | E | Va mod2 | Mode 2: operating mode = 1-channel / 2-chan. 1:1 / 2- chan. x:y | | 1) 4) |
| 19 | E | Fault corr. G7 | Mode: characteristic correction acc. to G7 = no / yes | | 1) |
| 22 | E | d Kvc>L | Limiting value for max. deviation due to characteristic correction | % | 5) |
| 23 | A | d Kvc | Deviation of corrected pulse value (Kvc) from pulse value (Kv) | % | 5) |
| 25 | A | Kvc | Corrected pulse value of the volume meter | pulses/m3 | 5) |
| 26 | E | Kv | Volume meter pulse value | pulses/m3 | |
| 27 | E | MWP | Number of blades of the measuring wheel * 10 | | |
| 28 | E | RWP | Number of blades of the reference wheel * 10 | | |
| 29 | E | DP | Limiting value for the number of disturbing pulses (official value 10) | pulses | 6) |
| 30 | E | RP | Limiting value for the number of reference pulses (off. val. 10000) | pulses | 6) |
| 31 | E | P start | Suppression of fault messages during startup of volume meter | pulses | |
| 32 | E | f<L | Min. volume meter frequency | Hz | 7) |
| 33 | E | t qmin | Max. operating time for qa < qa min | sec | 8) |
| 34 | E | A-2 | Polynomial coefficient for characteristic correction | | 5) |
| 35 | E | A-1 | Polynomial coefficient for characteristic correction | | 5) |
| 36 | E | A 0 | Polynomial coefficient for characteristic correction | | 5) |
| 37 | E | A 1 | Polynomial coefficient for characteristic correction | | 5) |
| 38 | E | A 2 | Polynomial coefficient for characteristic correction | | 5) |
| 40 | A | >qa | Max. qa value (peak value) | m3/h | |
| 41 | A | > | Time of max. value (date / time) | | |
| 43 | A | Fqa | Freeze: volume flow rate at actual conditions | m3/h | |
| 44 | A | Fqac | Freeze: corrected volume flow rate at actual conditions | m3/h | 5) |
| 45 | A | Ffm | Freeze: measuring channel frequency | Hz | |
| 46 | A | Ffr | Freeze: reference channel frequency | Hz | |

Comments: See next page.

8.2.4 Standard volume flow rate



Indirect access by pressing the  key

| | | K / 11 | Description of coordinates | Unit | Comment(s) |
|----|---|--------|--------------------------------------|-------------------|------------|
| 1 | A | qn | Calculated standard volume flow rate | m ³ /h | |
| 14 | B | qnmin | Min. limiting value contact | m ³ /h | |
| 15 | B | qnmax | Max. limiting value contact | m ³ /h | |
| 40 | A | >qn | Max. qn value (peak value) | m ³ /h | |
| 41 | A | > | Time of max. value (date / time) | | |
| 43 | A | Fqn | Freeze: standard volume flow rate | m ³ /h | |

Comments on the column for the volume flow rate at actual conditions

- 1) Rolling texts! Press the **MODE** key to make your changes.
- 2) If the percentage deviation between the qa measuring channel (qam) and the qa reference channel (qar) is smaller than the preset value, the arithmetic mean is used to display the qa flow rate and the qa current output. If the deviation is greater, the greater one of the two flow rates is used.
Attention! The calculation or display of flow rates does not have any effect on the calculation and monitoring of totalizers.
- 3) Va-mod1 = off The Flow Computer operates in the pulse counting mode without monitoring volume limits including f<L.
- 4) Va-mod2 = 1-chan. J/9, J/27 - J/31 not active
Va-mod2 = 1:1 J/27, J/28 not active
Va-mod2 = x:y J/29, J/30, J/31 not active
- 5) ECL = none The field is not displayed.
- 6) Number of permissible missing pulses for a quantity of reference pulses before an alarm is tripped.
- 7) Lower limiting frequency of the volume meter. When the frequency drops below the lower limiting frequency, correction is no longer carried out.
- 8) Time in seconds during which the volume meter can be operated below qa-min before an alarm is tripped.

8.2.5 Analysis



C. Factor


↓ Direct access

| | L / 12 | Description of coordinates | Unit | Comment(s) |
|----|--------|----------------------------|-------|------------|
| 1 | A | VCF | | |
| 2 | A | K | | |
| 9 | B | K DF | | |
| 13 | B | VCF A | | |
| 17 | B | BB mod1 | | 1) |
| 18 | B | G sel | | 1) |
| 22 | A | Racalc | kg/m3 | |
| 23 | A | Rn-TAB | kg/m3 | |
| 24 | A | Z | | |
| 25 | A | Zn | | |
| 43 | A | FVCF | | |
| 44 | A | FK | | |


1) Rolling texts! Press the **MODE** key to make your changes.

8.3 Outputs

8.3.1 Current Outputs




↓ Direct access



| | | M / 13 | N / 14 | O / 15 | P / 16 | Description of coordinates | Unit | Comment(s) |
|----|---|--------|--------|--------|--------|--|----------|------------|
| 1 | A | I1O | I2O | I3O | I4O | Physical value for output n | variable | |
| 3 | A | I | I | I | I | Indication of current for output n | mA | |
| 5 | B | O1< | O2< | O3< | O4< | Lower limiting value for output n | variable | 2) |
| 6 | B | O1> | O2> | O3> | O4> | Upper limiting value for output n | variable | 2) |
| 9 | B | I1CC | I2CC | I3CC | I4CC | Calibrating current default value | mA | 3) |
| 11 | B | O1 CS | O2 CS | O3 CS | O4 CS | Selection of coordinate for output n | | 4) |
| 12 | B | I1 c | I2 c | I3 c | I4 c | Correction factor (D/A converter) | | |
| 13 | B | I1 A | I2 A | I3 A | I4 A | Averaging factor (damping) | | |
| 17 | B | I1 mod | I2 mod | I3 mod | I4 mod | Mode: operating mode = off / 0-20 mA / 4-20 mA / calibrating current | | 1) |

- 1) Rolling texts! Press the **MODE** key to make your changes.
- 2) Assigning physical limits to 0/4 mA or 20 mA.
- 3) If the "calibration current" mode is selected under I(n)-mod, the corresponding output (n) operates as current transmitter. The current value preselected in this field will be outputted.
- 4) Selection of measured value to be outputted as current. Preselected the value via ist coordinate. Example: See Annex D.

8.3.2 Dispatcher outputs




Indirect access by
pressing the

→ key 4 times →


| | | Q / 17 | R / 18 | Description of coordinates | Unit | Comment(s) |
|----|---|--------------|--------------|---|------|------------|
| 1 | A | Dispatcher 1 | Dispatcher 2 | Designation of the selected dispatcher | | |
| 9 | B | PW | PW | Setting the dispatcher pulse width (50 - 300) | ms | |
| 11 | B | D1 CS | D2 CS | Assignment of the dispatcher = Va / Vn / Vac | | 1) |
| 17 | B | D1 mod | D2 mod | Mode: dispatcher = off / on | | 1) |
| 27 | B | Df1 | Df2 | Pulse value (0.001 to 10000) | | |

- 1) Rolling texts! Press the **MODE** key to make your changes.

8.3.3 Data interface



Indirect access by pressing the



| | S / 19 | T / 20 | Description of coordinates | Unit | Comment(s) |
|----|--------|-----------|----------------------------|---|------------|
| 1 | A | Data 1: | Data 2: | Designation of the RS 232 C data interface | 2) |
| 17 | B | D mod1 | D mod1 | Mode1: Interface off / on | 1) |
| 18 | B | | D mod2 | Mode 2: Data / HP DeskJet / EPSON | 1) |
| 27 | B | Baud rate | Baud rate | Data 1: bit rate = (1200 / 2400 / 4800 / 9600) Data 2: bit rate = (2400 / 4800 / 9600 / 19200) | 1) |
| 30 | B | | Baud rate 3 | Data 3: bit rate = DSfG standard (9600) | 1) |
| 31 | B | | D mod3 | Data 3: Interface off / on | 1) |
| 32 | B | | DSfG addr.: | User address on the DSfG bus (1 to 31) | |
| 35 | B | | Master: | Bus master = off / on | 1) |

- 1) Rolling texts! Press the **MODE** key to make your changes.
- 2) Data 1: Interface on the front panel.
By means of this interface it is possible to read all fields from the corrector or rewrite all programmable fields.
Data 2: C1 interface on the rear panel.
You can adjust this interface to different printer protocols via the "D mod2" field or handle it like the "Data 1" interface. Make your selection via the fields T17, T 18 and T27.

C2 interface on the rear panel.
This interface can (optionally) be fitted as a standard data communication interface (DSfG). Make your selection via the fields T30, T31, T32 and T35.

8.4 Totalizer



↓ Direct access

| | | U / 21 | Description of coordinates | Unit | Comment(s) |
|----|---|-----------|--|------|------------|
| 1 | A | Vn | Main totalizer for standard volume | m3 | |
| 2 | A | Vac | Main totalizer for corrected volume at actual conditions | m3 | 2) |
| 3 | A | Va | Main totalizer for uncorrected volume at actual conditions | m3 | |
| 4 | A | M | Main totalizer for mass | kg | |
| 5 | A | LVn | Low tariff totalizer for standard volume | m3 | |
| 6 | A | HVn | High tariff totalizer for standard volume | m3 | |
| 7 | A | tb setp. | tariff band setpoint (standard volume flow rate qn) | m3/h | |
| 17 | E | TOT. mod: | Mode: Main totalizers = alarm run(ning) / alarm stop | | 1) 3) |
| 20 | B | If Va: | Va totalizer factor output contacts (1, 10, 100, 1000) | | 1) |
| 21 | B | If Vn: | Vn totalizer factor output contacts (1, 10, 100, 1000) | | 1) |
| 25 | E | Vac set | Setting: Main totalizer for corrected volume at operating conditions | m3 | 2) 4) |
| 26 | E | Vn set | Setting: Main totalizer for standard volume | m3 | 4) |
| 27 | E | M-set | Setting: Main totalizer for mass | kg | 4) |
| 28 | E | Va set | Setting: Main totalizer for uncorrected volume at operat. cond. | m3 | 4) |
| 29 | E | VacD set | Setting: Disturbing quantity totalizer for corr. volume at operat. cond. | m3 | 2) 4) |
| 30 | E | VnD set | Setting: Disturbing quantity totalizer for standard volume | m3 | 4) |
| 31 | E | MD-set | Setting: Disturbing quantity totalizer for mass | kg | 4) |
| 32 | E | VaD set | Setting: Disturbing quantity totalizer for uncorr. vol. at operat. cond. | m3 | 4) |
| 33 | E | LVn set | Setting: Low tariff totalizer for standard volume | m3 | 4) |
| 34 | E | HVn set | Setting: High tariff totalizer for standard voume | m3 | 4) |
| 37 | A | VacD | Disturbing quantity totalizer for corrected volume at actual cond. | m3 | 2) |
| 38 | A | VnD | Disturbing quantity totalizer for standard volume | m3 | |
| 39 | A | VaD | Disturbing quantity totalizer for uncorrected volume at actual cond. | m3 | |
| 43 | A | FVac | Freeze: Main totalizer for corrected volume at actual conditions | m3 | 2) |
| 44 | A | FVn | Freeze: Main totalizer for standard volume | m3 | |
| 45 | A | FVa | Freeze: Main totalizer for uncorrected volume at actual cond. | m3 | |

The number of digit positions preceding or following a decimal point depends on the size of the flow meter preset in the ID data field.

| | Size <= G 2500 | | Size > G 2500 | |
|-----|---|---|---|---|
| | Digit positions preceding / following a decimal point | | Digit positions preceding / following a decimal point | |
| Vn | 10 | 3 | 11 | 2 |
| Va | 9 | 3 | 10 | 2 |
| Vac | 9 | 3 | 10 | 2 |

- 1) Rolling texts! Press the **MODE** key to make your changes.
- 2) Fault corr. G7 = no: The field is not displayed.
- 3) Tot-mod = alarm stop: In the event of an alarm (Annex D) the main totalizers stop and the disturbing quantity totalizers start to run.
Tot-mod = alarm run: In the event of an alarm (Annex D) the main totalizers continue to run and in addition to this, the disturbing quantity totalizers start to run.
- 4) To set the totalizer, you must first input the code number and then set the calibrations witch to "Input". Example: see Annex D.
Attention! Observe the sequence of operations.

8.5 Test




↓ Direct access

| | V / 22 | Description of coordinates | Unit | Comment(s) |
|----|--------|----------------------------|------|------------|
| 1 | A | CVn | m3 | 2) |
| 2 | A | CVac | m3 | 1) 2) |
| 3 | A | CVa | m3 | 2) |
| 43 | A | FVacD | m3 | 1) |
| 44 | A | FVnD | m3 | |
| 45 | A | FVaD | m3 | |

- 1) Fault corr. G7 = "none": The field ist not displayed.
- 2) The totalizer can be started and stopped independetly of the main totalizer via the **TEST** key. See also Chapter "**TEST**" Key Special Function.

8.6 ID display




↓ Direct access


| | W / 23 | Description of coordinates | Unit | Comment(s) |
|----|--------|----------------------------|---|------------|
| 1 | A | Designation | ID header line | |
| 2 | A | ID | 1st line of ID data: pressure range | bar |
| 3 | A | ID | 2nd line of ID data: temperature range | °C |
| 4 | A | ID | 3rd line of ID data: volume meter G size | |
| 5 | A | ID | 4th line of ID data: flow rate range | m3/h |
| 6 | A | ID | 5th line of ID data: volume meter pulse value | pulses/m3 |
| 7 | A | ID | 6th line of ID data: fault correction (characteristic correction G7) | |
| 8 | A | ID | 7th line of ID data: type of volume meter | |
| 9 | A | ID | 8th line of ID data: serial No. of volume meter | |
| 10 | A | ID | 9th line of ID data: type of pressure transmitter | |
| 11 | A | ID | 10th line of ID data: serial No. of pressure transmitter | |
| 12 | A | ID | 11th line of ID data: type of temperature transmitter | |
| 13 | A | ID | 12th line of ID data: serial No. of temperature transmitter | |
| 14 | A | ID | 13th line of ID data: QminHP | m3/h |
| 15 | A | ID | 14th line of ID data: Rho<HP | kg/m3 |
| 16 | A | ID | 15th line of ID data: Rho>HP | kg/m3 |
| 17 | A | ID | 16th line of ID data: gas type | |
| 18 | A | ID | 17th line of ID data: serial No. of corrector | |
| 19 | A | Designation | ID bottom line | |
| 25 | E | PT type | Input field: G1151AP / G1151GP / 2088A / 3051CA | 1) |
| 26 | E | PT No. | Input field: serial No. of pressure transmitter | |
| 27 | E | PT min | Input field: lower adjusting value of pressure transmitter | bar a/g |
| 28 | E | PT max | Input field: upper adjusting value of pressure transmitter | bar a/g |
| 29 | E | TT type | Input field: AGG Ex / Q/4407 / PT100 | 1) |
| 30 | E | TT No. | Input field: serial No. of temperature transmitter | |
| 31 | E | TT min | Input field: lower limiting value of temperature transmitter | °C |
| 32 | E | TT max | Input field: upper limiting value of temperature transmitter | °C |
| 33 | E | Meter type | Input field: TRZ / DKZ / WBZ08 | 1) |
| 34 | E | Meter No. | Input field: serial No. of volume meter | |
| 35 | E | Q min | Input field: lower limiting value of volume meter | m3/h |
| 36 | E | Q max | Input field: upper limiting value of volume meter | m3/h |
| 37 | E | Meter size | Input field: volume meter G size | |
| 38 | E | QminHP | Input field: lower limiting value of volume meter above high pressure | m3/h |
| 39 | E | RhominHP | Input field: min. density at actual conditions above high press. | kg/m3 |
| 40 | E | RhomaxHP | Input field: max. density at actual conditions above high press. | kg/m3 |
| 41 | E | Gas type | Input field: natural gas / ethylene / oxygen / hydrogen / nitrogen | 1) |
| 42 | E | PV | Input field: volume meter pulse value | pulses/m3 |

1) Rolling texts! Press the **MODE** key to make your changes.

For more information, please refer to Chapter 4.

8.7 Mode




Indirect access by
pressing the  key

| | X / 24 | Description of coordinates | Unit | Comment(s) |
|----|--------|----------------------------|--|------------|
| 1 | A | Mode | Heading | |
| 2 | B | Time: | Current time | |
| 3 | B | Date: | Current date | |
| 4 | E | Code No. | User code (can only be defined if slide switch is set to "Input") | |
| 5 | A | Oph | Indication of operating hours | hours |
| 6 | B | F mod: | Mode: Freeze = manual / minute / hour / day / week / month | 1) 2) |
| 7 | B | F time: | Time: Freeze start | |
| 8 | B | F date: | Date: Freeze start | |
| 9 | B | F rep.: | Repetition rate for automatic freezing | 2) |
| 10 | A | F | Indication of time / date of the last freeze operation | |
| 11 | B | Pr mod1: | Mode: Print initiation = clock / external | 1) 3) |
| 12 | B | Pr mod2: | Mode: Switching over = automatic / revision | 1) 4) |
| 13 | B | Pr mod3: | Mode: Printout = ---- / manual / channel | 1) 5) |
| 14 | B | Pr start: | Start time for automatic printout | |
| 15 | B | Auto rep: | Repetition time for automatic printout (1, 2, 3, 4, 6, 12, 24 hours) | hours |
| 16 | B | Rev.rep: | Repetition time for revision printout (1 to 99 minutes) | minutes |
| 17 | A | LPr | Last print time | |
| 18 | B | ><Cont.: | Limiting contacts: Definition of coordinate | 6) |
| 19 | B | Display mod: | Mode: Active display = 30 min. / 6h - 18h / continuous duty | 1) |
| 20 | A | Comp. type: | Corrector version, e.g.: ERZ 9004 M | |
| 21 | A | V | Software version: Version date | |
| 22 | B | Comp. No.: | Serial number | |
| 23 | E | AD corr.: | Correction factor for AD measurement | |
| 24 | E | RTC corr.: | Correction factor for real-time clock | |
| 25 | E | f Vol | Internal clock frequency for volume frequencies | Hz |
| 26 | E | f Den | Internal clock frequency for density frequencies | Hz |
| 27 | A | Lamp test b. | Lamp test of bottom line of display | |
| 28 | A | Lamp test t. | Lamp test of top line of display | |

- 1) Rolling texts! Press the **MODE** key to make your changes.
- 2) If F-mod = "manual" is selected, the F-rep mode is not active.
If F-mod = "minute, hour, day, week, or month" is selected, the freeze operation is carried out periodically in connection with the field X9. See also Chapter "'Test" Key Special Function'.
- 3) Printing is initiated via the internal clock or an external contact.
- 4) Automatic printing in connection with the field X15 or revision printing in connection with the field X16.
- 5) Initiate printing manually, print a channel protocol.
- 6) Selection of the measured value whose min. and max. limiting value contacts should be available as output contacts. The measured value is to be preselected via its coordinate.

8.8 Clear / Fault




↓ Direct access

| | | Y / 25 | Description of coordinates | Unit | Comment(s) |
|----|---|------------------|--|------|------------|
| 1 | A | Fault indication | Heading | | |
| 2 | A | | Indication of fault number and type or "Operation" | | |
| 3 | A | Time: | Time of the first fault message | | |
| 4 | A | Date: | Date of the first fault message | | |
| 5 | A | Clear fault? | Indirect clearing function | | |
| 6 | A | CF | Indication of the time of clearing the last faults | | |
| 17 | B | Fault mode: | Mode: Fault clearing = direct / indirect | | 1) |

1) Rolling texts! Press the **MODE** key to make your changes.

For more information, please refer to Chapter 5.

Annex A Function Chart for the ERZ 9004 M Mass Flow Computer



Transmission

- Π Pulses / current
- Current


Devices:

- FM = Vortex meter, turbine meter or
- PT = Pressure transmitter
- TT = Temperature transmitter
- ERZ = Computer

Indications / outputs

- | | |
|---|----------------------------------|
| V_a = Volume at actual conditions (m^3) | K = Compressibility factor |
| V_n = Standard volume (m^3) | p_n = Standard pressure (bar) |
| p = Pressure (bar) | T_n = Standard temperature (K) |
| t = Temperature ($^{\circ}C$) | |
| T = $273.15 (K) + t$ | |

Annex B Block Diagram for the ERZ 9004 M



Isolated amplifiers are not incorporated into the computer

* If a turbine meter is used, the device can be fitted with an explosion-protected isolating amplifier.

** These inputs are not available with the ERZ 9004 / ERZ 9004 M

— — option

Annex C Survey of Equations Used

Volume at actual conditions

| | | |
|----------|--|----------------|
| V_a | = Volume at actual conditions | (m^3) |
| p_V | = Volume pulse | |
| K_V | = Meter factor | $(pulses/m^3)$ |
| K_{Z1} | = V_a totalizer factor (output contact only) | |

$$V_a = \frac{p_V}{K_V} \cdot \frac{1}{K_{Z1}}$$

Volume correction factor

| | | |
|-------|-------------------------------|------------|
| VCF | = Volume correction factor | |
| V_n | = Standard volume | (m^3) |
| V_a | = Volume at actual conditions | (m^3) |
| p | = Absolute pressure | (bar) |
| T | = Temperature | $(Kelvin)$ |
| T_n | = Standard temperature | $(Kelvin)$ |
| p_n | = Standard pressure | (bar) |
| K | = Compressibility factor | |

$$VCF = \frac{V_n}{V_a} \cdot \frac{p \cdot T_n}{p_n \cdot T \cdot K}$$

Compressibility factor

| | | |
|-------|--|--|
| K | = Compressibility factor | |
| Z | = Real gas factor | |
| Z_n | = Real gas factor at standard conditions | |

$$K = \frac{Z}{Z_n}$$

Calculation is made in accordance with GERG 88 pursuant to G 9.

Standard volume / Mass

| | | |
|----------|---|------------|
| M | = Mass | (kg) |
| Rho_b | = Density | (kg/m^3) |
| K_{Z2} | = V_n / M index factor (output contact) | |

$$V_n = V_a \cdot VCF_{(Rho)} \cdot \frac{1}{K_{Z2}}$$

$$M = V_a \cdot Rho_b \cdot \frac{1}{K_{Z2}}$$

Volume flow rate at actual conditions

| | | |
|----------|------------------------------------|----------------|
| Q_{Va} | = Volume flow rate at actual cond. | (m^3/h) |
| f_V | = Volume transmitter frequency | (Hz) |
| K_V | = Meter factor | $(pulses/m^3)$ |

$$Q_{Va} = \frac{f_V}{K_V} \cdot 3600$$

Standard volume flow rate

| | | |
|----------|--------------------------------|----------------|
| Q_{Vn} | = Standard volume flow rate | (m^3/h) |
| f_V | = Volume transmitter frequency | (Hz) |
| K_V | = Meter factor | $(pulses/m^3)$ |
| VCF | = Volume correction factor | |

$$Q_{Vn} = \frac{f_V}{K_V} \cdot VCF \cdot 3600$$

Gas meter error curve linearization

Correction is made using a quartic polynomial which adequately simulates the fault curve of the gas meter.

Fault equation: $F = A_{-2} \cdot Q_{Va}^{-2} + A_{-1} \cdot Q_{Va}^{-1} + A_0 + A_1 \cdot Q_{Va} + A_2 \cdot Q_{Va}^2$

| | | |
|----------|------------------------------------|-----------|
| F | = Deviation of the error curve | $(\%)$ |
| Q_{Va} | = Volume flow rate at actual cond. | (m^3/h) |
| A_n | = Constants | |

The following values are permanently programmed in the computer: $A_1: 10^{-4}$ $A_2: 10^{-8}$

The constants A_n ($n = -2$ to $n = 2$) are calculated from the measured value pairs error F_i and flow rate Q_{Vai} . Instead of the constant meter factor K_V the corrected meter factor K_{Vc} is used for subsequent calculation or correction.

$$K_{Vc} = K_V \cdot \left(1 + \frac{F}{100}\right)$$

Thus, the volume flow rate at actual conditions Q_{Va} is calculated from the following equation:

| | | |
|----------|--------------------------------|----------------|
| f_V | = Volume transmitter frequency | (Hz) |
| K_{Vc} | = Corrected meter factor | $(pulses/m^3)$ |

$$Q_{Va} = \frac{f_V}{K_{Vc}} \cdot 3600$$

Annex D Operating Examples

Displaying measured values and constants on the ERZ 9004 M mass flow computer

The columns B, C, D, F, G, H and I are not applicable to the ERZ 9004 M.

1. example

Press the **PRESSURE** key

| | | |
|----------|--------------|--------------|
| P | 34,26 | bar a |
| I | 13,50 | mA |

Press ↓ twice

| | | |
|--------------|--------------|--------------|
| P | 34,26 | bar a |
| P< | 10,00 | bar a |

p min

Press ↓

| | | |
|--------------|--------------|--------------|
| P | 34,26 | bar a |
| P> | 50,00 | bar a |

p max

Press →

| | | |
|--------------|--------------|--------------|
| t | 10,57 | bar a |
| t> | 30,00 | mA |

t max

Press →

| | | |
|---------------|----------------|-------------|
| qa | 734,26 | m3/h |
| qa> | 3600,00 | m3/h |

qa max

2. example

Press the **C FACTOR** key

| | | |
|------------|--------------|--|
| VCF | 55,41 | |
| K | 0,988 | |

Press ↓ three times

| | | |
|--------------|--------------|--|
| VCF | 55,41 | |
| K-mod | GERG | |

Press ↓ twice

| | | |
|------------|--------------|----------|
| VCF | 55,41 | |
| CO2 | xx,xx | % |

Press ↓

| | | |
|------------|--------------|----------|
| VCF | 55,41 | |
| H2 | xx,xx | % |

Press ↓

| | | |
|-------------|--------------|--------------|
| VCF | 55,41 | |
| Rhon | x,xxx | kg/m3 |

Press ↓

| | | |
|------------|--------------|---------------|
| VCF | 55,41 | |
| Hon | xx,xx | kWh/m3 |

Programming a new constant

You want to change the p-max value to 41,50 bar.

Press the **PRESSURE** key

| | | |
|---|-------|-------|
| P | 34,26 | bar a |
| I | 13,50 | mA |

Press ↓ twice

| | | |
|----|-------|-------|
| p | 34,26 | bar a |
| p> | 50,00 | bar a |

p max range

Set the **SWITCH** to "Input"

Press the **ENTER** key.

The bottom line of the display turns darker and the POWER / STANDBY LED flashes at one-second intervals to indicate the programming mode.

Press the "4" key

| | | |
|----|-------|-------|
| p | 34,26 | bar a |
| p> | 4.... | |

Press the "1", "±", "5" and "0" keys consecutively.

| | | |
|----|-------|-------|
| p | 34,26 | bar a |
| p> | 41,50 | |

Press the **ENTER** key

| | | |
|----|-------|-------|
| p | 34,26 | bar a |
| p> | 41,50 | bar a |

The display turns bright and the unit indicated again.

Lock the data inputted by means of the **SWITCH**.

Programming is completed!

General information about inputting new values:

If a value is locked with the code number (user data), you must first input the correct code number into the appropriate field (X4) in the **MODE** function (see example on Page 33). You can input values either in the **short designation** or **coordinate** display mode. Switching over is possible at any time by pressing the **SELECT** key.

Programming current / dispatcher outputs

Current outputs

You can select the desired values in the columns M11, N11, O11, P11 via the **OUTPUT** function key and the cursor keys. To input coordinates, you must input the appropriate digits (A = 01, B = 02, etc.) instead of the letters of the columns concerned (A, B, etc.). **However, you can only connect the fields 1 and 2 of the columns A to L to one current output!**

Example: You want to output the standard volume flow rate (field 1, column J) to current output 1. (Column J corresponds to the number 10; see Page 11 Flow Rate 1 column)

- 1) Press the **OUTPUT** key.
- 2) Press ↓ four times ("I10 J-1" is indicated on the bottom line of the display).
- 3) Press the **ENTER** key. (The display switches over to "I10 10-1").
- 4) Input the key sequence "1" "0" "1" (for field J1). (The first two digits stand for the column and the third digit stands for the field.)
- 5) Press the **ENTER** key.

Dispatcher outputs

Programming dispatcher outputs is analogous to the procedure for programming current outputs.

Programming a new mode

Press the **PRESSURE** key

| | | |
|---|-------|------|
| p | 34.26 | bara |
| l | 13.50 | mA |

Press ↓ nine times.

| | | |
|--------|-------|------|
| p | 34.26 | bara |
| p-mod1 | 0-20 | mA |

Set the **SWITCH** to "Input".

The POWER / STANDBY LED flashes at one-second intervals to indicate the programming mode, and after you have pressed the **ENTER** key, the bottom line of the display turns darker.

Press the **MODE** key.

| | | |
|--------|-------|------|
| p | 34.26 | bara |
| p-mod1 | 4-20 | mA |

The setting changes from 0-20 mA to 4-20 mA.

Press the **ENTER** key and lock the data inputted by setting the of the **SWITCH** to „Input“.

The input field that you must change via the **MODE** key is separately referred to under **Summary of Device Functions to Be Called up with Function Keys** (Chaper 8).

Setting main totalizers

You want to set the main totalizer V_a to 100000.

First input the code number and then set the **SWITCH** to "Input".

Press the **TOTALIZER** key.

| | | |
|----|---------------|----|
| Vn | 000004321.985 | m3 |
| Va | 00000346.987 | m3 |

Press ↓ five times

| | | |
|--------|---------------|----|
| Vn | 000004321.985 | m3 |
| Va-set | 0 | m3 |

Press the **ENTER** key. The bottom line of the display turns darker and the POWER / STANDBY LED flashes at one-second intervals to indicate the programming mode.

Press the keys "1" "0" "0" "0" "0" "0" consecutively.

Press the **ENTER** key and lock the data inputted bei setting the **SWITCH** to „Input“.

| | | |
|--------|---------------|----|
| Vn | 000004321.985 | m3 |
| Va-set | 100000 | m3 |

Setting and resetting disturbing quantity totalizers is performed in the same way.

NOTE:

If you set the mode in the column J19 (Fault correction G7) to "yes", the sequence of the totalizers changes, since additional totalizers are inserted for the corrected volume at actual conditions (see also Chapter 8.3).

Enabling programming

Code number to enable user access

First press the **MODE** key and then the → key. The time is indicated.

Time: **Mode**
12-48-10

Press ↓ twice.

Press the **ENTER** key and input the appropriate digits.

Code **Mode**
**** - ****

Code **Mode**
*

The digits inputted remain invisible. Each digit is marked with an asterisk.

Press the **ENTER** key to complete the data input.

Code **Mode**
**** - ****

If the code number is correct, the POWER / STANDBY LED on the front panel starts to flash at one- second intervals. If the code number is incorrect, the display returns to

Code **Mode**
**** - ****

Repeat the operation using the correct code number!

The computer enables you to access user data. To change data, you must select the desired coordinate on the bottom line of the display and press the **ENTER** key. The brightness of the bottom line is reduced to indicate that access to the coordinate field is enabled. If you want to lock the computer again after having completed your programming, press the **CLEAR / FAULT** key twice quickly. If you forget to do so, the computer itself disables access after approx. 30 minutes. It is possible to change the code number if the sealable slide switch is in its "Input" position.

Sealable switch for the Office of Weights and Measures

When the switch is operated, the POWER / STANDBY LED starts to flash at one-second intervals and access to the memories (incl. code number) is enabled. To change data, you must select the desired coordinate on the bottom line of the display and press the **ENTER** key. The brightness of the bottom line is reduced to indicate that access to the coordinate field is enabled.

Annex E Technical Data

Inputs

| | |
|-------------------|--|
| Analog inputs: | 14½-bit resolution corresponding 20000 steps accuracy ± 1 bit, measuring period approx. 100 ms. |
| Volume frequency: | 16-bit resolution, reciprocal measuring method range from 0.05 Hz to 20 kHz or metering from 0 Hz. |
| Frequency inputs: | 23-bit resolution, reciprocal measuring method range from 0.05 Hz to 25 kHz. |
| Digital inputs: | Status signals, passive contact mechanism (relay or open collector), load 5 V, 20 mA. |

Outputs

| | |
|------------------|---|
| Analog outputs: | 14-bit resolution, accuracy ± 1 bit, load 800 ohms, electrically isolated as plug-in module for each output. The CPU can optionally be fitted with 1 to 4 analog outputs. |
| Digital outputs: | Limiting value 24V 100mA |

Dispatcher

Pulse width adjustable from 50 ms (10 Hz) to 300 ms (1.5 Hz).
Output frequency from 0 to 10 Hz, electrically isolated open
collector.

Index pulses

Pulse width of approx. 150 ms (3 Hz), not adjustable.
Electrically isolated open collector.

Limiting contacts

Electrically isolated open collector.

Fault / Warning

Contact assemblies (principle of closed-circuit current).

Power supply

| | |
|--------------------------------|--|
| | Switched-mode power supply unit with 40 kHz clock frequency. All secondary voltages are electrically isolated from each other. Charging unit for standby battery. |
| Standard power supply unit: | 24 V DC (21 V to 27 V), power input approx. 31 W |
| Special version: | 230 V AC (-10% to +6%), power input approx. 31 W |
| Internal battery (option): | The standby battery sustains the power supply of the ERZ 9004 M including transmitters for approx. 30 minutes. After a discharge, the battery attains its full power after approx. 10 hours. |

Ambient temperature

| | |
|--------------------|----------------|
| Temperature range: | -20°C to +60°C |
|--------------------|----------------|

Weight & dimensions

| | |
|---------------------|---|
| Rack-mounting unit: | Height 3 units, width 213 mm, depth 295 mm (without connectors) weight excl. battery approx. 3.2 kg, weight incl. battery approx. 4 kg |
| Wall-mounting unit: | Height 245 mm, width 340 mm, depth 260 mm weight excl. battery approx. 3.7 kg, weight incl. battery approx. 4.5 kg |

Interfaces

Without handshake lines, communication is made via Xon / Xoff. Short-circuit-proof.

Rack-mounting unit

Front panel:

Front interface

RS 232 C as service interface
9-pin Cannon connector
transmission rates from 1200 to 9600 baud
1 start bit, 1 stop bit, 8-bit data, no parity

Rear panel:

C1 interface

RS 232 C as service or printer interface
9-pin Cannon connector
transmission rates from 2400 to 19200 baud
1 start bit, 1 stop bit, 8-bit data, no parity

C2 interface (option)

RS 485 as standard data communication (DSfG) interface
9-pin Cannon connector
transmission rates from 2400 to 19200 baud
1 start bit, 8-bit data
parity bit setting: off / even / odd
stop bit setting: 1 / 2

Wall-mounting unit

Front panel:

Front interface

RS 232 C as service interface
9-pin Cannon connector
transmission rates from 1200 to 9600 baud
1 start bit, 1 stop bit, 8-bit data, no parity

Rear panel:

Interface in the terminal compartment

Max. one interface. Screw terminals in the terminal compartment.
There are the same interfaces available as with the rack-mounting unit.

CPU

CPU:

80C537 / 12 MHz

Memory areas:


- a) Official calibration data: non-volatile memory
C-MOS RAM, 2 kilobytes
- b) User data: non-volatile memory
C-MOS RAM, 2 kilobytes
- c) Totalizer memory: non-volatile memory
C-MOS RAM, 512 bytes
- d) Program memory: EPROM 64 / 128 kilobytes

Display field and keypad

2-line luminescent display in blue with 20 characters per line.
Digit height 5 mm, 7x5 dot matrix.
Luminosity 856 cd / m²
Temperature range -10°C to +60°C

Front panel film with short-stroke keys

Pulse counting / pulse frequency measurement block diagram



Description of pulse counting

2-channel pulse counting arrangement with separate measuring and reference channels

1:1 operating mode

There is the same number of pulses per time unit (or per rotation of the turbine wheel) on both channels. The input pulses must be out of phase (90° to 270°). The difference formation feature alternately compares the measuring and reference pulses. Every deviation is counted by the missing-pulse counter. If the preset limiting value (e. g. 10 pulses) is exceeded, an alarm is tripped. If the limiting value is not exceeded within a presettable period (e. g. 10000 pulses), the missing-pulse counter is set to zero.

X:Y operating mode


The number of pulses per time unit (or per rotation of the turbine wheel) is not the same on both channels. The input pulses may have any phase angles. Differences are formed only via the software. The deviation results from the ratio of the measuring wheel and reference wheel parameters inputted. In the event of a deviation > 4%, an alarm is tripped.

Description of pulse frequency measurement

To calculate the flow rate, the frequency of volume pulses is determined by means of a period measurement. A selector switch samples the measuring and reference channels in such a way that a frequency and thus a volume flow rate can be determined from both pulse frequencies (irrespective of the mode 1:1 or X:Y). Clock frequency changing (250 kHz / 1 MHz) allows to change the measuring resolution or the measuring period in connection with the chosen volume transmitter (vortex meter = long gate time).

Measurable frequency, min.: 0.05 Hz
Measurable frequency, max.: 20 kHz

Frequency measurement block diagram




Description of frequency measurement

To carry out density or sound velocity calculations, it is necessary to measure the frequency of the transmitters connected. A selector switch samples the inputs connected. The measuring pulse counter has a resolution of 16 bits, whereas the reference pulse counter has a resolution of 32 bits.

Measurable frequency, min.: 0.05 Hz
Measurable frequency, max.: 20 kHz

Block diagram of analog inputs



Analog inputs

Dual-slope analog-digital converter with $14\frac{1}{2}$ -bit resolution corresponding to 20000 steps. A multiplexer which can sample a maximum of 6 analog inputs is located upstream of the A/D converter. Four inputs are designed for current measurement and two inputs for resistance measurement using four-wire technology with open-circuit monitoring.

Analog outputs

Digital-analog converters with 14-bit resolution. There is one electrically isolated converter for each current output.

Storing quantity pulses / electronic indexes

The counted and evaluated pulses are stored threefold in a non-volatile memory (C-MOS RAM). A cyclic 1-out-of-3 comparison checks the contents of the memory locations for equality. In the event of one value deviating from the other two values, an alarm is tripped and the wrong value is overwritten with the contents of the coinciding memory locations. This applies to all V_a and V_n indexes.

Digital outputs

| | |
|--------------------|--|
| Index pulses: | Transistor output open collector with protective network limiting values: 24 V 100 mA |
| Limiting contacts: | Transistor output open collector with protective network limiting values: 24 V 100 mA |
| Dispatcher: | Transistor output open collector with protective network limiting values: 24 V 100 mA |
| Fault / Warning: | Contact assemblies with protective network limiting values: 24 V 100 mA |

Interfaces

There are two RS 232 C interfaces. One is located on the front panel and the other on the rear panel. Both interfaces are without handshake lines; communication is made via Xon / Xoff. The rack-mounting unit is fitted with two 9-pin subminiature Cannon connectors, whereas the wall-mounting unit has one 9-pin connector on the front panel and one screw terminal in the terminal compartment. Including back-up fuse, varistor and transient absorber (TAZ diode).

Power supply unit

| | | |
|------------------|----------|--------------|
| Standard version | 24 V DC | 21 V to 27 V |
| Special version | 230 V AC | -10% + 6% |
| Power input | approx. | 26 W |

Switched-mode power supply unit with 40 kHz clock frequency. All secondary voltages are electrically isolated from each other.

Charging unit for standby battery.

a) Rack-mounting unit

| | | | |
|-----------------------|-----------------|---------------|---------------------------------------|
| Size: | Height: 3 units | Width: 213 mm | Depth: 295 mm (without connectors) |
| Weight excl. battery: | approx. 3.2 kg | | |
| Weight incl. battery: | approx. 4.0 kg | | |


b) Wall-mounting unit

| | | | |
|-----------------------|----------------|---------------|---------------|
| Size: | Height: 225 mm | Width: 340 mm | Depth: 260 mm |
| Weight excl. battery: | approx. 3.7 kg | | |
| Weight incl. battery: | approx. 4.5 kg | | |

Original battery standby supply

The standby battery sustains the power supply of the entire device and the transmitters for approx. 30 minutes if it is fully charged. Recharging the battery after a discharge takes approx. 2 hours.

Block diagram of battery standby supply



Activation of the standby battery


To activate the standby battery, set the following jumper:

- Rack-mounting unit: Connector J4, jumper between 9 and 10.
- Wall-mounting unit: Jumper between A2 and A6

Afterwards, the device must be supplied with 24 V or 230 V one time. Only then will the standby battery sustain the power supply of the device in the event of a power failure.

Annex F Pin Assignment Diagrams


Inputs of the rack-mounting unit



1) Set jumper externally




Outputs of the rack-mounting unit



1) When using an internal battery, set a jumper between the contacts 9 and 10. When using an external battery, set the soldering jumper P14 in the ERZ 9004 / ERZ 9004 M.
2) In the event of fault-free operation, the fault / warning relays are picked up (contacts J3/(9-10) and J2/(9-10) are closed). If a fault occurs and in the event of a power failure, the relays release (contacts J3/(10-11) and J2/(10-11) are closed).

Inputs of the wall-mounting unit




NAMUR signal

Frequency and status signals


-30 to +60°C

0 / 4-20mA



1) Set jumper externally

Outputs of the wall-mounting unit
















RS 232C No.: **C1**

0 / 4-20mA $R_L = 1 \text{ k}\Omega$

$I_{max} 100\text{mA}$

$U_i \text{ max } 24\text{V}$

Power supply



1) When using an internal battery, set a jumper between the contacts A2 and A6. When using an external battery, set the soldering jumper P14 in the ERZ 9000 (see "Technical data").

2) In the event of fault-free operation, the fault / warning relays are picked up (contacts B2-C2 and A4-C3 are closed). If a fault occurs or if the device is disconnected from the power supply, the relays release (contacts C2-A3 and C3-B3 are closed).

Annex G Fault List

FAULT MESSAGES

| No. | Text displayed | Explanation |
|---------------------------|------------------|--|
| General | | |
| 02 | Power failure | Power failure |
| 03 | Defective clock | Clock component in the ERZ 9004 M is defective |
| 04 | EEPROM fault | Fault detected when checking the EEPROM |
| 05 | A/D hardw. 517 | Hardware fault A/D measurement 517 |
| 06 | A/D hardw. 7135 | Hardware fault A/D measurement 7135 |
| 07 | Watchdog | Program runtime exceeded |
| 08 | AGA iter. 1 | AGA-NX 19 iteration 1 |
| 09 | AGA iter. 2 | AGA-NX 19 iteration 2 |
| 10 | AGA limit. | AGA-NX 19 limiting values |
| 11 | 8279 fault | 8279 fault |
| 12-15 | | Spare |
| Volume measurement | | |
| 16 | Pulse comp. 1:1 | Pulse comparison 1:1 |
| 17 | Pulse comp. x:y | Pulse comparison x:y |
| 18 | Miss.pulse meas. | Missing pulses of the measuring channel |
| 19 | Miss.pulse ref. | Missing pulses of the reference channel |
| 20 | qVa min range | Min. range of volume flow rate at actual conditions violated |
| 21 | qVa max range | Max. range of volume flow rate at actual conditions exceeded |
| 22 | Delta qVa | Delta fault of volume flow rate at actual conditions |
| 23 | Delta Kvc max | Kvc delta fault |
| 24 & 25 | | Spare |
| Analog inputs | | |
| 26 | p hardware | Pressure hardware |
| 27 | p min range | Min. pressure range violated |
| 28 | p max range | Max. pressure range exceeded |
| 29 | p delta | Pressure delta fault |
| 30 – 41 | | Spare |
| 42 | T hardware | Temperature hardware |
| 43 | T min range | Min. temperature range violated |
| 44 | T max range | Max. temperature range exceeded |
| 45 | T delta | Temperature delta fault |
| 46 – 49 | | Spare |
| Totalizers | | |
| 50 | 1 out of 3 Va | 1-out-of-3 comparison volume at actual conditions |
| 51 | 1 out of 3 Vn | 1-out-of-3 comparison standard volume |
| 52 | 1 out of 3 Vac | 1-out-of-3 comparison corrected volume at actual conditions |
| 53 | | Spare |
| 54 | 1 out of 3 VaD | 1-out-of-3 comparison disturbance of volume at actual conditions |
| 55 | 1 out of 3 VnD | 1-out-of-3 comparison disturbance of standard volume |
| 56 | 1 out of 3 VacD | 1-out-of-3 comparison disturbance of corrected volume at actual conditions |
| 57 - 69 | | Spare |

WARNINGS

| No. | Text displayed | Explanation |
|---------------------------------|-----------------|--|
| Totalizers and flow rate | | |
| 70 | Dispatcher 1 | Dispatcher output 1 |
| 71 | Dispatcher 2 | Dispatcher output 2 |
| 72 | el.mech. TOT. 1 | Output contacts of totalizer V_a |
| 73 | el.mech. TOT. 2 | Output contacts of totalizer V_n |
| 74 | qVa min limit | Min. limit of volume flow rate at actual conditions violated |
| 75 | qVa max limit | Max. limit of volume flow rate at actual conditions exceeded |
| 76 | qVn min limit | Min. limit of standard volume flow rate violated |
| 77 | qVn max limit | Max. limit of standard volume flow rate exceeded |
| 78 & 79 | | Spare |
| Current outputs | | |
| 80 | I1 out min | Current output 1 min. violated |
| 81 | I2 out min | Current output 2 min. violated |
| 82 | I3 out min | Current output 3 min. violated |
| 83 | I4 out min | Current output 4 min. violated |
| 84 | I1 out max | Current output 1 max. exceeded |
| 85 | I2 out max | Current output 2 max. exceeded |
| 86 | I3 out max | Current output 3 max. exceeded |
| 87 | I4 out max | Current output 4 max. exceeded |
| Limiting contacts | | |
| 88 | p min limit | Min. limit of pressure violated |
| 89 | p max limit | Max. limit of pressure exceeded |
| 90 - 95 | | Spare |
| 96 | T min limit | Min. limit of temperature violated |
| 97 | T max limit | Max. limit of temperature exceeded |
| 98 & 99 | | Spare |