

Volume Corrector EC 24



OPERATING INSTRUCTIONS

Reliable Measurement of Gas



CONTENTS

Manufacturer Our customer service is available for technical queries

Address	RMG Messtechnik GmbH Otto-Hahn-Straße 5 D-35510 Butzbach
Telefon switchboard	+49 6033 897 – 0
Telefon service	+49 6033 897 – 127
Telefon spare parts	+49 6033 897 – 173
Fax	+49 6033 897 – 130
E-mail	service@rmg.com

Original Document The **EC24_manual_en_07** from September 19th, 2019 for the volume corrector EC 24 is the document translated first from the German original version. Anyhow, this document may serve as reference for translations into other languages. Please use in case of any uncertainties the German version as main reference.

Note Unfortunately, paper is not updated automatically, whereas technical development continuously advances. Therefore, we reserve the right to make technical changes in regard to the representations and specifications of these operating instructions. The latest version of this manual (and other devices) can be downloaded at your convenience from our Internet home-page www.rmg.com.

Date created	July	2009
1st revision date	January	2012
2nd revision date	March	2012
3rd revision date	May	2013
4th revision date	February	2015
5th revision date	February	2017
6th revision date	September 19th,	2019

Document version and language

Document version	EC24_manual_en_07 September 19th, 2019
Language	EN

INTRODUCTION.....	1
General information.....	1
Design variants.....	1
The coordinate system	2
The display field.....	2
The system	2
Program memory.....	2
Reset.....	2
Bootng.....	3
OPERATING MODES.....	4
SAFETY INSTRUCTIONS.....	5
Operating instructions for the installer	6
INSTALLATION	8
Electrical connections	8
Installing the remote totalizer	12
OPERATION	14
Front panel and keyboard of the EC 24	14
Display	15
Programming	16
Parameters and modes of the EC 24.....	19
Coordinate system.....	21
Coordinates from A – E	21
Coordinates from F – Z.....	22
Description of individual columns.....	23
Column structure	23
Totalizers	24
Flow rate.....	24
Pressure	24
Temperature	25
Analysis	25
Outputs.....	25
Error / ID	26
Mode / Memory.....	26
Operating modes.....	27
Error messages	29

CONTENTS

Changing the batteries (EC 24).....	30
ANNEXES.....	31
A Equations used with the EC 24 volume corrector.....	31
B Block diagram for the EC 24.....	33
C Specifications	34
D Examples of connection (EC 24)	40
E Instructions for the measuring element of the turbine meter	42
F Modbus.....	46
G Dimensions.....	52
H Sealing plan.....	53
I Certificates	54


Introduction

General information

Design variants

The EC 24 volume corrector (correction is performed using measured pressure and temperature values) can be used as a unit together with electronic turbine meters from RMG or separately with any mechanical turbine or rotary displacement meters.

The following device types are available:

Device type	TERZ 94	EC 24
Measuring element (meter)	electronic	electronic
Function	Vm totalizer	Vm totalizer and volume correction (p,T)
Case		
Inputs	Wiegand (1 or 2 channels)	Wiegand (1 or 2 channels)
Pulse comparison	No	Optional
Pulse outputs	LF, HF	LF, HF

There are various hardware configurations for the device types listed:

- without current output: Mother board
- with current output (4 to 20 mA): S board

If the corrector is used together with an electronic RMG turbine meter, please observe the instructions for the measuring element in the annex to this manual!

The operating concept

The operating concept has been chosen in such a way that the operator can easily use the device without wasting too much time reading a manual.

The coordinate system

A coordinate system makes it easy for the operator to access all configuration data as well as measured and calculated values by means of a table. The coordinate system is based on 8 columns. Every value in this coordinate system can be reached by pressing the appropriate cursor keys (arrows “►“ “▼“).

The display field

An alphanumeric single-line display with 12 characters enables data and measured values to be indicated together with their abbreviated designations and units. The LCD has been designed in such a manner that it is particularly suitable for battery-powered mode. At temperatures below -25°C or exceeding +60°C, the display may be impaired.

The system

A complete Flow Computer System has been developed on the surface of a few square centimetres using the most advanced SMD technology with large-scale integrated components. Several device functions, such as pulse counting, frequency measurement, keyboard controller and dispatcher output, have been incorporated into a controller. Thanks to large-scale integrated components, fewer chips are required and this also contributes to making the device reliable. The type of the individual device essentially depends on the software used.

Program memory

The program memory of the base device is located in a flash memory on the main board, whereas the data memory is located on an additional board.

Reset

In the case of a reset, the power supply is disrupted and the corrector is switched off during this period of time. In this way, the program and the operating parameters will not be lost and also the meter readings will be retained. A reset is made on the EC 24 by switching off not only the battery but also a possibly available external power supply.

Booting

In case of serious disturbances it may be necessary to reboot the device.

With the booting all parameter settings and totalizer readings are lost! Therefore read out all parameters of the EC 24 before booting.

To reboot the device proceed as follows:

- For mains supplied devices switch off the power supply.
- For battery powered devices disconnect the battery (see section "Changing the battery"). Also a possibly existing backup battery for mains supplied devices must be disconnected.
- Press the "P" key and keep it pressed.
- Connect the battery again and/or switch on the power supply again.
- Now the text "del all" appears in the display. Press the ☐-key (Enter).
- As soon as the addresses are counted up in the display, you can release the "P" key.
- The booting procedure has finished, if the totalizer is displayed (now set to 0).

Now transfer all device parameters back to the EC 24 or enter the values from the calibration certificate.

Operating Modes

Battery-powered device

The EC 24 is fitted with two exchangeable batteries. Both devices have been designed for a continuous operation over approx. six years. This, however, is conditional on the device being either read or “woken up” by pressing the external button once a week.

Battery-powered device with an external power supply

If an interface submodule is used for transmitting data, such as the externally supplied RS 485, the service life of the battery is more than 10 years.

Externally supplied device with built-in standard battery

In the case of an external power supply (current transmitter which serves as a power supply and 4 to 20 mA current output at the same time), the EC 24 is completely supplied via a current loop. For this purpose, a power supply unit is required which is to be connected to this output.

In the case of the EC 24 volume corrector, pulse processing is even ensured in the event of a power failure of the current loop.

Display of battery change

Lithium batteries retain their voltage until they are almost completely discharged so that the voltage cannot be monitored with an appropriate display until the next battery change is necessary.

Safety Instructions

The EC 24 comply with currently applicable standards and regulations. However, failure to operate them properly may cause hazards. Persons who install or operate a volume corrector in areas subject to explosion hazards, must be familiar with the currently applicable explosion protection standards and regulations. Do not change anything of the volume corrector on your own, otherwise the approval will become invalid.

Operate the volume corrector only in the specified temperature range from -25°C to +60°C.

The electronic corrector system of the explosion-protected design has been approved for use in areas subject to explosion hazards and its code is:

II 2 G Ex ib[ib] IIC T3/T4 Gb

You can find the EC type approval certificate in the annex and its reference number is:

TÜV 02 ATEX 1970

Please observe the following signs:

Danger of explosion



In the manual, this symbol warns you of an explosion hazard. Please observe the instructions given next to this symbol. As to the danger of explosion, please note the following in particular:

- Only the explosion-protected design of the EC 24 may be used in areas subject to explosion hazards. Connect the pulse outputs of these devices only to intrinsically safe circuits.
- The battery must be changed in an area without explosion hazards.
- The specifications on cable type and cable length in this manual and in the ex-approval must be observed.
- Modifications to the device make the Ex approval invalid and are therefore prohibited.

Damage to property



In the manual, this symbol warns you of possible damage to property. The instructions given next to this symbol inform you about what you can do to avoid damage to the EC 24 volume corrector.

It is essential to observe the warning information in these operating instructions and the generally applicable safety rules. No warranty claims can be asserted if there is unauthorized interference with the device!

Operating instructions for the installer

Identification:



Type: EC 24*
II 2 G Ex ib[ib] IIC T3/T4 Gb
TÜV 02 ATEX 1970
Temp.= -25°C....+40°C and/or +60°C
Data see EC type approval certificate
Year of construction: 2004
Serial number: xxxx xx
0032



Manufacturer: RMG Messtechnik GmbH
Otto – Hahn – Straße 5
D-35510 Butzbach

Application:

The device EC 24 is equipment for hazardous area.

Assembly/disassembly:

When assembling it is to be made sure that the degree of protection of the case is kept.

A direct exposure to sun must be avoided.

In case of disassembly the signal circuits are to be switched to zero potential and the corresponding cables are to be removed.

Installation:

If one or more circuits are used, it is to be made sure with the cable selection that the permissible limiting values according to the EC type approval certificate are not exceeded.

Each Ex signal circuit is to be run in its own cable, which has to be lead through the appropriate PG cable gland.

A fixed laying of the intrinsically safe cables is obligatory.

The connecting cables are to be provided with core-end sleeves.

Start-up:

With the start-up of this device it is to be made sure that all cables in the clamp area are correctly connected and run.

The case must be completely closed.

With the installation and start-up the standard EN60079-14 is to be observed.

The device may be started up only by persons after training.

Settings:

The basic setting of the device takes place by RMG Messtechnik.

Changes of the basic setting may only be carried out by persons after training and/or instruction.

Maintenance:

The battery changes may only take place in a safe area.

Repairs at this device may be carried out by RMG Messtechnik only.

Safety instructions:

The manual must be accessible to all persons, who are authorized with the operation of the device.

No arbitrary changes may be made at the device, since otherwise the [ATEX] approval becomes invalid.


The device may be never opened by force.

The warning references in this manual and the generally accepted safety rules must be observed.

Installation

Electrical connections

To reach the electrical connections, you must first remove the cover of the corrector.



You must select the sensor inputs before you connect the cables. To do this, install the jumpers XS1 / XS2 and XTERZ90 on the board as indicated (see inputs and outputs in the annex).


Make your settings for input X5 by the X_S1 (for sensor 1), X_S2 (for sensor 2) and X_TERZ90 (additional for remote totalizer) jumpers as follows:

Reed contact	Wiegand	Remote totalizer	
X_S1, X_S2	X_S1, X_S2	X_S1, X_S2	X_TERZ90
Jumpers 1-3 and 2-4	Jumpers 3-5 and 4-6	Jumper 3-4	Jumpers 1-2 and 3-4

Controlling the start-stop totalizer or resetting the resettable totalizer (depending on the programming of the electronic totalizing unit) is performed through input X5 terminals 1 and 2. As soon as input X5 terminals 1 / 2 has been short-circuited through an external contact, interruption or resetting is performed.

⇒ For this purpose, set jumpers at the positions identified with X_S2 to the “reed contact” function.


For devices with current output: Before commissioning, the device must be activated. The jumper must be plugged as shown in the drawing.




In the case of the EC 24, terminal X22 (on TERZ94trm current module which is plugged in the main card) is used as current-loop connection to supply the device and as output current (4-20 mA).

To connect cables to the spring terminals, you need a screwdriver with a blade width of a maximum of 2.5 mm. Introduce the blade into the intended slot and press down the screwdriver to open the spring terminal.

Standard connection pulse outputs: 7-pin connector (Binder series 692)



Standard connection interface: 6-pin connector (Binder series 423)



INSTALLATION



In areas subject to explosion hazards, the EC 24 must only be connected to certified intrinsically safe circuits.

Make sure that the limit values specified in the certificate of conformity (see annex) for the devices to be connected are not exceeded.



The maximum voltage which may be connected to the RS 485 interface is 10.5 V. A higher voltage causes damage of the device.

If one or more than one circuit is used, make sure that the permissible limit values in accordance with the EC type approval certificate are not exceeded. Each intrinsically safe signal circuit must be installed in a separate cable which is to be taken through an appropriate high-strength cable gland. It is absolutely imperative that the intrinsically safe cables are permanently installed. Make sure that the connecting cables are provided with core-end sleeves.


Earthing

To prevent measuring errors caused by electromagnetic interference, you **must not fail** to earth the case of the meter head via the earthing screw on the left side of the case.

Minimum cable cross section:

Up to a length of 10 m: 6 mm²

From a length of 10 m: 10 mm²



Cables

Use 2-core or multicore shielded cables which are twisted together in pairs (type LIYCY) for the signal lines (LF output, HF output, current-loop connection, control input). Use 4-core shielded cables which are twisted together in pairs (type LIYCY) for the data lines (RS 485). The shielding must always be connected to earth on both sides. In the case of the EC 24, you must proceed as described under "Cable glands".


We recommend that cable cross sections of 0.5 mm² are used. Due to the cable gland, the outside diameter must be between 4.5 mm and 6.5 mm.

If the device is used in areas subject to explosion hazards, the maximum cable length is limited by the limit values for intrinsically safe circuits and depends on the inductance and capacitance of the cable!

Cable glands

Clamp the shielding on both sides, as shown in the picture below, into the cable glands located on the outside of the case:

- Unscrew the cap nut.
- Pull out the plastic clamping piece.
- Push the cable end through the cap nut and the clamping piece and bend the shielding backwards.
- Put the clamping piece back into the connecting piece.
- Screw on the cap nut again.




Permissible temperature ranges

For the standard design, the following fluid temperature and ambient temperature ranges are permitted:

Fluid temperature range: -20°C to +60°C
 Ambient temperature range: -25°C to +60°C or 40°C

Installing the remote totalizer



If your model is designed for remote totalizing, you can install the totalizer at a distance of up to 3 m from the meter case. Usually, the cable has already been connected to the sensor and the totalizing unit when the device is delivered. Should this not be the case, you will have to connect the connecting cable to input X5, terminals S1+ and S1- of the board. If you have a 2-channel meter connect the second sensor to the clamps S2+ and S2-. Use only shielded cables of the type:

LIYCY - 2 x 0.75 blue (1-channel Ex)
LIYCY - 2 x 2 x 0.75 blue (2-channel Ex or 1-channel Non-Ex)
LIYCY - 3 x 2 x 0.75 blue (2-channel Non-Ex)

Maximum cable length: 3 m (installation with longer cable only on request)



In hazardous areas the temperature transmitter must not be connected via the socket on the meter case. In this case it is prescribed to lay a separate cable for the temperature transmitter!


13




In addition, check the plug-in jumpers XS1 / XS2 and XTERZ90 on the board (see inputs and outputs in the annex).

Make your settings of XS1 and XS2 as follows: jumpers 3-4.

Operation

Front panel and keyboard of the EC 24











Keyboard	Designation	Effect
	Arrow Down	<ul style="list-style-type: none"> Moves downwards within a list: Moves from the first value of the list towards the last value.
	Arrow Right	<ul style="list-style-type: none"> Moves to the right towards another list: Moves from the first list towards the last list.
	Function	<ul style="list-style-type: none"> Press both buttons at the same time to initiate the following functions: Hold down >2 sec.: Segment test Hold down < 2 sec.: The coordinate will be displayed.





If the EC 24 is operated together with the measuring element of an electronic turbine meter, the EC 24 contains the totalizing unit of the meter and the data plate of the meter is located on the left side of the front panel.

Display

In normal operating mode, the main totalizer is displayed. If you press the external control buttons, you can select the other display values. After an adjustable time has elapsed, the EC 24 will return to displaying the main totalizer. If the display of the EC 24 does not show anything, the device is in energy-saving mode. In this mode, the display is completely switched off. However, incoming pulses are processed, and the outputs are set. If you press one of the two control buttons, the display value will appear again.

Display switched off:		
→		
Pointer position 1	0 0 0 0 5 8 3 1 m3	Main totalizer V
→		
Pointer position 2	1 0. 0 0 0 m3/h	Flow rate V·
→		
Pointer position 3	1. 0 0 0 0 0 0 0 bara	Pressure P
→		
Pointer position 4	20. 0 0 0 0 0 0 °C	Temperature T
→		
Pointer position 5	1 --	Conversion factor C (analysis)
→		
Pointer position 6	16. 0 0 0 0 0 0 mA	Current I _o
→		
Pointer position 7	1 --	Error / ID
→		
Pointer position 8	1 --	Mode / Memory


The external and internal buttons correspond to each other in the following way:

Int. button	Ext. button	Meaning
P	P	Display mode: Switch over to programming mode. (Press the button longer than 2 seconds.) Programming mode: Put the decimal point at the current position.
+		In display mode: Move to the right within the matrix (change of column). In programming mode: - Increase the decimal by 1. - Scroll in the list. (Display value is identified by "L".)
-		In display mode: Move towards the bottom (change of line). In programming mode: - Decrease the decimal by 1. - Scroll in the list. (Display value is identified by "L".)
		In display mode: Short-term view of the coordinate (e.g. A01) In programming mode: Go to the right by one decimal place (if the last decimal has been reached: Quit programming mode).

Principle of programming

For programming, you must always proceed as follows:

- First change over to the display value to be modified.
 - To do this, press either the control button (only forwards)
 - or the internal buttons “+” and “-” or the external buttons “^” and “v” (forwards and backwards).
- Change to programming mode by pressing “P” for at least 2 seconds. On the left side of the display, a flashing character or cursor will appear:



- You can modify the flashing decimal by pressing either “+” or “^” (+1) or “-” or “v” (-1).
Example: If you press the “^” button three times, the first decimal will be increased from 0 to 3. If an “L” appears on the far left side of the display, this value is a list. With a list, you can only scroll in the specified values.
- After you have completed your programming of the first decimal, press “□□” once and the next character will start to flash.
Now proceed with your programming until you have reached the last decimal place.
- Then press “□□” once again to have the set value accepted and quit programming mode.
- Press the “P” button to set the decimal point behind the flashing digit.
With totalizers, modes and integers, no decimal point is permitted.
- Press the control button if you have made an error or if you want to discontinue inputting data.

Display values

Measured values, such as the flow rate, frequency, etc. are display values and cannot be directly modified. However, there are many parameters which influence the formation of these measured values. These parameters are described in the following section.

Display values include the flow rate, version number, year of construction, serial number, value of the current output in mA, for example.

Parameters and modes of the EC 24

The following sections describe the meaning of the individual parameters.

Meter factor (pulse value)

With the meter factor (pulse value), the relevant flow rate at measurement conditions is calculated from the signal frequency of the sensor element in the electronic totalizing unit:

$$Q_B = \frac{f}{K_V} \cdot 3600 \left[\frac{m^3}{h} \right]$$

- f : Signal frequency [Hz]
 K_V : Meter factor (pulse value) [pulses/m³]
 Q_B : Flow rate at measurement conditions [m³/h]

The meter factor has been calibrated in the factory in such a way that working cubic metres are directly displayed.

Any modification of this adjustment is within the sphere of responsibility of the operating company.

NOTE!

The new value is immediately used for all calculations performed after each modification of the meter factor.

The uninfluenced signal frequency of the sensor element is available at the HF output. The frequency range can be determined from the meter factor K and the minimum and maximum flow rates at measurement conditions of the meter in accordance with the following formulae:

$$f_{\min} = \frac{Q_{B \min}}{3600} \cdot K_V \quad f_{\max} = \frac{Q_{B \max}}{3600} \cdot K_V$$

- $Q_{B \min}$: Minimum flow rate at measurement conditions
 $Q_{B \max}$: Maximum flow rate at measurement conditions
 K_V : Meter factor

Example:

$$Q_{B \min} = 16 \text{ m}^3/\text{h} \quad Q_{B \max} = 250 \text{ m}^3/\text{h} \quad K_V = 2362 \text{ Pulses}/\text{m}^3$$

$$f_{\min} = \frac{16}{3600} \frac{\text{m}^3}{\text{h}} \cdot 2362 \frac{\text{Pulses}}{\text{m}^3} = 10,5 \text{ Hz} \quad f_{\max} = \frac{250}{3600} \frac{\text{m}^3}{\text{h}} \cdot 2362 \frac{\text{Pulses}}{\text{m}^3} = 164 \text{ Hz}$$

OPERATION

Totalizer factor (decimal places)

You can set the totalizer factor in coordinate Z 01.

There are the following setting options:

Totalizer factor	Multiplier for value displayed	Decimal places
0.01		2
0.1		1
1		0
10	10	0
100	100	0

Example:

If the factor has been set to 0.1, the meter reading will be displayed with one decimal.

If the factor has been set to 10, the value displayed will be shown without decimals and you will obtain the actual meter reading by multiplying the value displayed by 10.

Output pulse value

The output pulse value indicates how many LF output pulses correspond to one cubic metre.

The output pulse value can be entered in coordinate A 05 from 0.01 to 100 as required.

Coordinate system

Coordinates from A – E

Pointer position	V	V·	P	T
Designation	Totalizers	Flow Rate	Pressure	Temperature
Coordinate / Line	A	B	C	D
1	Volume at base conditions	Qb	bara	°C
2	Volume at measurement conditions	Qm	p min	t min
3	Disturbing quantity totalizer Vb	Frequency	p max	t max
4	Disturbing quantity totalizer Vm	Qm min	pb specified value	tb specified value
5	Pulse scaling factor	Qm max	p default	t default
6	Meter factor	Qm max val.	p binary display	Factor adjustment value
7		Switch-off Qm	Binary value at 0.5 V	Offset adjustment value
8		Time limit for Q < Qm.min	Binary value at 4.5 V	AD binary value
9	Monthly data memory		U min	
10	Monthly data memory		pu min	
11	Monthly data memory		Rise	
12	Monthly data memory		Factor correction value	
13	Monthly data memory		Offset correction value	
14 ... 22	Monthly data memory			

Coordinates from F – Z

Pointer position	C	Io	Error / Type	Mode
Designation	Analysis	Outputs	Error / ID	Mode / Memory
Coordinate / Line	E	F	G	Z
1	Conversion factor	Current	Error text	TerzMode
2	K coefficient	Current min	Software version	EcMode
3	K specified value	Current max	Serial number	Puls_X
4	Hs	Current default	Checksum	Puls_Y
5	Rhon	Current rise	Ser. no. pressure transmitter	Time
6	CO2	Current offset	p min	Date
7	Zb	Current damping	p max	Modbus address
8	Z		Ser. no. temperature transmitter	ModbusRegOffset
9	Hs ref temp		T min	Error bit string
10	N2		T max	Wake-up pulse
11	rd		Ser. no. meter	Code number
12			Meter size	Beginning of gas day
13			Battery change	EcMode2
14				Charge no.
15				K factor formula
16				Change of code number

Description of individual columns

Column structure

Designation of columns A to O

Press the above function key and then the ► key once.

Pointer position		V			
Coding	Coordinate / Line	A	Description of the coordinate	Unit	Special feature
S	1	Nm3	Main totalizer, volume at base conditions	m3	
S	2	m3	Main totalizer, volume at measurement conditions	m3	
S	3	VbD	Disturbing quantity totalizer, volume at base conditions	m3	
S	4	VmD	Disturbing quantity totalizer, volume at measurement conditions	m3	

Abbreviated designation of the matrix field

Unit of the value displayed or programmed

Explanatory notes on a coordinate field

Field designation shown in the display of the EC 24

Designation of the

Coding of column line
 H = Head
 D = Display
 C = Access protected
 S = Access protected by the calibration switch

Note: In the software version 1.0 the user code is not yet implemented. To change parameters with "C" coding it is necessary to open the calibration switch!

The **calibration switch** is realized by a screw on the left (EC 24) side of the device (see fig. on page 10). For opening the calibration switch just unscrew the screw by some turns until the text "Input" is blinking in the display. Then all parameters coded with "S" or "C" can be changed.

Totalizers

Pointer position		V			
Coding	Coordinate / Line	A	Description of the coordinate	Unit	Special feature
S	1	Nm3	Main totalizer, volume at base conditions	m3	
S	2	m3	Main totalizer, volume at measurement conditions	m3	
S	3	VbD	Disturbing quantity totalizer, volume at base conditions	m3	
S	4	VmD	Disturbing quantity totalizer, volume at measurement conditions	m3	
S	5	l/m3	Pulse scaling factor	l/m3	
S	6	l/m3	Meter factor	l/m3	
D	9 ... 22		Monthly data memory 1 ... 14 (Date, Vb, Vm, dVb, dVm, P, T)		

Flow rate

Pointer position		V̇			
Coding	Coordinate / Line	B	Description of the coordinate	Unit	Special feature
D	1	N3H	Flow rate at base conditions	m3/h	
D	2	m3/h	Calculated flow rate at measurement conditions	m3/h	
D	3	F	Frequency (measurement)	Hz	
S	4	Qm<	Lower fault limit	m3/h	
S	5	Qm>	Upper fault limit	m3/h	
D	6	Qmx	Maximum value of the flow rate at measurement conditions	m3/h	
S	7	qug	Creeping limit	m3/h	
S	8	qmt	Time limit for operation below Qm<	s	

Pressure

Pointer position		P			
Coding	Coordinate / Line	C	Description of the coordinate	Unit	Special feature
D	1	bar	Measured value for pressure (absolute pressure)	bara	
S	2	p<	Lower fault limit	bara	
S	3	p>	Upper fault limit	bara	
S	4	pb	Specified value, pressure at base conditions	bara	
C	5	p-def	Default value, pressure	bara	
D	6	Dig	Pressure, binary display		
D	7	Dig	Binary value at 0.5 V		
D	8	Dig	Binary value at 4.5 V		
S	9	Umi	Constant, pressure transmitter base calibration	V	
S	10	pmi	Constant, pressure transmitter base calibration	bara	
S	11	p-S	Constant, pressure transmitter base calibration		
S	12	pA0	Correction value, pressure transmitter (factor)		
S	13	pA1	Correction value, pressure transmitter (offset)		

Temperature

Pointer position		T			
Coding	Coordinate / Line	D	Description of the coordinate	Unit	Special feature
D	1	°C	Measured temperature value	°C	
S	2	T<	Lower fault limit	°C	
S	3	T>	Upper fault limit	°C	
S	4	Tb	Specified value, temperature at base conditions	°C	
C	5	T-def	Default value, temperature	°C	
S	6	T-F	Adjustment value (factor)		
S	7	T-O	Adjustment value (offset)		
D	8	Dig	Binary value of AD converter		

Analysis

Pointer position		C			
Coding	Coordinate / Line	E	Description of the coordinate	Unit	Special feature
D	1	C	Conversion factor	1	
D	2	K	K coefficient	1	
C	3	K-V	Specified value, K coefficient (if K=const)	1	
C	4	Hon	Superior calorific value	KWh/m3	
C	5	rhon	Rhon	Kg/m3	
C	6	CO2	Carbon dioxide content	%	
D	7	Zb	Compressibility factor at base conditions	1	
D	8	Z	Compressibility factor at measurement conditions	1	
S	9	TB	Reference temperature, superior calorific value	°C	
C	10	N2	Nitrogen content (for AGA-NX-19)	%	
C	11	dv	Relative density (for AGA-NX-19)	1	

Outputs

Pointer position		Io			
Coding	Coordinate / Line	F	Description of the coordinate	Unit	Special feature
D	1	mA	Current out	mA	
C	2	I<	Value at 4 mA	mA	
C	3	I>	Value at 20 mA	mA	
C	4	I-def	Current default	mA	
C	5	I-F	Current rise		
C	6	I-O	Current offset		
C	7	I-D	Current damping		

Error / ID

Pointer position		Error / Type			
Coding	Coordinate / Line	G	Description of the coordinate	Unit	Special feature
D	1	ERR	Error text		
D	2	Ver	Software version		
S	3	SNo	Serial number		
D	4	CRC	Checksum		
S	5	PNo	Serial number pressure transmitter		
S	6	P <	Pressure range min	bar	
S	7	P >	Pressure range max	bar	
S	8	TNo	Serial number temperature transmitter		
S	9	T <	Temperature range min	°C	
S	10	T >	Temperature range max	°C	
S	11	ZNo	Serial number gas meter		
S	12	G	Meter size		
S	13	Bat	Date of next battery change		

Mode / Memory

Pointer position		Mode			
Coding	Coordinate / Line	Z	Description of the coordinate	Unit	Special feature
C	1	MOD	TerzMode		See operating modes
C	2	MOD	EcMode		See operating modes
C	3	X	Puls_ X		
C	4	Y	Puls_ Y		
C	5	T	Time		
C	6	D	Date		
C	7	Mid	Modbus address		
C	8	Mof	Modbus register offset		
C	9	Err	Error bit string (hexadecimal)		
D	10	Pul	Wake-up pulse		
-	11	COD	Code number		Presetting: 1234
C	12	h	Beginning of day for data logger		full hour (0-23)
S	13	MOD	EcMode2		See operating modes
D	14	CNO	Charge number		
D	15	ZG	10=GERG, 11=AGA-NX-19, 12=AGA-8		fixed value
C	16	C-V	Input for change of the code number		

TerzMode, EcMode and EcMode2 are 8-digit strings where each digit stands for one mode. These modes are listed in the following tables.

Operating modes

TerzMode (coordinate Z1)

TerzMode [0]	TerzMode [1]	TerzMode[2]	TerzMode[3]	TerzMode[4]	TerzMode[5]	TerzMode[6]	TerzMode[7]
Internal	Units	Pulse width I.F. output	Display cut-off time	Interface protocol	Pulse scaling factor	Current output	Operating mode
0	customer	125 ms	1 min.	off	0.01	off	1 channel
1	service	250 ms	5 min.	Modbus ASCII	0.1	lout without error	1 channel Vm Stop
2			10 min.	Modbus RTU	1	lout 3.5 mA with error	1 channel Vm Run
3			15 min.		10	lout 21.8 mA with error	2 channels // X:Y act. (SW) Vm Stop
4			test mode		100		2 channels // X:Y act. (SW) Vm Run
5							2 channels // X:Y act. (HW) Vm Stop
6							2 channels // X:Y act. (HW) Vm Run
7	clear data						2 channels // X:Y deactivated
8	clear Qm						
9	all coord. on						

EcMode (coordinate Z2)

EcMode[0]	EcMode[1]	EcMode[2]	EcMode[3]	EcMode[4]	EcMode[5]	EcMode[6]	EcMode[7]
Pressure mode	Temperatur e mode	Current selection	LF selection	Pulse width I.F.-II	Analysis mode	Data logger mode	Frequency mode
0	off	off	Vm	0.8 ms	K=const	Off	off
1	on	default	Vb	10 ms	GERG	Vb, Vm, dVm, p, T	pos. edge
2	default	Qm		20 ms	AGA		neg. edge
3		Qb		50 ms			
4		temp		75 ms			
5		pressure		100 ms			
6				125 ms			
7				250 ms			
8							
9							

EcMode2 (coordinate Z13)

EcMode2[0]	EcMode2[1]	EcMode2[2]	EcMode2[3]	EcMode2[4]	EcMode2[5]	EcMode2[6]	EcMode2[7]
GERG-TN mode	GERG-TB mode	Protection mode	Spare mode	Spare mode	Device type- mode	Spare mode	Tamper contact mode
0	0	fiscal metering			meter		OFF
1	15	secondary metering			meter + T		tamper contact closed
2	20				meter + p + T		tamper contact open
3	25				corrector + T		
4					corrector + p + T		
5							
6							
7							
8							
9							

The connection of a
tamper contact is only
possible with the one-
channel version via the
sensor input 2.

Error messages

In coordinate G 01 error messages are displayed as error number followed by "Err".

The messages no. 1 to 8 are fault messages. In this case the main totalizers stop and the disturbing quantity totalizers start to run. The messages no. 9 to 16 are warnings and have no effect on the totalizers.

Error no.	Hexadecimal	Description
1	0x0001	Parameters in EEPROM are wrong (may be wrong version)
2	0x0002	EEPROM cannot be written (parameters are lost)
3	0x0004	Analog digital converter for temperature measurement
4	0x0008	Analog digital converter for pressure measurement
5	0x0010	Sensor failure
6	0x0020	Measured temperature outside limits
7	0x0040	Measured pressure outside limits
8	0x0080	Hardware and software configuration do not fit
9	0x0100	Tamper contact
10	0x0200	Error during GERG calculation
11	0x0400	Error in flow rate measurement
12	0x0800	Error in monthly data logger
13	0x1000	Current output
14	0x2000	Too many output pulses in buffer (>500)
15	0x4000	Sensor defect (check hardware)
16	0x8000	Sensor defect (check hardware)

In the column "Hexadecimal" the error bit strings displayed in coordinate Z 09 are listed.

Changing the batteries (EC 24)


The two batteries of the EC 24 can easily be changed without opening the corrector. On the left side of the casing, there is a round slotted cover which can be screwed out. Behind this cover, there is the battery holder. In hazardous areas disconnect the battery holder and change the batteries in a safe area. Afterwards connect the battery holder again (see figure) and push it into the battery compartment. Now screw in the cover again and the battery change is terminated.

In safe areas the batteries can be changed directly without disconnecting the battery holder.



If you use other batteries than the replacement batteries from RMG, you run the risk of the EC 24 not being approved for areas subject to explosion hazards any more.

In areas subject to explosion hazards, you must never insert or remove the batteries. Remove the battery holder from the case and change the batteries in an area without explosion hazards.



Annexes

A Equations used with the EC 24 volume corrector

Symbol	Unit	Designation
q_m	= m ³ /h	Flow rate at measurement conditions
f_V	= Hz	Frequency of the volume transducer
K_V	= P/m ³	Meter factor
V_m	= m ³	Volume at measurement conditions
P_V	= 1	Volume pulse
K_{Z1}	= m ³ /P	Totalizer factor (for output contacts only)
q_b	= m ³ /h	Flow rate at base conditions
V_b	= m ³	Volume at base conditions
$C(p, T)$	= 1	Conversion factor
K_{Z2}	= m ³ /P	Totalizer factor (for output contacts only)
p	= bara, (barg, kg/cm ²)	(Absolute) pressure at measurement conditions
p_b	= bara (barg, kg/cm ²)	Pressure at base conditions (= 1.01325 bar absolute)
T	= °C	Temperature at measurement conditions
T_K	= K	Temperature at measurement conditions in Kelvin
T_b	= K	Temperature at base conditions (= 273.15 K)
K	= 1	K coefficient
Z	= 1	Compressibility factor at measurement conditions
Z_b	= 1	Compressibility factor at base conditions
Z / Z _b are calculated in compliance with GERG-88 as per G9		

Flow rate at measurement conditions

$$q_m = \frac{f_v}{K_v} \cdot 3600$$

Volume at measurement conditions

$$V_m = \frac{P_v}{K_v} \cdot \frac{1}{K_{Z1}}$$

K coefficient

$$K = \frac{Z}{Z_b}$$

Conversion factor

$$C(p, T) = \frac{p \cdot T_b}{p_b \cdot T_K \cdot K}$$

Flow rate at base conditions


$$q_b = \frac{f_v}{K_v} \cdot 3600 \cdot C(p, T)$$

Volume at base conditions

$$V_b = V_m \cdot C(p, T) \cdot \frac{1}{K_{Z2}}$$

The pressure at measurement or base conditions is processed as absolute pressure in the relevant equations. In selection mode 2 of column A, however, transmitters with gauge-pressure or kg/cm² scaling are also permitted. If these transmitters are used, the pressure at base conditions must also be indicated in the appropriate unit. Both the pressure at measurement conditions and the pressure at base conditions will then be converted automatically for the relevant equations.

B Block diagram for the EC 24



C Specifications

Temperature ranges

Type: EC 24 II2 G Ex ib IIC T4 Gb from -25°C to +40°C
 II2 G Ex ib IIC T3 Gb from -25°C to +60°C

In the case of special designs, even higher or lower fluid temperatures are possible with not explosion-protected (Non-Ex) versions.

Device types

Reed

Supply	Internal battery (Ex), or external 24 V supply via current-loop connection by means of an intrinsically safe power supply unit, e.g. KFD2-STC3-Ex1 (Ex) plus battery pack.
Pulse input	Reed or transistor
Current output	Only possible via the current-loop connection.
Standby battery	Only in conjunction with the current-loop connection.

Wiegand

Use	Direct installation onto the TERZ 94 meter instead of the meter head.
Supply	Internal battery (Ex), or external 24 V supply via current-loop connection by means of an intrinsically safe power supply unit, e.g. KFD2-STC3-Ex1 (Ex) plus battery pack.
Pulse input	Wiegand
Current output	Only possible via the current-loop connection.
Standby battery	Only in conjunction with the current-loop connection.

Inputs

Volume

– Reed

Pulse frequency	0 Hz to 4 Hz; in battery-powered mode, max. 1 Hz due to the service life
Pulse width	≥ 20 ms
Voltage	low: ≤ 0.9 V high: ≥ 2.2 V

– Wiegand

Pulse frequency	0 Hz to 400 Hz; in battery-powered mode
Pulse width	≥ 5 μ s
Voltage	min: 1 V max: 5 V (depends on the sensor used)

Sensor – S1 input (Measurement input)

(For Ex connected loads, see the approval certificate.)

Terminals:	X5,1 (+) X5,2 (-)
Sensor type:	
Wiegand sensor, direct	Jumpers X_S1 / 3-5 and 4-6
Wiegand sensor, remote totalizer	Length of line < 50 m ¹⁾ Jumpers: X_S1 / 3-4 Jumpers: X_TERZ90 / 1-2
Reed contact	Jumpers: X_S1 / 1-3 and 2-4

Sensor – S2 input (Reference input)

(For Ex connected loads, see the approval certificate.)

Terminals:	X5,3 (+) X5,4 (-)
Sensor type:	
Wiegand sensor, direct	Jumpers X_S1 / 3-5 and 4-6
Wiegand sensor, remote totalizer	Length of line < 50 m ¹⁾ Jumpers: X_S2 / 3-5 and 4-6 Jumpers: X_TERZ90 / 3-4
Reed contact	Jumpers: X_S2 / 1-3 and 2-4

¹⁾ Attention: In case of use of an external pressure transmitter the maximum cable length reduces to 3m!

Temperature input: (hardware and software option)

For Ex connected loads, see the approval certificate.

Signal:	Resistor (Pt1000), 2-wire
Terminals:	X9,1 (+)
	X9,2 (-)

Measuring range:	-20°C to 60°C
Resolution:	± 0.2 °C

Pressure transmitter

For Ex connected loads, see the approval certificate.

Signal:	Voltage: 0.5 V to 4.5 V
Resolution:	16 bits

Terminals:	Plug X16_0
------------	------------

Outputs

HF output

In the case of the explosion-protected (Ex) design, the device can only be connected to a certified intrinsically safe circuit.

Connector: 3 (-) internally: X4,3
 6 (+) internally: X4,4
 Output: Open-drain transistor
 T_{Pulse} : 1 ms \pm 10%
 F_{max} : 300 Hz

	Ex	Non-Ex
U_{min} :	2.0 V	2.0 V
U_{max} :	28 V	30 V
I_{max} :	60 mA	400 mA
Internal inductivity	neglectable	
Internal capacity	3.3 nF	

LF output

In the case of the explosion-protected (Ex) design, the device can only be connected to a certified intrinsically safe circuit. (For Ex connected loads, see the approval certificate.)

Connector: 1 (-) internally: X4,1
 4 (+) internally: X4,2
 Output: Open-drain transistor
 T_{Pulse} : 125 ms \pm 10% (F_{max} : 4 Hz)
 250 ms \pm 10% (F_{max} : 2 Hz)

	Ex	Non-Ex
U_{min} :	2.0 V	2.0 V
U_{max} :	28 V	30 V
I_{max} :	60 mA	400 mA
Internal inductivity	neglectable	
Internal capacity	3.3 nF	

Fault output

In the case of the explosion-protected (Ex) design, the device can only be connected to a certified intrinsically safe circuit. (For Ex connected loads, see the approval certificate.)

Connector: 2 (-) internally: X4,5
 5 (+) internally: X4,6
 Output: Open-drain transistor

	Ex	Non-Ex
U_{\min} :	2.0 V	2.0 V
U_{\max} :	28 V	30 V
I_{\max} :	60 mA	400 mA
Internal inductivity	neglectable	
Internal capacity	3.3 nF	

RS-485 data interface

In the case of the explosion-protected (Ex) design, the device can only be connected to a certified intrinsically safe circuit. (For Ex connected loads, see the approval certificate.)

Connector: 4 (+supply) internally: X15,4
 1 (-supply) internally: X15,3
 5 (line A) internally: X15,2
 3 (line B) internally: X15,1

U_{\min} : 6.0 V
 U_{\max} (U_i): 10.5 V
 I_i : 428 mA
 P_i : 900 mW
 Internal inductivity: 1320 nF
 Internal capacity: 600 μ H

Note: If the RS-485 interface is used, the device is supplied via the data interface.

Current-loop connection

Terminals:	X22,1 (+)	with cable: white conductor
	X22,2 (-)	with cable: brown conductor
U_{ext} (min):	12 V	
U_{ext} (max):	28 V	
I_{min} :	3.5 mA	
I_{max} :	23 mA	

External load (max.): $R_{L\text{max}} = (U_{\text{ext}} - 10 \text{ V}) / I_{\text{max}}$ (in Ω)
 e.g. $U_{\text{ext}} = 16 \text{ V}$
 $\Rightarrow R_{L\text{max}} = (16 \text{ V} - 10 \text{ V}) / 23 \text{ mA} = 260 \Omega$

Current output for

- minimum flow rate:	4 mA
- maximum flow rate:	20 mA
- warning:	3.5 mA
- fault:	23 mA

Accuracy of current output: Better than 1% of the upper-range value

Data for use in areas subject to explosion hazards:

U_i	=	28 V
I_i	=	110 mA
P_i	=	770 mW
C_i	=	2.2 nF
L_i	=	110 μH


Supply

Battery supply 3.6 V lithium cell; inside the device (battery pack)

External 24 V supply 24 V DC; external; via current-loop connection plus battery pack

D Examples of connection (EC 24)


Battery-powered device



* If 2-channel isolating amplifiers are used, the two inputs must be separated!

Mains-powered device


(Connection only via a current module with built-in back-up battery)



* If 2-channel isolating amplifiers are used, the two inputs must be separated!

E Instructions for the measuring element of the turbine meter

Construction



Part	Designation	Material
1	Totalizing unit	
2	Clamping screw	Steel
3	WF01-* or WF02-* sensor	
4	Permanent magnet	Oerstit 500
5	Lubricator (with TERZ 94 from DN 200)	
6	Radial ball bearing	Nirosta steel
7	Turbine wheel	Delrin / aluminum
8	Flow straightener	Hostaform
9	O-ring	
10	Sensor sleeve with sensor	Nirosta steel
11	O-ring 8x2.5	83FKM592

Functional description

The measuring element directly measures the flow rate at measurement conditions and in the top-mounted meter head or corrector the measured values are integrated so that the result is the gas volume which flowed through the meter. The gas flow drives a turbine wheel whose speed is recorded through non-contact measurement by a sensor. Therefore, the meter is characterized by long-term stability and low wear.

An aerodynamic flow straightener (8) fitted into the meter case constricts the effective cross section of the pipe to form a ring-shaped cross-sectional area and substantially eliminates turbulence. The velocity of the flowing gas increases and the gas is directed to the turbine blades.

The turbine wheel (7) is dynamically balanced and mounted with dust-proof ball bearings (6). A permanent magnet (4) located at the end plate of the turbine shaft induces the sensor element (3) to give a voltage pulse with each rotation of the turbine wheel. This pulse is further processed by the electronic system of the meter head (1).

Inside the meter head or corrector, the number of pulses is divided by the meter factor (number of pulses per m³) and the result is used to calculate the volume at measurement conditions. In the main totalizer, the sum of the volume at measurement conditions which flowed through the meter is formed and you can read the gas volume which flowed through the meter per time unit on the flow rate display.

At the HF output (only in the case of an electronic measuring element), the unchanged signal frequency of the sensor element is outputted, whereas, for the LF output, this HF frequency can be reduced by two programmable scaling factors.

Operating conditions

Permissible types of gases

The **standard design** of the TRZ 03 – TE / TEL turbine meters can be used for all non-aggressive gases, such as

Natural gas	Air
Town gas	Acetylene
Methane	Helium
Ethane	Carbon dioxide (dry)
Propane	Nitrogen
Butane	Hydrogen

Special designs (PTFE lining, special lubrication, special material, etc.) can be used for aggressive and humid gases, such as

Ethylene	Digester gas
Biogas	Sulphur dioxide
Acid gas	etc.

Permissible temperature ranges

For the standard design, the following fluid temperature and ambient temperature ranges are permitted:

Fluid temperature range: -20°C to +60°C

For the ambient temperature range, see the ID plate and Annex C on page 34.

Pressure loss

The pressure loss is calculated using the following formula:

$$\Delta p = Z_P \cdot \rho \cdot \frac{Q_M^2}{DN^4}$$

where Δp	is the pressure loss	[mbar]
Z_P	is the pressure loss coefficient	
ρ	is the density	[kg/m ³]
Q_M	is the flow rate at measurement conditions	[m ³ /h]
DN	is the nominal diameter of the meter	[mm]

The pressure loss coefficient Z_P is:

$$Z_P = 5040 \text{ (TERZ 94, TRZ 03-TE)} \quad Z_P = 6050 \text{ (TRZ 03-TEL)}$$

This is an approximate mean value. The exact value is calculated from the pressure loss which is determined on testing the volumeter.

Example of calculation:

$Q_M = 650 \text{ m}^3/\text{h}$; $DN = 150$; $\rho = 1.3 \text{ kg/m}^3$ [natural gas, 600 mbar]

$$\Delta p = Z_P \cdot \rho \cdot \frac{Q_M^2}{DN^4} = 5040 \cdot 1.3 \cdot \frac{650^2}{150^4} = 5.5 \text{ mbar}$$

Therefore, the pressure loss Δp with a TERZ 94 or TRZ 03-TE turbine meter is 5.5 mbar in this case.

Installation

The gas flow must be free of shocks and pulsations as well as free of foreign particles, dust and liquids. Any components affecting the gas flow must absolutely be avoided directly upstream of the TERZ 94 or TRZ 03-TE turbine meter.

To achieve the highest possible accuracy, the following inlet pipe is to be installed upstream of the meter:

- TERZ 94: length of 2 DN, with one perforated-plate straightener
- TRZ 03-TE: length of 2 DN (specified by Technical Guideline G 13)
- TRZ 03-TEL: no inlet pipe required.

Downstream of the meter a straight pipe or a bend in the diameter of the meter and with a total length of at least 2 DN has to be built in as outlet pipe.

In the case of the TERZ 94, you can install the meters in any position (vertical or horizontal) up to and including the nominal diameter of DN 200. From the nominal diameter of DN 250 and in the case of the TRZ 03-TE / TEL, only the position stated in the purchase order is possible.

When you install the meter, please observe the direction of flow indicated on the case!

The meter head (1) can be turned after the clamping screw (2) has been loosened. Turn the meter head by max. 360°, otherwise the signal wires can become twisted and break.

Start-up

Connecting the gas flow



Do not fill any downstream pipelines or station sections through the TERZ 94 or TRZ 03 – TE / TEL turbine meters. This may speed up the turbine wheel and lead to excessively high flow rates with resultant damage.

Short-time overload operation of 20% above the maximum flow rate Q_{max} is permissible. No damage will occur in the case of a return flow without shocks.

Initializing the device

Set all totalizers to the meter reading of your choice. (See programming.)
Now check the settings of the pulse width, decade scalars, etc.

In the case of models with a current output:
Also check the settings of the current output.

NOTE:

All parameters can only be changed if the device has been opened.

F Modbus

Modbus settings

- The EC 24 Modbus has to be activated via coordinate Z01
- The Modbus - ID has to be set via coordinate Z07 (default is 1)
- The Modbus - register - Offset (MRO) has to be set via coordinate Z08 (default is 0)
The MRO has to be used during reading and writing operations.

EC 24 interface parameters

The EC 24 only operates with the following interface parameters:

2400 baud
no Parity
8 Data bit
1 Stop bit
Modbus – ASCII or RTU

The EC 24 has a passive RS485 interface, means, the interface needs to be powered externally.
(see Page 37, RS 485 interface)

EC 24 Modbus – commands

The EC 24 knows the following Modbus commands:

(03 Hex) Read Holding Registers
(06 Hex) Read Single Register
(10 Hex) Preset Multiple Regs
(08 Hex) Diagnostic
(00 Hex) Return Query Data

EC 24 Exception Codes

01 Illegal Function
02 Illegal Data Address (Register not available)
03 Illegal Data Value (Register not addressable or wrong value)

Example (Modbus Question /Answer):

Question:	Sent character	
Start Char	:	
Slave Address	01	
Function	03	
Starting Address Hi	07	
Starting Address Lo	CF	2000-1
No. of Points Hi	00	
No. of Points Lo	02	
LRC	24	
carriage return	cr	
line feed	lf	
Answer:	Received character	
Start Char	:	
Slave Address	01	
Function	03	
Byte Count	04	
Data Hi (Reg 2000)	3F	s.u.
Data Lo (Reg 2000)	80	s.u.
Data Hi (Reg 2001)	00	s.u.
Data Lo (Reg 2001)	00	s.u.
LRC	39	
carriage return	cr	
line feed	lf	

Example (Modbus – format of numbers):

Data type	Register	Value	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	Byte 9	Byte 10
float	2	1.0	0x3f	0x80	0x00	0x00						
Text	5	"90111200"	0x39	0x30	0x31	0x31	0x31	0x32	0x30	0x30	0x00	0x00
int	1	1357	0x05	0x4d								
long	2	698614	0x00	0x0a	0xa8	0xf6						

Further information you may get from the Modbus specifications.

Specifics of the EC 24 – Modbus:

- Data types (float, text ...) may only be read or written completely

float	:	2 Register
long integer	:	2 Register
integer	:	1 Register
text	:	5 Register
Month-archive	:	15 Register

- Maximal 100 register (with one command) can be read or written.

- Text fields have to have minimal one final zero (0x00).

- The writing of certain parameters causes an internal initiating of the hardware, for example, to delete intermediate results (pulse output, ...)

Therefore parameters should only be overwritten if required (for example counter factor).

- Totalizer factors will be given as long – value (without point), the priority of the totalizing unit the be read via the TerzMode (Register 2310).

Modbus - register (November 2009)

Koordinate	Kurzbezeichnung	Beschreibung	Modbus Reg.	Zugriff	Type
A01	ZlwVN	Totaliser base condition	1000 (2)	W-E	long
A02	ZlwVB	Totaliser measurement condition	1002 (2)	W-E	long
A03	ZlwVNErr	Totalisator meas. cond. disturbing quantity	1004 (2)	W-E	long
A04	ZlwVBErr	Totalisator base. cond. disturbing quantity	1006 (2)	W-E	long
B01	Qn	Base cond. volume flow rate	1008 (2)	R-O	float
B02	Qb	Meas. cond. volume flow rate	1010 (2)	R-O	float
B03	Freq	Frequency	1012 (2)	R-O	float
B06	QbMaxwert		1014 (2)	R-O	float
C01	Druck	Pressure	1016 (2)	R-O	float
D01	Temp	Temperature	1018 (2)	R-O	float
E01	ZustandsZahl		1020 (2)	R-O	float
E02	K Zahl	K-number at Gerg or Aga	1022 (2)	R-O	float
E07	Zn		1024 (2)	R-O	float
E08	Z		1026 (2)	R-O	float
F01	StromOut	Current output in mA	1028 (2)	R-O	float
G02	SwVersion		1030 (2)	R-O	float
C06	DruckBin	Pressure Binary	1100 (1)	R-O	int
D08	PT1000Bin	Binary value AD converter	1101 (1)	R-O	int
G01	Error		1102 (1)	R-O	int
G04	Checksumme		1103 (1)	R-O	int
Z09	ErrorStatus	(Hexadezimal)	1104 (1)	R-O	int
A05	PulsUntersetzer		2000 (2)	W-E	float
B04	QbMin	Min. limit	2002 (2)	W-E	float
B05	QbMax	Max. limit	2004 (2)	W-E	float
C02	PMin	Min. limit	2006 (2)	W-E	float
C03	PMax	Max. limit	2008 (2)	W-E	float
C04	Pn	Start pressure base cond.	2010 (2)	W-E	float
C05	PVorgabe	Start pressure meas. cond.	2012 (2)	W-C	float
C09	DruckUmin	Voltage at Pmin	2014 (2)	W-E	float
C10	DruckPmin	Pmin	2016 (2)	W-E	float
C11	DruckSteigung	Pressure gradient	2018 (2)	W-E	float
C12	DruckA0	Factor corr. Equation	2020 (2)	W-E	float
C13	DruckA1	Offset corr. Equation	2022 (2)	W-E	float
D02	TempMin	Min. limit	2024 (2)	W-E	float
D03	TempMax	Max. limit	2026 (2)	W-E	float
D04	Tn	Start temperature base cond.	2028 (2)	W-E	float
D05	TempVorgabe	Start temperature meas. cond.	2030 (2)	W-C	float
D06	TempFaktor		2032 (2)	W-E	float
D07	TempOffset		2034 (2)	W-E	float
E03	KZahlVorgabe	Start value for K-number at K=const.	2036 (2)	W-C	float
E04	Ho	Calorific value	2038 (2)	W-C	float

ANNEXES



E05	Rhon	Base density	2040 (2)	W-C	float
E06	CO2	Concentration	2042 (2)	W-C	float
E09	Tb		2044 (2)	W-E	float
F02	StromMin	Value at 4 mA	2046 (2)	W-C	float
F03	StromMax	Value at 20 mA	2048 (2)	W-C	float
F04	StromVorgabe		2050 (2)	W-C	float
F05	StromOffset		2052 (2)	W-C	float
F06	StromSteigung		2054 (2)	W-C	float
F07	StromDaempfung	Damping	2056 (2)	W-C	float
G06	DruckBereichMin		2058 (2)	W-E	float
G07	DruckBereichMax		2060 (2)	W-E	float
G09	TempBereichMin		2062 (2)	W-E	float
G10	TempBereichMax		2064 (2)	W-E	float
E10	N2	for AGA	2066(2)	W-C	float
E11	dv	for AGA	2068(2)	W-C	float
G03	SerialNo		2200 (2)	W-E	long
G05	DruckNo	Serien Nr. pressure transmitter	2202 (2)	W-E	long
G08	TempNo		2204 (2)	W-E	long
G11	ZaehlerNo		2206 (2)	W-E	long
G13	BattWechsel	(z.B. 10032008) 10.03.2008	2208 (2)	W-C	long
A06	Zaehlerfaktor		2300 (5)	W-E	Text
G12	ZaehlerGroesse		2305 (5)	W-E	Text
Z01	TerzMode		2310 (5)	W-E	Text
Z02	EcMode		2315 (5)	W-E	Text
Z05	TimeStr		2320 (5)	W-C	Text
Z06	DateStr		2325 (5)	W-C	Text
Z13	EcMode-2		2330 (5)	W-E	Text
C07	DruckBin05	Binary value at 0.5 V	2400 (1)	W-E	int
C08	DruckBin45	Binary value at 4.5 V	2401 (1)	W-E	int
Z03	Imp_X		2402 (1)	W-E	int
Z04	Imp_Y		2403 (1)	W-E	int
Z07	ModbusID	Modbus Bus address	2404 (1)	W-C	int
Z08	ModbusRegOffset		2405 (1)	W-C	int
Z10	WakeUpPuls		2406 (1)	W-E	int
Z11	CodeWort		2407 (1)	W-E	int
Z12	Tagesbeginn		2408 (1)	W-C	int
	Gerätetyp		5000(1)	R-O	
	CRC		5001(1)	R-O	
	EcStatus		5002(1)	R-O	
	Bit 0	Current Modul available	5002.0		
	Bit 1	EZD- or 485 HW	5002.1		
	Bit 2	Sealing switch	5002.2		
	Bit 3	Code word	5002.3		

	Bit 4	Reserve	5002.4		
	Bit 5	IG04	5002.5		
	Bit 6	Error	5002.6		
	Bit 7	Notstrom	5002.7		
	Bit 8 ... Bit 15	Reserve	5002.8 - .15		
A09	Mon. Speicher 1	Tag ; Vn ; Vb ; dVn ; dVb ; P ; T ; S	6000 (15)	R-O	Struct
A10	Mon. Speicher 2	Tag ; Vn ; Vb ; dVn ; dVb ; P ; T ; S	6015 (15)	R-O	Struct
A11	Mon. Speicher 3	Tag ; Vn ; Vb ; dVn ; dVb ; P ; T ; S	6030 (15)	R-O	Struct
A12	Mon. Speicher 4	Tag ; Vn ; Vb ; dVn ; dVb ; P ; T ; S	6045 (15)	R-O	Struct
A13	Mon. Speicher 5	Tag ; Vn ; Vb ; dVn ; dVb ; P ; T ; S	6060 (15)	R-O	Struct
A14	Mon. Speicher 6	Tag ; Vn ; Vb ; dVn ; dVb ; P ; T ; S	6075 (15)	R-O	Struct
A15	Mon. Speicher 7	Tag ; Vn ; Vb ; dVn ; dVb ; P ; T ; S	6090 (15)	R-O	Struct
A16	Mon. Speicher 8	Tag ; Vn ; Vb ; dVn ; dVb ; P ; T ; S	6105 (15)	R-O	Struct
A17	Mon. Speicher 9	Tag ; Vn ; Vb ; dVn ; dVb ; P ; T ; S	6120 (15)	R-O	Struct
A18	Mon. Speicher 10	Tag ; Vn ; Vb ; dVn ; dVb ; P ; T ; S	6135 (15)	R-O	Struct
A19	Mon. Speicher 11	Tag ; Vn ; Vb ; dVn ; dVb ; P ; T ; S	6150 (15)	R-O	Struct
A20	Mon. Speicher 12	Tag ; Vn ; Vb ; dVn ; dVb ; P ; T ; S	6165 (15)	R-O	Struct
A21	Mon. Speicher 13	Tag ; Vn ; Vb ; dVn ; dVb ; P ; T ; S	6180 (15)	R-O	Struct
A22	Mon. Speicher 14	Tag ; Vn ; Vb ; dVn ; dVb ; P ; T ; S	6195 (15)	R-O	Struct

W-E	Gaige switch
W-C	Code word
R-O	No protection


G Dimensions

52



*Standard installation

DN	H1
25	190
40	190
50	225
80	260
100	265
150	295
200	325
250	370
300	385
400	375
500	395




MESSTECHNIK GMBH
35510 Butzbach

Dimensions
volumeter/PT-corrector
type EVC 24

Drwg. no.

058147.4

H Sealing plan



Subject to technical modification

For further information

please visit our website:

www.rmg.com

or contact your local sales support office
to learn more about the RMG products.

RMG Messtechnik GmbH

Otto-Hahn-Straße 5

35510 Butzbach, Deutschland

Tel: +49 (0) 6033 897 – 0

Fax: +49 (0) 6033 897 – 130

Email: service@rmg.com

Internet: www.rmg.com

