Turbine meter TME400-VM (..-VMF)



OPERATING MANUAL

Reliable Measurement of Gas

Issued: Version: Firmware: 2019 November 6th 06 1.04



Address	RMG Messtechnik GmbH Otto-Hahn-Straße 5 D-35510 Butzbach (Ger- many)
Main office	+49 6033 897 – 0
Service	+49 6033 897 – 0
Spare parts	+49 6033 897 – 173
Fax	+49 6033 897 – 130
Email	service@rmg.com

Manufacturer Contact our customer service department for technical information.

Translation of the original document The manual TME400VMF_manual_en_06 of 2019 November 6th for the TME400-VM and TME400-VMF turbine meters is the original document. This document is a template for translations in other languages.

Note Unfortunately, paper is not updated automatically, whereas technical development continuously advances. Therefore, we reserve the right to make technical changes in regard to the representations and specifications of these operating instructions. The latest version of this manual (and other devices) can be downloaded at your convenience from our Internet page:

www.rmg.com.

	Created	June	2018
	4 th Revision	March	2019
	5 th Revision	July	2019
	6 th Revision	2019 November 6th	
Document version and language	Document version	TME400VMF_manual_en_06 2019 November 6th	
	Language	EN	

.....

Ι

TABLE OF CONTENTS

1. INTRODUCTION1
1.1. STRUCTURE OF THE MANUAL1
1.2. PURPOSE OF THE MANUAL
1.2.1. ABBREVIATIONS2
1.2.2. SYMBOLS
1.2.3. STRUCTURE OF NOTICES
1.2.4. WORKING WITH THE DEVICE
1.2.4.1. SAFETY NOTICES DANGER, WARNING, CAUTION AND NOTE
1.2.4.2. DANGERS DURING COMMISSIONING
1.2.4.3. DANGERS DURING MAINTENANCE AND REPAIR
1.2.4.4. QUALIFICATION OF PERSONNEL9
1.2.5. RISK ASSESSMENT AND MINIMIZATION9
1.2.6. APPLICABILITY OF THE MANUAL11
1.2.6.1. DANGER DURING OPERATION12
1.2.6.2. DANGERS OF OPERATION IN EX AREAS
1.2.6.3. RESPONSIBILITY OF THE OPERATOR12
1.2.7. TRANSPORT
1.2.8. SCOPE OF DELIVERY13
1.2.9. DISPOSAL OF PACKAGING MATERIAL14
1.2.10. STORAGE
1.3. OVERVIEW OF VERSIONS15
1.3.1. DESCRIPTION15
1.3.2. DEVICE FEATURES
1.3.3. POWER SUPPLY
1.3.4. AREA OF APPLICATION16
1.3.4.1. INSTALLATION AND MOUNTING POSITION17
1.3.4.2. TEMPERATURE RANGES
1.3.5. USE OF GAS METERS FOR DIFFERENT GASES
1.3.5.1. USE OF GAS METERS FOR DIFFERENT GASES
1.4. AREAS OF APPLICATION
1.4.1. WORKING PRINCIPLE OF THE TME40021

CONTENTS

1.4.2. INTEGRATING THE TURBINE METER INTO THE PIPELINE23
1.4.2.1. SEALS
1.4.2.2. SCREWS
1.4.2.3. METER HOUSING MATERIAL
1.4.2.4. INSTALLATION
1.4.2.5. THRESHOLD VALUES
1.4.2.6. TECHNICAL GUIDELINE G13
1.4.2.7. STANDARDS / GUIDELINES
1.4.2.8. MEASURING RANGES
1.4.2.9. MEASURING ACCURACY
1.4.2.10. PRESSURE LOSS
1.4.2.11. PUTTING THE DEVICE INTO OPERATION
1.4.2.12. MAINTENANCE / LUBRICATION
2. INSTALLATION
2.1. ELECTRICAL CONNECTIONS
3. TME40045
3.1. DISPLAY FIELD
3.1.1. DISPLAY TEST
3.1.2. RESET
3.1.3. BOOTING UP
3.1.4. BATTERY REPLACEMENT
4. OPERATION
4.1. OPERATION CONCEPT
4.1.1. COORDINATE SYSTEM
4.1.2. DISPLAY AND COORDINATE SYSTEM
4.1.3. PARAMETER PROTECTION
4.2. PROGRAMMING55
4.2.1. PROGRAMMING WITH THE PROGRAMMING BUTTONS
4.2.1. PROGRAMMING WITH THE PROGRAMMING BUTTONS
4.2.1. PROGRAMMING WITH THE PROGRAMMING BUTTONS 55 4.3. EQUATIONS IN THE TME400 59 4.3.1. VARIABLE DESCRIPTION 59
4.2.1.PROGRAMMING WITH THE PROGRAMMING BUTTONS554.3.EQUATIONS IN THE TME400594.3.1.VARIABLE DESCRIPTION594.3.2.STANDARD FORMULA59

II

Contents

.....

4.3.3.	1.	VOLUME / METERS60
4.3.3.	2.	FLOW RATE
4.3.3.	3.	CURRENT OUTPUT63
4.3.3.	4.	ERROR / TYPE PLATE64
4.3.3.	5.	RS-485 INTERFACE65
4.3.3.	6.	ARCHIVE
4.3.3.	7.	SETTINGS
4.4.	RM	GVIEW ^{EVC}
5. T	ECH	NICAL DATA73
5.1.1.	D	EVICE TYPES
5.1.2.	IN	IPUTS73
5.1.2.	1.	POWER SUPPLY73
5.1.2.	2.	PULSE IN MEASURING INPUTS (SENSOR 1 / 2)74
5.1.3.	0	UTPUTS
5.1.4.	D	ATA INTERFACE74
5.1.5.	С	URRENT LOOP CONNECTION
5.1.6.	С	ABLE
5.1.7.	С	ABLE CONNECTION
5.1.8.	G	ROUND
5.2.	OVE	ERVIEW OF MATERIALS IN USE
6. E	RRO	R MESSAGES
APPE	NDI)	(
A N	IODE	83US
B D	IME	NSIONS
с т	YPE	PLATE
D S	EAL	DIAGRAMS
E C	ERT	IFICATES AND APPROVALS



1. Introduction

1.1. Structure of the manual

The introduction of this manual comprises two parts. The first part lists general specifications; the symbols used in the manual and the structure of notices are presented and a risk assessment is provided. The differences between the TME400-VM and TME400-VMF turbine meters are explained. If there is no explicit reference to differences, the TME400 is superordinate for both versions of the turbine meter.

Note

This manual refers to the TME400-VM and TME400-VMF instead of the complete turbine meter.

In addition, the first part includes specifications for the transport and storage of the TME400. The second part of the introduction describes the features and areas of application of the TME400; basic standards are listed and the pressure and temperature ranges in which the TME400 can and may be used are pre-adjusted.

The second chapter describes the electrical and mechanical commissioning of the TME400. An explanation of how to achieve the reliable commissioning of the meter and high precision is provided.

The third chapter explains the displays of the TME400. It explains resetting, booting and replacement of the battery.

The settings of the TME400 are explained in chapter four. In particular, all adjustable parameters are provided there with some explanations.

The fifth chapter summarizes the technical data and the sixth chapter provides a list of error messages.

The appendix provides details about the Modbus, measurements, type plate and seal plans. Then the certificates and approvals are listed.



1.2. Purpose of the manual

This manual provides information that is necessary for fault-free and safe operation.

The TME400 was designed and produced according to the state of the art and generally recognized safety standards and directives. However, its use can entail dangers that are avoidable by complying with this manual. The device must only be used as intended and in technically sound condition.

🛕 Warning

Unintended use voids all warranty claims and the TME400 can also lose its approvals.

1.2.1. Abbreviations

The following abbreviations are used:

TME400-VM	The TME400-VM is a turbine meter which is used for non-custody-transfer volume measurement (\underline{V} olume \underline{M} easurement) of the operating volume of non-aggressive gases and combustion fuels is used.
TME400-VMF	The TME400-VMF is a turbine gas meter that is used in custody- transfer applications (<u>F</u> iscally). The designation TME400-VMF comprises all turbine meters.
TME400-VC	The TME400-VC also enables calculation of the standard volume flow (\underline{V} olume \underline{C} orrector) from the operating volume flow in non-custody-transfer applications.
TME400-VCF	The TME400-VCF is used in custody-transfer applications (<u>F</u> iscally). In addition to the turbine meter, the TME400-VCF designation also includes the volume corrector.

Note

This manual only describes the TME400-VM and TME400-VMF.



MessEG	Measurement and Calibration Act Law on the marketing and provision of measuring devices in the market, their use and calibration, valid since 1/1/2015	
MessEV	Measurement and Calibration Regulation Regulation on the marketing and provision of measuring devices in the market and on their use and calibration; 12/11/2014	
MID	Measurement Instruments Directive	
PTB	Physikalisch-Technische Bundesanstalt [German National Test Authority]	
Vo	original meter reading (Volume) of a mechanical counter	
approx.	approximately	
max.	maximum	
min.	minimum	

1.2.2. Symbols

The following symbols are used:

1, 2,	Identifies steps for work tasks

1.2.3. Structure of notices

The following notices are used:

▲ Danger This warning notice informs you of imminently threatening dangers that can arise due to misuse/operator error. If these situations are not avoided, death or severe injuries can occur.

1 Introduction



Warning

This warning notice informs you of potentially dangerous situations that can arise due to misuse/operator error. If these situations are not avoided, minor injuries can occur.

Caution

This notice informs you of potentially dangerous situations that can arise due to misuse/operator error. If these situations are not avoided, damage to the device or nearby property can occur.

Note

4

This notice informs you of potentially dangerous situations that can arise due to misuse/operator error. If these situations are not avoided, damage to the device or nearby property can occur.

This notice can provide you with helpful tips to make your work easier. This notice also provides you with further information about the device or the work process in order to prevent operator error.

1.2.4. Working with the device

1.2.4.1. Safety notices Danger, Warning, Caution and Note

Danger All of the following safety notices must be observed!

Disregard of the safety notices can result in danger to the life and limb or environmental and property damage.

Bear in mind that the safety warnings in this manual and on the device cannot cover all potentially dangerous situations, because the interaction of various conditions can be impossible to foresee. Merely following the instructions may not suffice for correct operation. Always remain attentive and consider potential consequences.



- Read this operating manual and especially the following safety notices carefully before working with the device for the first time.
- Warnings are provided in the operating manual for unavoidable residual risks for users, third parties, equipment or other property. The safety instructions used in this manual do not refer to unavoidable residual risks.
- Only operate the device in fault-free condition and in observance of the operating manual.
- Compliance with local statutory accident prevention, installation and assembly regulations is also mandatory.

Caution

All notices in the manual must be observed. Use of the TME400 is only permitted in accordance with the specifications in the operating manual. RMG assumes no liability for damages arising due to disregard of the operating manual.

▲ Danger

Service and maintenance tasks or repairs that are not described in the operating manual must not be carried out without prior consultation with the manufacturer. The device must not be opened forcefully.

A Caution

The TME400 is approved for custody-transfer applications. For this purpose, it is sealed before deliver and settings specified by the approval authority are locked. These seals, software or hardware locks must not be damaged, destroyed or removed!

In this case, the TME400 loses its official certification!

The TME400 can only be approved for officially certified operation after a renewed inspection by an officially recognized inspection authority or calibration officials and an additional inspection of additional settings. The calibration official must re-apply the seals after the inspection.



Observe the following, in particular:

- Changes to the TME400 are not permitted.
- The technical specifications must be observed and followed for safe operation. Performance limits must not be exceeded (*chapter 5 Technical data*).
- For safe operation, the TME400 must only be used in the scope of the intended use (*chapter 1.3 Overview of versions*).
- The TME400 complies with current standards and regulations. However, danger can arise with misuse.

1.2.4.2. Dangers during commissioning

Initial commissioning

The initial commissioning must only be carried out by specially trained personnel (training by RMG) or RMG service personnel.

Note

An acceptance test certificate must be created during the commissioning. This, the operating manual and the EU Declaration of Conformity must be stored so that they are always readily available.

All sharp edges on the device were removed, insofar as possible. However, personal protective equipment provided by the operator must be worn during all work.

🛕 Danger

Install the device as specified in the operating manual. If the device is not installed as specified in the operating manual, there may be a risk that adequate explosion protection is not provided.

The explosion protection is lost!



🛦 Danger

Inadequately qualified persons working on the equipment are unable to correctly estimate dangers. Explosions can be triggered. Only work on the equipment if you have the appropriate qualifications.

Components can be damaged if you do not use suitable tools and materials. Use tools that are recommended for the respective work in the operating manual.



Mechanical installation	Mechanical installation must only be performed by appro- priately qualified technicians.
Electrical installation	Installation on electrical components must only be carried out by qualified electricians.
Mechanical and/or electrical installation	These qualified personnel require training specifically for work in hazardous areas. Qualified personnel are persons who have training / education in accordance with DIN VDE 0105 , IEC 364 or comparable standards .

🛦 Danger

Installation and removal of the TME400 must only take place in an explosionfree, pressure-free atmosphere. The descriptions in the operating manual must be observed. In general, it is recommended that the replacement should only be carried out by RMG Service.

A leak test must be carried out after work on pressurized components.

All of the above points also apply to repair and maintenance tasks and in general when opening the meter is necessary.

Flange fastening elements, fastening screws, screw couplings and check valves, the oil supply, pressure relief connections, valves, HF pulse generators, protective pipes and swivel adapters must <u>not</u> be loosened during operation.

1.2.4.3. Dangers during maintenance and repair

Operating personnel The operating personnel use and operate the device in the scope of the intended use.



Maintenance personnel	Work on the device must only be carried out by qualified personnel who can carry out the respective tasks on the basis of their technical training, experience and familiarity with the applicable standards and requirements. These qualified personnel are familiar with the applicable statu- tory regulations for accident prevention and can inde- pendently recognize and avoid potential dangers.
Maintenance and clean-	Maintenance and cleaning must only be performed by ap-
ing	propriately qualified technicians.

A Danger

Inadequately qualified persons working on the equipment are unable to correctly estimate dangers. Explosions can be triggered. If work on live equipment must be conducted in hazardous areas, sparks that are created can trigger an explosion.

▲ Danger

The device can be damaged if it is not cleaned as specified in the operating manual. Only clean the device as specified in the operating manual.

Components can be damaged if you do not use suitable tools. The explosion protection is lost.

- Only clean the device with a damp cloth!

▲ Danger

The TME400 must only be used as intended! (*Chapter 1.3 Overview of versions*). Prevent use of the TME400 as a potential climbing aid or use of attachments of the TME400 as potential handles!



1.2.4.4. Qualification of personnel

Note

In general, the following is recommended for all persons working with or on the TME400:

- Training / education for work in hazardous areas.
- The capacity to be able to correctly estimate dangers and risks when working with the TME400 and all connected devices. Possible dangers include components that are under pressure and consequences of incorrect installation.
- Recognition of dangers that can arise from the flow medium that is used.
- Training / education by RMG for work with gas measuring devices.
- Education / instruction in all national standards and directives to be complied with for the work to be carried out on the device.

1.2.5. Risk assessment and minimization

According to assessment by qualified employees of RMG, the TME400 is subject to risks during its use. Risks can arise, for example, due to high pressures and occasionally due to pressures that are too low. Work outside of the permissible temperature range can also lead to dangers. Impermissible current and voltage values can trigger explosions in hazardous areas. The risk assessment requires an emptying and ventilation of the pipeline for connection with installation and removal of a turbine. Then and only then is it assured that there is not an hazardous gas mixture in the pipeline. Naturally, work must only be carried out by trained personnel (see *chapter 1.2.4.4 Qualification of personnel*), who are also trained to recognize suitable tools and use them exclusively. The risks were summarized alongside development and measures were taken to minimize these risks.

Measures for risk minimization:

- All pressurized parts are designed in accordance with AD 2000 rules and regulations, Pressure Equipment Directive, Annex 1
- The complete pressure design has been inspected by TÜV Hessen
- All pressurized parts have been manufactured with a material certificate; there is an uninterrupted change of batch tracing of pressurized components
- The mechanical properties of all relevant pressurized components have been subjected to tension tests, notch impact bending tests and hardness tests
- Non-destructive testing was also carried out: X-ray and ultrasonic inspection of the meter housing for defective points in material, surface crack testing with magnetic powder and a color penetration process



- Strength tests for components were conducted at 1.5 times the nominal pressure for the pressure testing; the leak testing for the assembly was conducted at 1.1. times the nominal pressure. Certificates were issued for successfully passed tests
- The maximum operating pressure and the permissible temperature range are specified on the type plate of the device. Operation of the device is only permitted within these specified ranges.

🛕 Danger

The following applies for work in hazardous areas (all zones):

- The pulse generators of the turbine meter must be connected to intrinsically safe power circuit only.
- Only tools that are approved for Ex Zone 1 are permitted for maintenance and repair tasks.
- Otherwise, work must only be carried out when there is not an explosive atmosphere.
- The risk of ignition due to impact or friction must be avoided.
- Work on devices which are used in hazardous areas must be carried out by qualified electrical engineers with special capabilities for work in hazardous areas.

🛕 Danger

The following applies for work in hazardous areas (all zones):

- The wiring / installation in hazardous areas must only be carried out by trained personnel in accordance with EN60079-14 and in observance of national regulations.
- Qualified persons must satisfy the definitions in accordance with DIN EN 0105 or IEC 364 or directly comparable standards.
- If one or more power circuits are used, it must be ensured that the permissible limit values according to the EC type approval certificate are not exceeded when choosing the cables.
- Every Ex signal circuit must be routed with a dedicated cable which must be guided through the appropriate PG screw coupling.
- Permanent installation of the intrinsically safe cable is mandatory.



🛕 Danger

In addition, the following applies for work in hazardous areas (all zones):

- Only trained and instructed personnel are permitted. Work on the measuring system must only be carried out from qualified persons and inspected by responsible qualified supervisors.
- Qualified persons have been authorized by the person responsible for safety of personnel to carrying out such work on the basis of their training, experience or instruction and familiarity with applicable standards, provisions, accident prevention regulations and system conditions. It is essential that these persons are able to recognize and avoid potential dangers in good time.



1.2.6. Applicability of the manual

This manual describes the TME400. TME400 is generally only part of a complete system. The manuals of the other components of the system must be observed. If you find contradictory instructions, contact RMG and/or the manufacturers of the other components.

Note

Ensure that the power data of the current connection matches the specifications on the type plate. Ensure that the limit values specified in the conformity certificate (see appendix) for the devices to be connected are not exceeded.

Observe any applicable national regulations in the country of use. Use cable that is appropriate for the cable fittings.

🛦 Danger

Only work on the equipment if you have the appropriate training and qualifications.

Attention: Risk of destruction due to body electricity, e.g. due to the rubbing of clothing.



1.2.6.1. Danger during operation

Observe the specifications of the system manufacturer and/or system operator.

1.2.6.2. Dangers of operation in EX areas

Only operate the device in fault-free and complete condition. If you make technical changes to the device, safe operation can no longer be guaranteed.

\Lambda Danger

Only use the device in its original condition. The TME400 is permitted for operation in Ex Protection Zone 1, but only within the permissible temperature range (*chapter 1.3.4.2 Temperature* ranges).

1.2.6.3. Responsibility of the operator

As the operator, you must ensure that only adequately qualified personnel work on the device. Ensure that all employees who work with the device have read and understood this manual. You are also obligated to train personnel regularly and inform them of the dangers. Ensure that all work on the device is carried out exclusively by qualified persons and inspected by responsible qualified supervisors. The responsibilities for installation, operation, fault rectification, maintenance and cleaning must be clearly regulated. Instruct your personnel with regard to the risks involved with working with the device.

1.2.7. Transport

The device is packaged specific to the transport requirements for each customer. Ensure safe packaging that absorbs light impact and vibrations is used for any further transport. Nevertheless, inform the transport company that all types of impact and vibrations should be avoided during transport.



🛕 Warning

Risk of injury during transport

Any foot screws must be mounted if they are provided as a transport safeguard to prevent rolling and tipping. Additional measures must be taken to ensure that impermissible rolling and tipping are prevented.

Only use the provided lifting eyes / ring screws to lift the meter. Please observe the relevant permissible loads for the lifting equipment. Prior to lifting, ensure that the load is securely fastened. Do not stand under suspended loads.

The device can slip, topple over or fall down when being lifted and set down. The device can fall over if the bearing capacity of the lifting equipment is disregarded. There is a risk of severe injury for nearby persons.

If the device is delivered on a Euro pallet, the device can be transported on the pallet using a pallet truck or forklift.

The gas meters and accessories must be protected from jarring and vibrations during transport.

The gas meters or any inlet/outlet pieces have a flange as an end piece. The flanges are sealed with a protective sticker or fitted with a plastic dummy plug. The protective stickers and/or dummy plugs must be removed without leaving any residue prior to installation in the pipeline. Residue from this film changes the flow and causes measuring errors!

This protection must be re-applied to the flanges for transport or storage of the device.

1.2.8. Scope of delivery

The scope of delivery can differ depending on the optional orders. The following is "normally" included in the scope of delivery:

Part	Quan- tity
TME400-VM (or TME400-VMF) turbine meter	1
1 Lubricating oil bottle	Op- tional
Lubricating instructions	1
Manual	
Test log	1



Calibration certificate	
Material test certificate	1
Strength test certificate 3.1.	Op- tional

1.2.9. Disposal of packaging material

Dispose of the material in an environmentally friendly manner in accordance with national standards and directives.

1.2.10. Storage

Avoid extended periods of storage. After storage, inspect the device for damage and test for correct function. Contact the RMG service department to arrange for inspection of the device after a storage period of longer than one year. For this purpose, return the device to RMG.

Note

Storage must take place in a dry and protected room.

It must be ensured that all open pipes are sealed.



1.3. Overview of versions

1.3.1. Description

The **TME400-VM** is a turbine meter which is used for volume measurement of the operating volume of non-aggressive gases and burnable gas. The operating volume flow is determined based on the turbine speed, which is scanned by means of a Wiegand or Reed sensor element and then added together in internal archives. The result is registered in an electronic meter.

There are a high-frequency (HF) and a low-frequency (LF) output, where the HF output is preferably used as a flow sensor for control tasks and remote transmission. In addition to these outputs, the TME400 VM has a serial RS 485 interface for digital data readings and parameterization. The TME400-VM is used in **non-custody-transfer** applications.

The **TME400-VMF** (MID) is the turbine meter for custody-transfer applications and has an equivalent function and operating method to the TME400-VM. The essential difference is the 2-channel measuring head version. It is used in **custody-transfer applications**.

1.3.2. Device features

TME400-VM

- Non-custody-transfer measurements
- Electronic meter
- Alarm output
- Optionally available in a version with remote meter (distance from meter head to meter: 10 m; see appendix B Dimensions)
- 2x pulse inputs selectable for Reed, Wiegand and external pulse transmitters (remote meters)
- 1x contact input
- 1x HF output
 - (input pulse of pulse input 1 is output with defined pulse width of 1 ms)
- 1x LF output with defined pulse width (20 ms, 125 ms or 250 ms)
- 1x RS485 with external power supply
- 1x optional power module
- Power supply via 3.6V lithium cell or an external power supply which is assigned to the RS485 interface (supply via power module alone is not adequate and a battery is required for support)
- Archive memory for events, parameters, measurements



TME400-VMF

16

In addition to the features of the TME400 VM, this version can be used for custody-transfer applications.

1.3.3. Power supply

Battery-operated device

The TME400 is equipped with a replaceable 3.6 V lithium battery. The device is designed for continuous operation for approximately 10 years. To achieve this, the devices may be operated for a maximum of 15 minutes per day with input pulses of 1 Hz.

Battery-operated device with additional external power supply

An electric supply of the TME400 via the 4-20mA current loop reduces the power consumption from the batterie and typically extends the service life of the battery to more than 12 years.

If the TME400 is additionally electrical powered by the RS485 interface, the service life of the battery is typically extended to clearly more than 12 years.

Battery replacement indicator

The remaining battery life is determined by means of an internal calculation. An indicator in the display appears when it is time to replace the battery. Battery replacement is described in *chapter 3.1.4 Battery replacement*. In parameter G20 *Date of last battery change* the date of the last battery change is displayed (see *chapter 4.3.3 Coordinates in context*).

Note

In case of a loss of the external power supply, the TME400 is supplied by the buffer battery. The battery symbol is blinking in this case.

1.3.4. Area of application

The TME400 is approved for use in hazardous areas with the following mark:



II 2G Ex ia IIC T4 Gb



The EC type approval certificate is:

TÜV 17 ATEX 207566 X IECEx TUN 18.0009 X

The corresponding conformity certificates are provided in the annex. The RMG contact information is provided on the second and last page.

1.3.4.1. Installation and mounting position

The TME400-VM and TME400-VMF can be supplied with DIN and ANSI connections. Up to nominal diameter DN 200, the installation position of the turbine meter with permanent lubrication can be selected as required. From nominal diameter DN 250, the meter must be installed in the ordered installation position. It must also be ensured that the filling opening of the lubrication faces upwards.

1.3.4.2. Temperature ranges

The turbine meter TME400 in standard version is approved for the following temperature ranges.

Temperature ranges	
Medium temperature	-25°C to +55°C
According to ATEX (Tamb)	-25°C to +55°C (II 2G Ex ia IIC T4)
According to PED 2014/68/EU	 -20°C to +80°C (spheroidal graphite iron) -40°C to +80°C (cast steel) -40°C to +80°C (stainless steel) -10°C to +80°C (welded version and round steel material)
Pressure safety for DN25 according to sound engineering practice, see PED 2014/68/EU, sec. 4, subsec. 3	-40°C to +60°C (aluminum)

Lower temperature limits are available on request with the welded version and round steel material.

Caution

Λ

Direct solar radiation must be avoided.



Note

If different temperature ranges apply simultaneously, the smallest specified range applies for the overall system. This is also marked on the type plate.

18

.....



1.3.5. Use of gas meters for different gases

Gas	Symbol	Tight- ness at 0°C and 1.013 bar	Meter housing	Comments	10
Natural gas		0.8	Standard		
City gas			Standard		
Methane	CH4	0.72	Standard		
Ethane	C ₂ H ₆	1.36	Standard		
Propane	C3H8	2.02	Standard		
Butane	C4H10	2.70	Standard		
Air		1.29	Standard		
Argon	Ar	1.78	Standard		
Helium	He	0.18	Standard		
Carbon dioxide (dry)	CO ₂	1.98	Standard		
Nitrogen	N2	1.25	Standard		
Hydrogen	H2	0.09	Standard	up to 100% Generally, a reduced meas- uring range	
Ethylene (gaseous)	C ₂ H ₄	1.26	Special	Special version (also for hu-	
Biogas			Special	mid gases):	
Sour gas			Special	Teflon coating, special lubri-	
Digester gas / sewage gas			Special		
Sulfur dioxide	SO ₂	2.93	Special		

The components of the gases must be within the concentration limits according to EN 437:2009 for test gases. Safe operation is guaranteed with these specified gases.

Other gases on request.



1.3.5.1. Use of gas meters for different gases

The TME400 can be used in hydrogen-containing natural gas up to pure hydrogen. There are no safety-related concerns for this use.

Notice

In accordance with the German TR-G19 – the TME400 is suitable and approved for use in custody transfer applications – in natural gases with a maximum hydrogen content of 10 mol-%, with the accuracy specified in *chapter 1.4.2.9 Measuring accuracy*.

Since there are currently no certified test rigs in Germany to calibrate meters with higher hydrogen-containing gases, an accuracy above 10 mol-% cannot be tested or certified.

Not custody transfer measurements are of course possible in natural gases with a hydrogen content above 10 mol%. However, a reduced measuring range must be taken into account if applicable. Please contact RMG for further information.





1.4. Areas of application

The following chapter provides handling instructions for the TME400 turbine meter for the purpose of safe and reliable operation of the device.

Note	21
Some of the settings described below must not be made until you have read the explanations in <i>chapter4 Operation</i> .	

1.4.1. Working principle of the TME400

The working principle of a mechanical turbine meter is based on the measurement of the gas velocity of the flowing gas which powers a turbine wheel. The speed of the turbine within the measuring range $(Q_{min} - Q_{max})$ is approximately proportional to the mean gas velocity and thus the flow rate. The number of rotations, therefore, is a measurement for the gas volume flowing through.

1 Introduction

22





Figure 1: Turbine meter sectional drawing

There is a permanent magnet on the end disc of the turbine shaft which induces a voltage pulse in the Wiegand sensor with every rotation. This pulse is supplied to the measuring unit of the meter head, which detects the operating volume flow directly as a main totalizer and determines the gas volume flowing through the meter by adding up the pulses and division by the meter factor (number of pulses per m₃). This operating volume is shown in the display of the TME400.



Note

The unchanged signal frequency of the sensor element is output at the HF output.

The LF output transmits this HF frequency with a variable scaling factor (*chapter 4.3.3.1 Volume / Meters*).

1.4.2. Integrating the turbine meter into the pipeline

Turbine meters from RMG are equipped with connecting flanges. For a secure connection, the connection dimensions of the flanges of the pipelines to be connected must match the connection dimensions of the flanges of the device.

- ANSI pressure levels: flange connection dimensions correspond to the standard ASME B 16.5.
- DIN pressure levels: flange connection dimensions correspond to the standard DIN EN 1092.

1.4.2.1. Seals

- Flat seals:
- Grooved seals:
- Spiral seals:
- Octagonal ring-joint seal:

 $k_0 \times K_D = 20 \times b_D | k_1 = 1.3 \times b_D [N/mm]$ $k_0 \times K_D = 15 \times b_D | k_1 = 1.1 \times b_D [N/mm]$ $k_0 \times K_D = 50 \times b_D | k_1 = 1.4 \times b_D [N/mm]$ $K_D = 480 N/mm_2$

Refer to the tables below for the recommended dimensions.

Flat seals (DIN 2690 / EN 12560-1 Form IBC)



1 Introduction

24

100	4"	115	162	162	175	168	168
150	6"	169	218	218	222	225	225
200	8"	220	273	273	279	285	292
250	10"	274	328	330	340	342	353
300	12"	325	378	385	410	402	418
400	16"	420	490	497	514	515	547
500	20"	520	595	618	607	625	628
600	24"	620	695	735	718	730	745

Grooved seals (EN 12560-6 with centering ring)



		ANSI 300/	ANSI 600	PN	64
D	Ν	d1	d2	d1	d2
50	2"	69.8	88.9	65	87
80	3"	98.4	123.8	95	121
100	4"	123.8	154.0	118	144
150	6"	177.8	212.7	170	204
200	8"	228.6	266.7	220	258
250	10"	282.6	320.7	270	315
300	12"	339.7	377.8	320	365
400	16"	422.3	466.7	426	474
500	20"	530.2	581.0	530	578
600	24"	631.8	682.6	630	680

Spiral seals (EN 12560-2 with centering ring)



.....





	l 600	ANS		64	PN		I 300	ANS			
2	d2	d1		d3	d2	d1	d3	d2	d1	N	D
5.9	85.9	69.9	51	84	66	54	85.9	69.9	51	2"	50
).7	120.7	101.6	81	119	95	86	120.7	101.6	81	3"	80
).4 —	149.4	120.7	106.4	144	120	108	149.4	127.0	106.4	4"	100
).6	209.6	174.8	157.2	200	174	162	209.6	182.6	157.2	6"	150
3.7	263.7	225.6	215.9	257	225	213	263.7	233.4	215.9	8"	200
'.5 —	317.5	274.6	268.3	315	279	267	317.5	287.3	268.3	10"	250
1.7	374.7	327.2	317.5	366	330	318	374.7	339.9	317.5	12"	300
3.6	463.6	412.8	400	466	426	414	463.6	422.4	400	16"	400
'.9	577.9	520.7	500	574	530	518	577.9	525.5	500	20"	500
5.8	685.8	628.7	603.3	674	630	618	685.8	628.7	603.3	24"	600

Note

When flange seals which protrude into the pipeline are used for turbine meters, the measuring accuracy can be influenced negatively. Ensure that the flange seals do <u>not</u> protrude beyond the seal surfaces into the pipeline.

🛕 Danger

Gas escape due to incorrect seal

If incorrect flange seals are used for the assembly of turbines, an explosive gas mixture can form due to leaks.

Danger of poisoning and explosion!

In addition, the stress on the flange is increased to an impermissible level when tightening the thread bolts.

Ensure secure fastening/attachment of the TME400 during assembly in order to avoid crushing. Ensure that you keep your fingers (or other body parts) away from these openings and gaps when pulling the flanges together.

1 Introduction



1.4.2.2. Screws

	Temperature ranges for screws and nuts								
	-10°C to +80°C		-40°C to +80°C						
Pressure levels		Option 1	Option 2	Option 3					
up to and including 40 bar	Screws according to DIN EN ISO 4014 in material 5.6 Nuts according to DIN EN ISO 4032 in material 5-2	Screws according to DIN EN ISO 4014 in material 25CrMo4, Nuts according to DIN EN ISO 4032 in material 25CrMo4							
40 bar or higher	Threaded bolts according to ANSI B1.1 material ASTM A 193 degree B7, Nuts according to ANSI B1.1 material ASTM A 194 degree 2H,	Threaded bolts according to ANSI B1.1 material ASTM A 320 degree L7, Nuts according to ANSI B1.1 material ASTM A 320 degree L7,	Threaded bolts according to ANSI B1.1 material 42CrMo4 Nuts according to ANSI B1.1 material 42CrMo4	Reduced shaft screws according to DIN 2510 material 25CrMo4, Nuts according to DIN 2510 material 25CrMo4					

Note

Reduced shaft screws must only be used for devices in the area of application of the Pressure Equipment Directive.

The durability of the flange connection was verified using the screws listed in this chapter in combination with the seals listed in the previous chapter with the following maximum material characteristic data according to AD200 rules and regulations. Other screw/flange variants were not tested.

Malfunctions can occur with incorrect seals.

1.4.2.3. Meter housing material

Cast steel or round steel material, depending on the pressure level and nominal diameter. Aluminum or stainless steel for the screw-type versions.



1.4.2.4. Installation

Note

Installations disturbing the gas flow directly upstream of the turbine meter must be avoided

(see DVGW guideline G 492 II and PTGB guideline G 13).

An inlet pipe of at least 2 x DN is required upstream from the turbine meter TME400. The inlet pipe must be designed as a straight pipe section with the same nominal diameter as the meter. With heavy upstream pertubations, installation of straighteners is recommended (refer to the table on the next page). A pipe or bend with the nominal diameter of the meter having a total length of 2 x DN must be arranged downstream from the meter.

Temperature measuring devices must be installed at a distance of at least 1 x DN or at least 300 mm with nominal diameters \ge DN 300.

If there is pertubation (e.g. a gas pressure control device) upstream from the inlet pipe, a perforated plate straightener is also necessary. Perforated plate straightener according to ISO 5167-1 or the type RMG LP-35, which cause a pressure loss by a factor of 2.5 in comparison with the standard straightener, can be used.

Recommended installation with straightener



1 Perforated plate straightener

• The opening angle of the reducing or expansion pieces which are installed upstream from the TME400 turbine meter must not be more than 30°.

Note

A screen must be installed on the inlet side of the meter for protection of the turbine meter from foreign objects which may be present in the gas flow. The screen can be, for example, a perforated plate/filter of \emptyset 0.15 mm (available as an accessory).

Perforated plate straightener LP 35



\Lambda Danger

Protect the turbine meter from damage caused by high pressure changes fluctuations in the flow, e.g. if the downstream pipeline system is filled or blown off.

🛕 🛛 Danger

Welding on the line must only take place at a safe distance from the meter. Extreme temperatures in the line near the meter can cause permanent damage to the meter.

▲ Danger

Establish all electrical connections between meters and amplifiers or flow computers as specified in the installation manual. Ensure that the connections are intrinsically safe.

A Caution

Liquids remaining in the line after hydrostatic testing can damage internal parts of the meter.

If hydrostatic testing is not possible, the turbine meter must be replaced with a pipe section. Ensure that there is no liquid remaining in the line above the meter after the hydrostatic testing.

1.4.2.5. Threshold values

The following threshold values are recommended for maximum durability and the highest measuring accuracy:



Note				
Maximum overload	< 20% above Q _{max} , short-term (< 30 sec)			
Maximum flow rate changes and/or impact loads	< 0.01.Qmax/sec = 1% of Qmax/sec e.g. start-up 0 - 100%: > 100 sec			
Maximum pressure change:	< 0.1 bar/sec			
Maximum flow pulsation:	< 5%			
Particle size in the gas flow:	< 5 µm			
Lubrication:	Refer to lubrication chapter Intervals depend on the status of the gas (condensate, rust, dust)			
Vibration / mech. vibration:	< 1 mm/sec (vibration speed)			

These measures must be determined and checked during commissioning, before filling, during the start-up and run-in phase of the meter and evaluated, in particularly with simultaneous occurrence of multiple of these threshold values. Intervention in the system for improvement of measuring conditions must be carried out when the aforementioned threshold values are reached.

Note

The operator should record the overall measurement data (meter and operating data) during the entire operation in order to be able to recognize causes of potential damage at an early stage and to intervene in good time.

Remedy and/or relief of critical operating statuses can be achieved, for example, with the following measures:

- Start-up screen (MW < 0.15 mm)
- Filter
- . Meter protection perforated plates (Ø 3 4 mm)
- . Valves with control drive (flow change)
- Check valves (pulsation, backflow)



1.4.2.6. Technical guideline G13

The installation conditions for new systems according to TRG G13 and the facilitated installation conditions for RMG turbine meters are compared in the table below.

Type of up- stream per- tubation	Installation conditions according to TR G13	Installation conditions for RMG type TME400 meters	Comments
	$\begin{array}{l} \text{Inlet} \geq 5 \text{ DN} \\ \text{Outlet} \geq 2 \text{ DN} \end{array}$	$\begin{array}{l} \text{Inlet} \geq 2 \text{ DN} \\ \text{Outlet} \geq 2 \text{ DN} \end{array}$	The outlet pipe can also be designed as a bend.
none	Inlet ≥ 10 DN		Pertubation upstream from this inlet pipe does not have to be factored in when the requirements for an alternating and puls- ing flow are fulfilled.
Bend	Inlet $\ge 5 \text{ DN}$	Inlet \geq 2 DN	
Bends in 2 planes	Inlet ≥ 5 DN plus 2 perforated plate straighteners or a bend straight- ener	Inlet ≥ 2 DN	
Gas pressure regulating device with an attenuator	Inlet ≥ 5 DN	Inlet ≥ 2 DN plus 1 perforated plate straightener	
Gas pressure regulating device without an attenuator	Inlet ≥ 5 DN plus 2 perforated plate straightener	Inlet ≥ 2 DN plus 1 perforated plate straightener	
Diffuser	Inlet ≥ 5 DN plus 1 perforated plate straightener	Inlet ≥ 2 DN	
Diffuser with swirling flow	Inlet ≥ 5 DN plus 2 perforated plate straightener	Inlet $\ge 2 \text{ DN}$	

30

.....


Perforated plate straightener

The following options are available for the straighteners:

Perforated plate straightener RMG L1 - L3 according to ISO 5167-1 and DIN 1952

Perforate plate straightener RMG LP-35



Characteristics	ISO/DIN	L1-L3	RMG LP-35
Hole diameter d	$d \le 0.05 \ D$	0.04 D	0.13 D
Plate thickness e	e≥d	e = d	0.13 D
Clearance a	$0.5 \ D \le a \le 1 \ D$	0.5 D	-
Opening ratio m	$0.2 \le m \le 0.4$	0.3	0.6
Dynamic pressure loss ∆p		5 - 15 (c² ρ / 2)	2 - 15 (c² ρ / 2)

With the RMG turbine meters, these straighteners fulfill the requirements of technical guideline G 13 and are approved with approval number D 81 / 7.211.10 for turbine meters.

1.4.2.7. Standards / guidelines

All RMG turbine meters have passed upstream perturbation measurements according to OIML recommendation IR-32/89, Annex A, with slight and heavy upstream perturbation. Therefore, this meter design fulfills the installation conditions according to technical guideline G 13, section 1. The PTB testing vol. 29 and 30, testing of volume gas meters with air at atmospheric pressure and high-pressure testing rules apply as a testing requirement. The RMG turbine meter TME400 conforms to EN12261. The measuring accuracy in the range of 0.2 Q_{max} to Q_{max} is between \pm 1.0 % to 1.5 % (see *chapter 1.4.2.9 Measuring accuracy*). The TME400 has an electronic suppression by external shut-down of the totalizer of the slow down cutoff of the turbine wheel after the flow is stopped.

31



1.4.2.8. Measuring ranges

Type TME400 turbine meters have measuring ranges of at least 1:20 at atmospheric pressure (see *chapter 1.4.2.9 Measuring accuracy*). At a higher pressure, the measuring range can be expanded to 1:50. The measuring ranges are between 2.5 and 25,000 m₃/h (operating conditions), depending on meter size.

The turbine meters with nominal diameter of DN25 and DN40 can be used up to a maximum of 16 bar. However, there may be restrictions for threaded connections that are subsequently used.





1 – Pipe fitting DIN2950

DN25 thread G 1 ½ ISO 228-1 DN40 thread G 2 ¼ ISO 228-1 DN25 / thread Rp 1 ISO 7-1 DN40 / thread Pp 1 ½ ISO 7-1

2 – Gas pipe

DN25 / thread R1 ISO 7-1 DN40 / thread R1 ½ ISO 7-1



According to DIN30690-1, the maximum operating pressure for non-flammable gases may not exceed 16 bar; for flammable gases, EN746-2 defines a maximum pressure of 5 bar for DN25 and 2 bar for DN40. Usually these pressure restrictions are specified on a plate on the pipe fittings.

1.4.2.9. Measuring accuracy

Measurement deviation in the range of DN Qmin Qmax MR Qmin-0,2 x Qmax 0,2 x Qmax-Qmax [m³/h] [m³/h] [%] [%] 2 2.5 1:10 3 25 25 3 1.5 40 6 70 1:12 80 13 160 3 1:12 1.0 50 6 100 1:16 3 1.5 80 250 1:16 3 1.0 16 25 400 1:16 3 1.0 25 400 1:16 2 100 1.0 40 650 1:16 2 1.0 3 1.5 80 13 250 1:20 400 1:20 3 20 1.5 3 100 20 400 1:20 1.5 32 650 1:20 3 1.5

The following error limits apply within the permissible measuring range:

Note

With a slightly smaller measuring range of 1:16, turbine meters are also available in nominal diameters DN 80 and DN 100, which have an increased accuracy with a deviation of max. $\pm 1\%$ in the range of 0.2 x Q_{max}-Q_{max}.

150	32	650	1:20	2	1
	50	1000	1:20	2	1
	80	1600	1:20	2	1
200	80	1600	1:20	2	1
	125	2500	1:20	2	1
250	125	2500	1:20	2	1
	200	4000	1:20	2	1

Manual TME400-VMF · EN06 · 2019 November 6th

1 Introduction



300	200	4000	1:20	2	1
	325	6500	1:20	2	1
400	325	6500	1:20	2	1
	500	10000	1:20	2	1
500	500	10000	1:20	2	1
	800	16000	1:20	2	1
600	800	16000	1:20	2	1
	1250	25000	1:20	2	1

1.4.2.10. Pressure loss

The measuring parts for determining pressure loss are 1 x DN upstream and downstream of the meter. The pressure loss is calculated according to the following formula:

$$\Delta p = Z_p \cdot \rho \cdot \frac{Q_m^2}{DN^4}$$

where:

∆р	pressure loss	[mbar]
Zp	coefficient of pressure loss	[-]
ρ	density	[kg/m³]
Qm	volume flow rate at measurement conditions	[m³/h]
DN	nominal diameter	[mm]

Device type	Zp
Turbine meter TME400	5040
Perforated plate straightener L1 according to ISO/DIN	3150
Perforated plate straightener L2 according to ISO/DIN	6300
Perforated plate straightener L3 according to ISO/DIN	9450
Perforated plate straightener LP-35 RMG standard	1260
Bend straightener RB 19 according to ISO/DIN	1260

The values for Z_p are rough averages. The exact value is calculated from the pressure loss, which is determined when testing the meter.



Example calculation for the pressure loss of a turbine meter:

TME400 in DN 150:

 $\begin{array}{ll} Q_m & = 650 \mbox{ m}^3/\mbox{h} \\ \rho & = 1.3 \mbox{ kg/m}^3 \mbox{ (natural gas at 600 mbar overpressure)} \\ Z_p(TME400) & = 5040 \mbox{ (see the table above)} \end{array}$

Calculation:

$$\Rightarrow \qquad \Delta p = 5040 \cdot 1.3 \cdot \frac{650^2}{150^4} \text{ mbar}$$
$$= 5.5 \text{ mbar}$$

1.4.2.11. Putting the device into operation

Note

You receive the TME400 parameterized and calibrated according to your specifications, so that no additionally settings are generally required.

However, check whether these settings match your specifications; check the settings of the pulse width, the frequency reducer and the settings of the current output (for versions with current output).

Bring all totalizers to the meter status which you desire. (see *chapter 4.2 Programming*).



Parameters can be changed exclusively with the device open.

1.4.2.12. Maintenance / lubrication

The TME400 is equipped with permanently lubricated bearings up to a nominal diameter of DN150 as standard. Nominal diameters of DN200 or higher are provided with an integrated lubricating device. Optionally, the TME400 can also be equipped with the "small oil pump" lubricating devices for DN25 to DN150 versions.

The type of lubricating device and the lubricant requirement depend on the nominal diameter and the pressure level:

Nominal diameter	Pressure classes	Lubricant require- ment		
DN25-DN150	All pressure classes	As necessary (see below) optional small oil pump (push-button operated)	Every 3 months 6 strokes	
DN200	All pressure classes	Small ail pump	Every 2 months	
DN250	PN10 to PN16 ANSI 150	(push-button operated)	6 strokes	
DN250	50 PN25 to PN100 ANSI300 toANSI600 Large oil pump		Every 3 months	
> DN300	All pressure classes	(lever operated)	2 strokes	

Also observe the notice plate on the housing.

In unfavorable conditions, e.g. with an accumulation of water and hydrocarbon condensate, as well as dust-laden gases, more frequent lubrication is recommended, even daily in extreme cases (e.g. with continuous condensate formation).

Note

Recommended lubricating oil:

Shell Tellus S2 MA 10 or another oil with 2 to 4°E at 25°C.



2. Installation

2.1. Electrical connections

Open the cover of the meter in order to reach the electrical connections.



Figure 3: Unscrewing the screws to open the cover

2 Installation





Figure 4: Electronics with cover of the calibration button

- 1 Jumper for RS 485 terminating resistor. Bridged: with 120 Ω ; open: $\infty \Omega$
- 2 Calibration switch
- 3 Current module board
- 4 Cover plate for pressure and temperature sensor and calibration switch
- 5 Normal position, indicated by green arrows





Figure 5: Connection assignment of the TME400

Note

Generally, no electrical connections are necessary when the turbine meter is used strictly as a flow indicator.

However, assignments are possible; the pin assignments of the TME400 are shown in in *Figure 5: Connection assignment of the TME400*. If, for example, the TME400 is to be used as a "flow sensor", the current must be connected to 4..20 mA (**terminal block X9**). The 4..20 mA current is then connected to the two terminals. For this function, the optional current module must be plugged in at the top left (see *Figure 6: Electronics with cover of the calibration button*).

The "sensor" TME400 is passive, it is fed and limits the current to the corresponding value. With this use, the current serves as an additional current supply (see *chapter 1.3.3 Power supply*). Here, care must be taken to ensure that this power supply is galvanically isolated.

If digital communication with the TME400 is required, it can be connected to the RS485. The differential signals are obtained via data lines A and B under RS485 (**terminal block X6**). Please pay attention to crossed signal lines and change the connections if appropriate. If necessary, the data interface can be conditioned using a jumper. Normally, the resistance is infinitely large ($\infty \Omega$); for a point-to-point connection or if the terminal device is part of a bus system, the resistance must be set to 120 Ω .

Via "+ Uext" (external voltage supply, positive potential) and "- Uext" (external voltage supply, negative potential) the TME400 can be fed with 6-30 VDC in addition to the internal battery (in non-Ex areas). "Earth" is used for internal voltage balance. The power supply can be independent or in combination with the RS485 interface. Anyhow, this supply voltage is required for communication via the RS485 interface.

Terminal block X6 also contains a digital input K1, which can be used to start, stop and reset the totalizer; "+Input" is the contact input for positive potential, "-Input" the contact input for negative potential. This contact input is currently not supported by the firmware.

A Caution

In the Ex version, refer to the EC type approval certificate for the maximum values for the current output and the RS 485!

Via "Pulse In" (terminal block X5), pulses proportional to the flow rate at measurement conditions can be read from an encoder with 1 or 2 frequency outputs (main encoder and second redundant encoder if required).

Encoder (sensor) 1 is connected to the terminals via "+S1" (positive potential) and "-S1" (negative potential), encoder (sensor) 2 is connected to "+S2" and "-S2". This is especially necessary for the TME400-VMF version operated at custody-transfer applications. The sensor types can be selected in coordinates Z26/27 (see chapter 4.3.3.7 Settings). Pulse input 2 is only active if a 2-channel counting mode is selected (coordinate Z25).

Via "Pulse Out2" (**terminal block X3**) pulses and redundant pulses can be output. An alarm output can also be connected here. These six terminals combine the three digital outputs:

-Alarm: Alarm output negative potential

+Alarm: Alarm output positive potential

The alarm output works according to the closed-circuit current principle. The switching contact is closed in undisturbed condition.



-Pulse 1: HF output negative potential

+Pulse 1: HF output positive potential

At this output, the arriving pulses at pulse input 1 are synchronously with a pulse width of 1 ms.

-Pulse 2: LF output negative potential

+Pulse 2: LF output positive potential

Output pulses are output at these terminals depending on the change in the volume flow rate. The pulse output factor can be used to weight the number of output pulses in relation to the increase in volume.

For the device types TME400-VC and TME400-VCF, the dependence of the pulse output on the standard volume can also be selected (see coordinates A11 and A21). In coordinate A23 the possible pulse width can be 20ms, 125ms or 250ms.

A pressure sensor can be connected to the four connections of **terminal block X8**: "+Up" positive and "-Up" negative voltage supply for pressure sensor; "RX" or "TX" are the serial data received from the pressure sensor or sent to the pressure sensor.

The temperature sensor, a Pt1000, is connected to the terminals of terminal block X11 in two-wire connection. Pressure and temperature sensors are generally only in use with the TME400-VS and TME400-VCF versions.

The terminals of the **terminal block X10** are connections for an optional module which is not yet supported by the firmware.

Use the wire end ferrules for the connecting cable and route them in from below; a seal holds the cable. To be able to pull a cable out again, press the small white square (marked with the X) down using a small screwdriver (at the bottom in *Figure 4: Electronics with cover* and *Figure 5: Connection assignment of the TME400*; top of the plug strip) in order to open the locking device. Hold down the square and pull the cable out of the connector strip.

Some connection examples are given on the following pages. Anyhow, please check for further connections the data and limitations of the connected devices in the documentations of these devices.

A Caution

The TME400 and connected devices do not have any plugs that have a to prevent polarity reversal.

Pay careful attention to the correct connections!

2 Installation



Ex version +0 P2 - RS232 -0 +n P0 - RS485 GND +0 P2 - RS485 -0 +0 DATCOM-K3 UTA sudboM A +D 42 B RS485 -a GND DIGITAL OUTPUTS 10 DIGITAL INPUTS DO4 DO3 DO3 Baudrate: 9600 / 19200 DI3 Puls 2 210 r slug HO MIBIA + GND GND GND 6V OUT + 15A DC 12V + +0 GND Power supply × GND Zusätzlicher DC DC Konverter erforderlich z. Bsp. additional DC DC converter required for example / Omron Typ / type S82S-7712 TME 400 Electronic RMG Messtechnik GmbH www.rmg.com PT 1000 ×12 0000 X1 88 4ndn+ 5 0000 25m UNIT 25+ E X5 Pulse In IS-15+ 8 t Pulses 000000 3456 Zasing . tesind + Lesind -Pulse Out WEIV -× melA EX NOVE 0 0 00000000 nu Þ Contraction of the local distance of the loc indu Note: All cables to TME 400 must be shielded. indul -1xeU -1xan + 9X HTAAE 00000000 - ILOOP dm0c. 52 8 X10 Ontio 0













3. TME400

3.1. Display field

A single-line alphanumeric display with 12 characters enables representation of the data and measurements together with the short description or the unit.



Total flow volume

Figure 7: Display field

- 1 8 characters for the value
- 3 Text: UNIT

2 Unit [m³]

4 Display arrow for volume

The LCD display and its operation are designed to save energy in order to enable battery-powered operation. The display can be impaired at temperatures below -25°C or above +60°C.



3.1.1. Display test

The display test is provided to ensure that all fields of the display function properly. For this purpose, please press and hold the up arrow and down arrow buttons (and) for more than 2 seconds. The following display appears while these buttons are held.



Figure 8: Display at display test

3.1.2. Reset

To reset the system, the voltage supply is interrupted and the TME400 is switched off for this period. For this purpose, the battery and any existing external voltage supply are disconnected. The program and operating parameters are not lost in the process and the meter statuses are saved.

3.1.3. Booting up

It may be necessary to re-boot the device in case of severe faults.



A Caution

It is necessary to remove the seals, particularly the seal over the calibration button in order to boot up (see *Figure 9: Position of the calibration button*).

The TME400 must only be used for custody transfer with unbroken seal. Removal or damage to seals normally entails considerable expenses!

Re-application of seals must only be carried out by an officially recognized inspection authority or calibration officials!

47



Figure 9: Position of the calibration button

Note

The current parameter settings and meter statuses are lost when re-booting! They are reset to standard values.

Therefore, prior to booting up, read and store all parameters of the TME400.



Proceed as follows to re-boot:

- Switch off the devices
- Press the "left ◀" and "right ▶ " buttons simultaneously
- Switch on the voltage again
- Then, the text "del All" appears in the display.
- Release the depressed buttons.
- Press the calibration button with a thin pencil or small screwdriver.
- Now the device is booted up and the display shows "Boot".
- Then, "done" appears in the display and the meter status of the main meter is displayed.

Then, re-transmit all device parameters to the TME400 or enter the values from the test certificated.

Note

The serial interface is set to 38400 Bps, 8N1, Modbus RTU after booting. These are also the default values of RMGView^{EVC} (see *chapter 4.4 RMGViewEVC*).

Manual TME400-VMF · EN06 · 2019 November 6th



3.1.4. Battery replacement

Note

The coordinate G24 (see *chapter 4.3.3.4 Error / type plate*) indicates the remaining battery capacity. If the remaining capacity falls below 10 %, a warning is generated.

```
49
```

In order to replace the battery, unscrew the large screw on the right side of the electronics with a large screwdriver or a coin.



Figure 10: Position of the battery housing

The meter is rotated in the next figure, showing the rear area in this figure below. Now, you can pull out the battery holder with battery on a handle.

The battery can be removed vertically in relation to the battery holder by pulling slightly. When installing the new battery, ensure that the polarity is retained for the new battery.



\Lambda Danger

The battery must only be replaced in a non-explosive atmosphere. Ensure that the electronics are supplied with adequate ventilation with fresh air.



Figure 11: Battery holder

Note

The battery can be changed during operation.

- All readings of the counter(s) and all counting parameters are retained.
- After changing the battery, the current time and date must be entered again (coordinates X01 and X02; see *chapter 4.3.3.6 Archive*). In addition, the battery change must be indicated in coordinate G25. This updates the battery change date and sets the operating hours G26 to 0 and the battery capacity G24 to 100 %.
- The current flow rate value is not stored during the change because there is no additional battery buffering.



Note

You can also have the battery replaced by the RMG Service department; please contact RMG for this purpose (see page 2). Please only use the battery types intended by RMG.

51



4. Operation

4.1. Operation concept



Figure 12: Front panel

The concept of the operation is simple and easy to implement with knowledge of the coordinates.

4.1.1. Coordinate system

All configuration data, measurements and computed values are sorted in a table in a coordinate system which enables easy access. The coordinate system is divided into several columns, as shown on, in part, on the front panel (see *top* and *bottom*).



Figure 13: 8 columns of the coordinate system

Note	53
With the TME400-VM and TME400-VMF turbine meters, the p/T and Calc. columns cannot be selected.	

With the cursor buttons (arrows)



you can reach each value by gently pressing the desired button in this coordinate system.

Keypad	Description	Effect
	Left arrow	Switches the column of the table from right to left
	Up arrow	Upward movement within the column of the table: You move from the last value of the list towards the first value. This is also used to adjust numbers (counting up).
▼	Down arrow	Downward movement within the column of the table: You move from the first value of the list towards the last value. This is used to adjust numbers (counting down).
	Right arrow	Switches the column of the table from left to right
OK	Function	The following functions are triggered by pressing: pressed < 2 seconds = display of the coordinate pressed > 2 seconds = shows the coordinate pressed > 2 seconds = switch to settings mode (see below)



4.1.2. Display and coordinate system

The main meter is displayed in normal operating mode. The other display values can be selected with the operating buttons. After approx. 1 minute, the TME400 switches back to the main meter.

If the display is dark, the TME400 is in energy-saving mode, where the display is completely switched off. The incoming pulses are processed, and the outputs are actuated.

The display value is shown again by pressing any operating button.

Any arbitrary position in the coordinate system, which is identified by letters and numbers, can be reached with the arrow keys.

	Α	В	С	D	E	F	G	Н	X	Υ	Ζ
01											
02						F02					
03											
04								Examp	le		
05											
06											
07											

Example:

F02 Current mode. The current output can be configured here.

4.1.3. Parameter protection

Note

All custody-transfer parameters are protected by the (sealed) calibration button.

There are different access authorizations for the parameters with which unauthorized changes are suppressed. The different access rights are assigned to the coordinates by a letter. They are shown in the coordinate list. The following access levels are used:



Access level	Access right	
А	Display values, change not possible	
Ν	Parameter for which no password is necessary for use	
С	Code word Entry of a code word is necessary to change the parameter.	
E	Calibration button Custody-transfer variant TME400-VMF: Custody-transfer display values / parameters, use of the calibration button is necessary. Non-custody-transfer variant TME400-VM: Entry of the code word is adequate.	
	Note	
	Enabling or disabling the code word or opening the calibration button creates an entry in the event archive (see below).	

4.2. Programming

There are five buttons available on the front foil for programming of the TME400. Alternatively, you can carry out programming via the RMGView^{EVC} operating software (see *chapter 4.4 RMGViewEVC*).

4.2.1. **Programming with the programming buttons**

Basically, you proceed as follows for the programming:

- First check the protection status of the coordinate. When parameters are not protected, you can carry out changes, as described below without additional measures.
- With parameters protected by code word, you must enter it first in coordinate Z15. Please read how to make the entry as below.



• With parameters protected for custody-transfer applications, you must press the calibration button first.

A Caution

It is necessary to remove the seals, particularly the seal over the calibration button in order to press the calibration button (see *Figure 9: Position of the calibration button*).

The TME400 must only be used for custody transfer with unbroken seal. Removal or damage to seals normally entails considerable expenses!

Re-application of seals must only be carried out by an officially recognized inspection authority or calibration officials!

The principle of the programming is shown based on the example of changing the output pulse factor:

- I. Move with the arrows (
- II. Activate the calibration button (see Figure 9: Position of the calibration button)
- III. The blinking "INPUT" text appears above the displayed value in the display view.
- IV. Press **OK** for more than 2 seconds
- V. The value begins to blink at a position
- VI. With the A and A arrows, you can now increase or decrease the value at this position. For the values, after the "0", you also have "-1" available in order to enter negative values, if necessary.
- VII. With the <a>And and <a>And arrows, you can move to a different position of the value and change it as described in the point above.
- VIII. An additional position is added when you move with the and before the displayed number. For example, only the units digit is displayed. If you move in front of it, you will also have the tens position available as an entry.
 - IX. By pressing and holding the "right" button \triangleright , the position of the decimal point is changed. After pressing and holding, the decimal point is inserted after the blinking digit.
 - X. By pressing and holding the "left" button , the entry can be canceled. If a change and/or entry is necessary, the entry must be restarted.
 - XI. When you have finished making an entry, you confirm it by briefly pressing OK



- XII. A plausibility check takes place and the result is displayed immediately.
- XIII. If this check shows an implausible entry, "rAnGE" will be shown briefly in the display and the display jumps back to the original value.
- XIV. If this check shows a plausible entry, "Good" will be shown briefly in the display and the value is adopted as a new value.
- XV. Now you can if necessary change other parameters.
- XVI. After about 1 minute without additional entries, the display returns to the display of the main meter.
- XVII. By pressing the calibration, you close the further entry of custody-transfer parameters.
- XVIII. After another minute without an entry, the change possibility is closed automatically.

Note

Some of the coordinates permit other settings as purely numerical values. However, these other entries are assigned numbers so that the adjustment can be carried out as described.

Example:

Current mode F02 can be deactivated or activated on various settings. This is adjusted as follows:

0	Off (default)
1	No errors
2	Error 3.5 mA
3	Error 21.8 mA
4	0 - 20mA

If F02 = "0" is selected for the coordinate, the current output is switched off.

Note
With some coordinates, a number is assigned fixed values. Instead of an adjustment with 0, 1,, these numerical values are shown directly. Changes are possible with the arrows and , then the next higher or lower value is shown and can be adopted with OK.



Example:

Digital output 2 pulse width (coordinate A22) can adjust the pulse width to 3 different widths. The following values can be directly as an assignment:

20 ms	
125 ms	
250 ms	

58



4.3. Equations in the TME400

The TME400 enables calculation of different values from the measured data and in the data entered in the TME400. For a better understanding, some variables and formula in this chapter are presented in advance; other equations and definitions of parameters are found in the *chapter 4.3.3. Coordinates in context.*

Formula symbol	Units	Name
q_m	m³/h	Operating volume flow at measurement condition
fv	Hz	Frequency of the volume transmitter
K_V	I/m ₃	Meter factor
V_m	m ³	Operating volume flow rate at measurement condition
P_V	Nondimensional (1)	Volume pulse
Kz1	m ³ /l	Meter factor (only for output contacts)
K _{Z2}	m ³ /l	Meter factor (only for output contacts)

4.3.1. Variable description

4.3.2. Standard formula

Variables presented from the previous chapter can be used for the basic equation for the volume flow at measurement conditions:

$$V_m = \frac{P_V}{K_V} \frac{1}{K_{Z1}}$$

(Volume flow at measurement conditions $= \frac{Number of pulses}{Meter factor x Totalizer factor}$)



60

4.3.3. Coordinates in context

In the following, the coordinates which can be addressed with the TME400-VM and TME400-VMF turbine meters are shown. In the tables, the parameters which can be addressed with the TME400-VM are shown in light blue and the values which are **ad-ditionally** available with the version for custody-transfer applications, TME400-VMF, are shown in orange.

TME400-VM	Non-custody-transfer applica- tions
TME400-VMF	Custody-transfer applications

4.3.3.1. Volume / Meters

Coordi-	Name	Description
nate		
A02	Operating volume	Volumes added up at current (temperature and pressure) conditions.
A05	Uncorrected operating volume	Z26: If the characteristic correction is deactivated, A05 is not visible and cannot be adjusted. If a characteristic correction is activated, this characteristic curve correction is deactivated from 0 up to this value A05.
A06	Volume Start/Stop	Starts and stops a volume flow measurement
A07	Volume Reset	Sets the volume flow rate to 0
A10 Meter factor		With the meter factor (pulse value), the corresponding operating value flow is calculated from the signal frequency of the sensor element in the meter electronics. $q_m = \frac{f_V}{K_V} * 3600 [\frac{m^3}{h}]$ The meter factor must be calibrated at the factory so that a direct meter display in cubic meters.
		Note
		A change of this adjustment takes place in the responsibil- ity of the operator.
		After any change to the meter factor, calculation takes place with the new value immediately.
		The uninfluenced signal frequency of the sensor element is available at the HF output. The frequency range can be determined from the

		meter fac	ctor K and the minimum and maximum operating volume
		tiow of tr	ie meter according to the formula:
			$f_{V \min} = \frac{q_{m \min}}{3600} * K_V f_{V \max} = \frac{q_{m \max}}{3600} * K_V$
		qm min: qm max:	minimum operating volume flow maximum operating volume flow
		Example	:
		(<i>q_{m min}</i> = 16 m3/h
		(<i>q_{m max}</i> = 250 m3/h
		I	$K_V = 2362 \text{ pulses/m3}$
			$f_{V \min} = \frac{16}{3600} \frac{m^3}{s} \cdot 2362 \frac{\text{Impulse}}{m^3} = 10,5 \text{ Hz}$
			$f_{V \max} = \frac{250}{3600} \frac{m^3}{s} \cdot 2362 \frac{\text{Impulse}}{m^3} = 164 \text{ Hz}$
A11	Output pulse factor	The outp spond to	out pulse value indicates how many LF output pulses corre- one m3 (1 m ³).
A20	Display factor	A20: Dis	splay factor for meters, including decimal places
		0.01	(i.e. display with 2 decimal places)
		0.1	(i.e. display with 1 decimal place)
		1	(default) (display without decimal places)
		10	(display without decimal places)
		100	(display without decimal places)
		Example If the fac decimal	e: tor is adjusted to 0.1, the meter status is displayed with one place.
		Note	
		If the fais disp	actor is adjusted, for instance, to 10, the display value layed without a decimal place.
		You ge	et the <u>actual</u> meter status by multiplying the display
		This se marked	etting is marked with a "x 10" sticker (or it must be d).





A22	Digital output 2 pulse width	20 ms 125 ms (default) 250 ms
A12	Meter factor corrected	The meter can be adjusted by the operator, e.g. during calibration. This value does not change.

62

.....

Coor- dinate	Name	Modbus register	Modbus access	Protec- tion	Data type	Min.	Max.	Default	Unit
A02	Operating volume	302	W	Е	unit32	0	99999999	0	m3
 A05	Uncorrected operating volume	308	W	Е	unit32	0	999999999	0	m3
 A06	Volume Start/Stop	310	W	Ν	unit32	0	99999999	0	m3
A07	Volume Reset	312	W	Ν	unit32	0	99999999	0	m3
A10	Meter factor	500	W	Е	string12	*	*	1000.0	l/m3
A11	Output pulse factor	506	W	Е	float	0.01	100	1.0	l/m3
A20	Display factor	510	W	Е	menu16	0	4	2	
A22	Digital output 2 pulse width	512	W	N	menu16	0	2	1	ms
A12	Meter factor corrected	508	R	Α	float	-	-	1.0	I/m3

4.3.3.2. Flow rate

Coordi- nate	Name	Description
B02	Operating flow rate	Flow rate under current operating conditions
B03	Frequency	Unchanged output value, frequency of Sensor 1.
B05	Min. flow rate	an alarm is generated below this flow rate
B06	Max. flow rate	an alarm is generated above this flow rate
B10, B11, B12, B13; B14;	Coefficients: A-2, A-1, A0, A1, A2	 Z26: If the characteristic correction is deactivated, the additional parameters are not visible and cannot be adjusted. If a characteristic correction is activated (see Z26 below), a correction takes place with the factors in: B10: Factor for the characteristic correction B11: Factor for the characteristic correction B12: Factor for the characteristic correction B13: Factor for the characteristic correction B14: Factor for the characteristic correction
B15	Max. operating point deviation	B15: If the deviation of the corrected from the uncorrected character- istic at an operating point (or a range) is more than the adjusted value (2% here), the correction, is set to "0" for this operating point or operating range, which means a correction takes place.
B08	Leak flow volume limit	The flow rate is disregarded below this leak flow volume limit - i.e. it is set to 0



B09	Maximum time > Qug +	Indicates the maximum time until the flow rate (e.g. on start-up)
		reaches the measuring range (Qmin) after reaching the lower meas-
		uring limit (Qug). The flow rate measurement applies as defective
		during this time, but no error message is generated.

Coor-	Name	Modbus	Modbus	Protec-	Data	Min.	Max.	Default	Unit	63
dinate		register	access	tion	type					
B02	Operating flow rate	320	R	А	float	-	-	*	m3/h	
B03	Frequency	322	R	А	float	-	-	*	Hz	
B05	Min. flow rate	521	W	E	float	*	*	0.0	m3/h	
B06	Max. flow rate	523	W	E	float	*	*	1000.0	m3/h	
B10	Coefficient A-2	530	W	E	float	*	*	0	Am2	
B11	Coefficient A-1	532	W	E	float	*	*	0	Am1	
B12	Coefficient A0	534	W	E	float	*	*	0	A0	
B13	Coefficient A1	536	W	E	float	*	*	0	A1x10 ⁻⁴	
B14	Coefficient A2	538	W	E	float	*	*	0	A2x10 ⁻⁸	
B15	Max. operating point de- viation	540	W	E	float	0.0	100.0	2.0	kkp	
B08	Leak flow volume limit	527	W	E	float	*	*	*	m3/h	
B09	Maximum time > Qug +	529	W	E	unit16	0	10000	10	S	

4.3.3.3. Current output

Coordi- nate	Name	Description						
F01	Current	Current to be output						
F02	Current mode	0 Off (default)						
		1 No errors						
		2 Error 3.5 mA						
		3 Error 21.8 mA						
		4 0 - 20mA						
		If the current mode is "0", meaning "Off", in apart from parameter F02: current mode, no additional parameters of the output are visible or adjustable.						
F03	Current source	0 Specification (default)						
		1 Operating flow rate						
		2 Frequency						
		3 Calibration 4mA						
		4 Calibration 20mA						



F04	Phys. minimum value	Current output phys. minimum (required for display in RMGView ^{EVC})
F05	Phys. maximum value	Current output phys. maximum (required for display in RMGView ^{EVC})
F06	Current specification	Specification value for the current output (for testing purposes)
F07	Current moderation	The current output is damped by averaging. A value of 0 corre- sponds to no damping. A value of 0.99 causes strong averaging.
F10	Calibration value 4mA	Calibration: Current value 4mA (after activation of current source)
F11	Calibration value 20mA	Calibration: Current value 20mA (after activation of current source)
F12	Module serial number	Serial number of the current module

Coor- dinate	Name	Modbus register	Modbus access	Protec- tion	Data type	Min.	Max.	Default	Unit
F01	Current	330	R	Α	float	-	-	-	mA
F02	Current mode	657	W	Ν	menü16	0	4	0	
F03	Current source	658	W	Ν	menü16	0	7	0	
F04	Figure below	659	W	Ν	float	-	-	0.0	
F05	Picture above	661	W	Ν	float	-	-	1000.0	
F06	Current specification	663	W	Ν	float	0.0	25.0	12.0	mA
F07	Current moderation	665	W	Ν	float	0.1	1.0	1.0	I-D
F10	Calibration value 4mA	667	W	Ν	float	0.0	25.0	4.0	mA
F11	Calibration value 20mA	669	W	Ν	float	0.0	25.0	20.0	mA
F12	Module serial number	671	W	Ν	string8	-	-	0000 0000	SN

4.3.3.4. Error / type plate

Coordi- nate	Name	Description
G01	Current error	Identifies the current error
G02	Software version	Shows the version number of the firmware in the TME400.
G04	Serial number	Serial number of the TME400
G05	Firmware checksum	Shows the checksum of the firmware (important for TME400-VMF and TME400-VCF in custody-transfer applications)
G06	Measuring point	Possibility of numerical identification for the measuring point
G18	Meter number	Number of the turbine meter
G21	CRC metrological Param. EEprom	CRC of metrological parameters EEprom
G23	Date of Battery Exchange	Date of battery exchange



G24	Remaining Battery Capacity	Remaining capacity of the battery	
G25	Battery Change	0No (default)1Yes	
G26	Operating Hours	Operating hours	
G19	Meter size	Meter size (G)	65
G20	Date of last battery re- placement	Shows the date of the last battery replacement	

Coor- dinate	Name	Modbus register	Modbus access	Protec- tion	Data type	Min.	Max.	Default	Unit	
G01	Current error	675	R	Α	unit16	-	-	0	ERR	
G02	Software version	676	R	Α	float	-	-	*	Rev	
G04	Serial number	680	W	E	int32	0	99999999	01	SNo	
G05	Firmware checksum	682	R	Α	int16	-	-	*	CRC	
G06	Measuring point	314	W	Α	unit32	*	*	0	Rev	
G18	Meter number	699	W	E	int32	*	*	9999 9999	MNo	
G21	CRC metrological Param. EEprom	804	R	Α	string8	-	-	CALC	Hex	
G23	Date of Battery Exchange	705	W	С	string8	-	-	010117	Bat	
G24	Remaining Battery Ca- pacity	790	R	Α	unit16	-	-	100	%	
G25	Battery Change	791	W	С	menü16	0	1	0	-	
G26	Operating Hours	792	R	Α	unit32	-	-	0	h	
G19	Meter size	701	W	E	string8	*	*	4-16000	G	
G20	Date of last battery re- placement	705	W	С	int32	*	*	0101 2014	Bat	

4.3.3.5. RS-485 interface

Coordi- nate	Name	Description
H01	RS-485 Baud rate	2400 Bps
		9600 Bps
	192	19200 Bps
		38400 Bps (default)
1.100		
HUZ	RS-485 parameter	0 8N1 (default)
		1 8E1
		2 801

.....



		3	7N1				
		4	7E1				
		5	701				
H03	RS-485 protocol	0	Off				
		1	Modbus RTU (default)				
		2	Modbus ASCII				
H04	Modbus ID	Modbus device address (default = 1).					
H05	Modbus register offset	The offset is defined as 1 by RMG.					

Coor- dinate	Name	Modbus register	Modbus access	Protec- tion	Data type	Min.	Max.	Default	Unit
H01	RS-485 Baud rate	709	W	Ν	menu16	0	3	3	Bps
H02	RS-485 parameter	710	W	Ν	menu16	0	5	0	
H03	RS-485 protocol	711	W	Ν	menu16	0	2	1	
H04	Modbus ID	712	W	Ν	unit16	1	250	1	MID
H05	Modbus register offset	713	W	Ν	unit16	0	10000	1	Mof

4.3.3.6. Archive

Coordi- nate	Name	Description
X01	Time	Direct entry of the current time as described above.
X02	Date	Direct entry of the current date as described above.
X10	Delete parameter ar- chive	0 No (default) 1 Yes
X11	Parameter archive fill level	Display value
X14	Delete event archive	0No (default)1Yes
X15	Event archive fill level	Display value
X16, X17.	Measurement archive mode	0Off (default)1On
X18, X19, X20, X21, X22,		If measurement archive mode is activated, the following archives are visible and can be adjusted and deleted as necessary.
X23		X17 interval015 minutes (default)130 minutes
4 Operation



		1		
			2 60 minutes	
		X18 delete	0 No (default)	
			1 Yes	
		X19 fill level	Display value	
		Day archive		67
		X20 delete	0 No (default)	
			1 Yes	
		X21 fill level	Display value	
		Month archive		
		X22 delete	0 No (default)	
			1 Yes	
		X23 fill level	Display value	
X24	Delete all Archives	All archives		
		X24 delete	0 No (default)	
			1 Yes	
X12	Delete parameter ar-	0 No (default)		
	chive (E)	1 Yes		
X13	Parameter archive (E) fill level	Display value		

Coor- dinate	Name	Modbus register	Modbus access	Protec- tion	Data type	Min.	Max.	Default	Unit
X01	Time	712	W	E	string8				Т
X02	Date	717	W	E	string8				D
X10	Delete parameter archive	722	W	Е	menu16	0	1	0	
X11	Parameter archive fill level	723	R	Α	unit16	-	-	0	%
X14	Delete event archive	726	W	Е	menu16	0	1	0	
X15	Event archive fill level	727	R	Α	unit16	-	-	0	%
X16	Measurement archive mode	728	W	Е	menu16	0	1	0	
X17	Minute archive interval	729	W	E	menu16	0	2	0	
X18	Delete minute archive	730	W	E	menu16	0	1	0	
X19	Minute archive fill level	731	R	Α	unit16	-	-	0	%
X20	Delete day archive	732	W	E	menu16	0	1	0	
X21	Day archive fill level	733	R	Α	unit16	-	-	0	%



4 Operation

.....

	X22	Delete month archive	734	W	E	menu16	0	1	0	
	X23	Month archive fill level	735	R	Α	unit16	-	-	0	%
	X24	Delete all archives	812	W	Е	menu16	0	1	0	
	X12	Delete parameter archive (E)	724	W	Е	menu16	0	1	0	
68	X13	Parameter archive (E) fill level	725	R	Α	unit16	-	-	0	%

The sizes of the archive are:

Event archive	200 Entries
Parameter archive (custody transfer)	300 Entries
Parameter archive (non custody transfer)	300 Entries
Month archive	25 Entries
Day archive	100 Entries
Periodic archive	9000 Entries

4.3.3.7. Settings

Coordi- nate	Name	Description
Z04	X:Y maximum pulse error	A differential circuit compares the metered pulse of measuring and comparison channels alternatingly. Every deviation is counted inter- nally. An alarm is generated if the adjusted limit value is exceeded. The failure counter is reset to 0 for each new measurement or after the maximum number of pulses (Z05) is reached.
Z05	X:Y maximum pulse	see above
Z10	Error register 1	Display value
Z11	Error register 2	Display value
Z12	Status register 1	Display value
Z13	Status register 2	Display value
Z15	Code word release	Note The code word for the TME400 is: 1 2 3 4 This is always displayed as " **** " in the parameter archive. With entry of this code word, the protected parameters can be changed.
Z16	Change code word	A new password can be defined here.

4 Operation



Z17 Z24	Device type Display active max.	 0 TME400-VM (default) 1 TME400-VC 2 TME400-VMF (MID) 3 TME400-VCF (MID) 0 1 minute (default) 1 5 minutes 2 60 minute test The time during which the display is active for tests is selected as)))))		
		60 minutes. In general, however, it must be observed that higher energy consumption is associated with this time, so this time should be selected as short as possible, if possible.			
Z25	Volume metering mode	 1-channel without errors (default) 1-channel stop on error 1-channel run on error 1-channel start / stop 1-channel start / stop 1-channel reset 2-channel stop on error 2-channel run on error 2-channel run on error 2-channel without X:Y error 1 Channel Start/Stop Mode 2 With 1-channel measurements (0, 1, 2, 3, 4), the Z04 and Z05 pulse comparison is not activated. An entry for sensor type 2 is superfluous and has no further significance. Volume metering mode 8: 1 Channel Start/Stop Mode 2 If the external contact input 3 is closed (or opened), this additional mode 2 triggers a start (or stop) for the start/stop totalizer during this time. The LF output and the current output are deactivated for this period (4 mA) and no pulses are output (main totalizers stop). In case of an error, the pulses are counted in the error totalizers and current and pulses are output.			
Z26	Characteristic correc- tion	If the TME400 is supplied with a current supply, the TME400 ena- bles a characteristic correction via a polynomial. This correction must be activated with coordinate Z26. With this polynomial correc- tion, the corresponding percentage deviations of the turbine meter from a reference standard are determined for fixed percentage flow rate values. From these deviations, a polynomial function which ide- ally reflects the curve running through these points is calculated. The coefficients of the polynomial A-2, A-1, A0, A1 and A2 are adjusted by the manufacturer in the coordinates B10 to B14 or can be entered			



		there when the manufacturer of the turbine meter provides these values. Note The HF output pulses (X3 pulse 1) are always uncorrected! With an active characteristic curve correction, no HF pulses are output.
		0 Off (default) 1 On
Z27	Sensor type 1	 0 Reed sensor 1 Wiegand sensor (default) 2 External
Z28	Sensor type 2	Settings are possible, but only make sense in 2-channel operation. Settings changed here have no effect in 1-channel operation, 0 Reed sensor 1 Wiegand sensor (default) 2 External
Z29	Volume unit	0 m3 (Default) 1 cf

.....

Coor- dinate	Name	Modbus register	Modbus access	Protec- tion	Data type	Min.	Max.	Default	Unit
Z04	X:Y maximum pulse error	775	W	E	unit16	1	10000	10	Х
Z05	X:Y maximum pulse	776	W	E	unit16	1	10000	10000	Y
Z10	Error register 1	332	R	Α	int16	-	-	*	Err
Z11	Error register 2	333	R	Α	int16	-	-	*	Err
Z12	Status register 1	334	R	Α	int16	-	-	*	Sta
Z13	Status register 2	335	R	Α	int16	-	-	*	Sta
Z15	Code word release	777	W	Ν	unit16	1	9999	0	COD
Z16	Change code word	778	W	С	int16	1	9999	1234	C-V
Z17	Device type	779	W	E	menu16	0	3	0	
Z24	Display active max.	780	W	Ν	menu16	0	2	0	
Z25	Volume metering mode	781	W	E	menu16	0	7	0	
Z26	Characteristic correction	782	W	E	menu16	0	1	0	
Z27	Sensor type 1	783	W	E	menu16	0	2	1	

	RMG							4 Oper	ation	
Z28	Sensor type 2	784	W	E	menu16	0	2	1		
Z29	Volume unit	785	W	E	menu16	0	1	0		
	Note									
	If the parameter is not dimensioned, the text in the "Unit" column is shown in the display of the TME400 to the right under UNIT.						n in	71		



4.4. RMGView^{EVC}

The RMGView^{EVC} software also provides an additional possibility of parameter input. This software offers you additional options in combination with the TME400.



Figure 14: RMGView^{EVC} software

For further details, please read the corresponding manual, which can be downloaded from our home page (*see page 2*).



5. Technical data

5.1.1. Device types

Reed or transistor (with connected turbine meter)					
Pulse input	Reed or transistor	73			
Current output	Itput Current loop connection (current supply via this current output possible)				
Wiegand (with connected turbine meter)					
Use	Direct installation on the TME400 turbine meter instead of the meter head				
Pulse input	Wiegand				
Current output	Current loop connection (current supply via this current output possible)				

5.1.2. Inputs

Volume	
Reed	
Pulse frequency	0 Hz 4 Hz
Pulse width	≥ 20 ms
Voltage	low: $\leq 0.9 \text{ V}$ high: $\geq 2.2 \text{ V}$
Wiegand	
Pulse frequency	0 Hz 400 Hz; with battery operation
Pulse width	$\geq 5 \ \mu s$
Voltage	min. 1 V max. 5 V (determined by sensor)

5.1.2.1. Power supply

Power supply	
Internal battery	Lithium cell 3.6 V; in the device (battery pack)
External 24 V DC	via Uext + battery pack
External 10.5 V DC	via RS-485 + battery pack
External 24 V DC	via current loop connection + battery pack



5.1.2.2. Pulse In measuring inputs (sensor 1 / 2)

Note

74

For Ex connection values, see approval.

The cable length to the Wiegand sensor must not exceed 15 m.

5.1.3. Outputs

The values for the HF, LF and alarm output can be taken from the certificate.

5.1.4. Data interface

RS-485 data interfac	e
Umin	6.0 V
Umax (Ui)	10.5 V
Imax	428 mA
Pi	900 mW
internal inductivity	1320 LF
internal capacity	600 µH

A Caution

A voltage of U_{max} (U_i) higher than 10.5 V will destroy the data interface.

Note

The device has to be supplied with power via the data interface when the RS-485 interface is used.

Note

In an Ex version, the connection must only be made to a certified, intrinsic safe current circuit.

The Ex-relevant connection values are specified in the approval.



Current loop connection 5.1.5.

Current loop connection		
Uext (min)	12 V	
Uext (max)	28 V	
Imin	3.5 mA	
Imax	23 mA	
External resistance (max.)	See: Figure 1	5: Load depending on feeder supply
Current output for		
- minimum flow rate		4 mA
- maximum flow rate		20 mA
- alarm		3.5 mA or 21.8 mA
Current output acouroov botto	r than 10/ of the	and value

Current output accuracy better than 1% of the end value



Bürde in Abhänigkeit Geberspeisung Load depending on feeder supply

Figure 15: Load depending on feeder supply

Data for use in haza	rdous areas (Ex)
Ui	28 V
li	110 mA
Pi	770 mW
Ci	2.2 LF
Li	110 μH

5.1.6. Cable

76

Signal cables (LF output, HF output, current loop connection, control input) must have 2 or more wires twisted in pairs and shielded (LiYCY-TP).

2-wire, twisted and shielded cables (LiYCY-TP) must be used for the data cables (RS-485).

The shielding must be grounded on both ends - on the TME400, as described in the *section 5.1.7 Cable connection*.

Cable cross-sections of 0.5 mm² are recommended. Due to the cable screw connection, the outer diameter of the cable must be between 4.5 and 6.5 mm.

Caution
 The maximum cable length is limited when used in hazardous areas due to
 the limit values for intrinsically safe current circuits and depending on the in ductivity and capacity of the cable.

5.1.7. Cable connection

Connect the shield on both ends to the cable screw connections on the outside of the housing, as shown in the figure below:

- Unscrew the union nut.
- Pull the terminal insert out of the plastic.
- Slide the cable end through the union nut and the terminal insert and bend the shielding back.
- Plug the terminal insert back into the connecting piece.
- Tighten the union nut.
- Every Ex signal circuit must be routed with a dedicated cable which must be guided through the appropriate PG screw coupling.







Figure 16: Terminal screw connection

- 1
- Coupling nut Terminal insert 2

- 3
- O-ring Connecting piece 4



5.1.8. Ground

Note

To avoid measuring errors due to electromagnetic interference, the meter housing <u>must</u> be grounded with the ground connection on the right section of the housing (see *Figure 17: Grounding the meter*).

Minimum cable cross-section:

- length of up to 10 m: 6 mm²
- length of 10 m or higher:10 mm²



Figure 17: Grounding the meter

In the process, a conductive connection between the TME400 and the pipeline must be provided as shown in the figure below.





Figure 18: Grounding with the connecting pipes

- Equipotential bonding conductor (PE) min. 6 mm² Measuring system potential 1
- 2



5.2. Overview of materials in use

Name	Material
Housing	Cast iron, cast steel, stainless steel, aluminum or welded steel
Flow straightener	Delrin, aluminum or steel
Turbine wheel	Delrin or aluminum
Measuring unit	Aluminum
Ball bearings	Stainless steel
Shafts	Stainless steel
Gear wheels	Stainless steel or plastic
Magnetic coupling	Stainless steel
Meter head	Plastic
Meter printed circuit board	Aluminum, zinc die-casting or brass

80



6. Error messages

Error messages are shown in the display as an error number and "unit" "Err".



Figure 19: Error message in the display

The message types are:

E = ErrorW = Warning H = Hint

There are the following error messages:

Message	Error	Brief description	Comment
type	no.		
E	1	EEprom version error	Contact RMG service.
E	2	EEprom error	Contact RMG service.
E	8	Flow rate min/max error	Check the alarm setting for the flow rate.

RMG

6 Error messages

82

.....

E	9	X:Y pulse comparison error	Check the alarm setting for the pulse comparison.
E	10	Max. output pulse error	Check the alarm setting for the max. output pulse.
E	11	Current output error	Check your current connections. Contact RMG service in case of uncertainty.
Е	12	Error CRC Calibration Parameter	Contact RMG service.
14/	101	Morris & Dottory Conscitutory	Discos shores the hotton.
W	101	Warning Battery Capacity low	Please change the battery
W	101	Warning Battery Capacity low	Please change the battery
W	101 201	Warning Battery Capacity low New software version	Please change the battery You have a new firmware version
W H H	101 201 202	Warning Battery Capacity low New software version Metrology switch open	Please change the battery You have a new firmware version Metrology switch open



Appendix

A Modbus

The TME400 has a passive RS-485 interface, which means the interface must be supplied with power externally.

Parameterizing the Modbus

Modbus activation

H03 RS-485 protocol

0	Off
1	Modbus RTU (default)
2	Modbus ASCII

The Modbus - ID is adjusted via the coordinate H04 (default is 1)

The **Modbus - Register - Offset** (MRO) is entered via coordinate H05 (default is 1). The MRO applies for read and write operations.

Baud rate

H01 Baud rate RS-485 interface

0	2400 Bps
1	9600 Bps
2	19200 Bps
3	38400 Bps (default)

Interface parameters

The interface parameters can be adjusted in coordinate H02. H02 RS-485 interface parameters

0	8N1 (default)
1	8E1
2	801
3	7N1
4	7E1
5	701



The TME400 recognizes the following Modbus commands:

- (03 Hex) Read Holding Registers
- (06 Hex) Preset Single Register
- (10 Hex) Preset Multiple Regs
- (08 Hex) Subfunction 00 Hex: Return Query data

TME400 Exception Codes

- 01 Illegal Function
- 02 Illegal Data Address (register not available)
- 03 Illegal Data Value (register not writable or incorrect value)

Example (Modbus query/response):

Query:	Send character	
Start Char	:	
Slave Address	01	
Function	03	
Starting Address Hi	07	
Starting Address Lo	CF	2000-1
No. of Points Hi	00	
No. of Points Lo	02	
LRC	24	
carriage return	cr	
line feed	lf	
line feed	lf	

Response:	Receive character	
Start Char	:	
Slave Address	01	
Function	03	
Byte Count	04	
Data Hi (Reg 2000)	3F	see below
Data Lo (Reg 2000)	80	see below
Data Hi (Reg 2001)	00	see below
Data Lo (Reg 2001)	00	see below
LRC	39	
carriage return	cr	
line feed	lf	



Example (Modbus number formats)

Data type	Reg- ister	Value	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8	Byte 9	Byte 10
float	2	1.0	0x3f	0x80	0x00	0x00						
Text	5	"90111200"	0x39	0x30	0x31	0x31	0x31	0x32	0x30	0x30	0x00	0x00
int	1	1357	0x05	0x4d								
long	2	698614	0x00	0x0a	0xa8	0xf6						

Refer to the Modbus specifications for further information.

Characteristics of the TME400 Modbus

- Data types (float, text ...) can only be read or written completely

menu16	:	1 Register
int16	:	1 Register
unit16	:	1 Register
int32	:	2 Register
unit32	:	2 Register
float	:	2 Register
string8	:	4 Register
string12	:	6 Register
Text	:	5 Register
Mon-buffer	:	15 Register

- A maximum of 125 registers can be read or written (in one command)..
- Text fields must have at least one terminating zero (0x00).
- Writing of certain parameters causes internal initialization of the hardware and/or:
 - Deletion of intermediate results (pulse output, meter calculation, etc.).
 - Therefore, the parameters should only be overwritten as necessary (e.g. meter factor)
 - Meter statuses are delivered as a unit32 value (without decimal)

Modbus - Register (Version:0.001; Matrix: 001; June 2018)

	MB reg	Reg. numbe	Data r type	MB acce	SS	Coordina	ite	Name	A	Access	U	Init	Des	scription
	302	2	unit32	2 RW		A02		Volume Mea- surement	E	E	&	VolumeUnit	Volu	ume at measure- nt conditions
86	306	2	unit32	2 RW		A04		Volume Mea- surement Error	E	E	&	VolumeUnit	Volu	ume at meas. ditions error
	308	2	unit32	2 RW		A05		Volume Mea- surement un- cor.	E	E	&	VolumeUnit	Volu mer corr	ume at measure- nt conditions un- rected
	310	2	unit32	2 RW		A06		Volume Start/Stop	Ν	1	&	VolumeUnit	Volu	ume Start/Stop
	312	2	unit32	2 RW		A07		Volume Reset	Ν	1	&	VolumeUnit	Volu	ume Reset
	314	2	unit32	2 RW		G06		Metering Point	E	E		-	Nar	ne of met. point
	MB reg	Reg. numbe	Data r type	MB acce	SS	Coordina	te	Name		Acces	S	Unit	Desci	iption
	320	2	float	R		B02		Flow Rate Mea- surement		A		&FlowUnit	Flow r ment	ate measure-
	322	2	float	R		B03		Frequency		А		Hz	Frequ	ency
	330	2	float	R		F01		Current		А		mA	Curre	nt to be output
	332	1	unit1	6 R		Z10		Error Register 1		А		Hex	Error	register 1
	333	1	unit1	6 R		Z11		Error Register 2		А		Hex	Error	register 2
	334	1	unit1	6 R		Z12		Status Register 1		А		Hex	Status	s register 1
	335	1	unit1	6 R		Z13		Status Register 2	2	А		Hex	Status	s register 2
	MB reg	Reg. number	Data type	MB acce	ess	Coordina	te	Name	A	ccess	U	nit		Description
	500	6	string	12 RW		A10		Meter Factor	Е		&	CounterFac	torUnit	Meter factor
	506	2	float	RW		A11		Output Pulse Factor	E		&	CounterFac	torUnit	Output pulse factor
	508	2	float	R		A12		Meter Factor corrected	A		&	CounterFac	torUnit	Meter factor corrected
	510	1	menu	16 RW		A20		Display Factor	Е					Display factor
	511	1	menu	16 RW		A21		Digital Output 2 Mode	E					Digital output 2 mode
	512	1	menu	16 RW		A22		Digital Output 2 Pulse Width	N	l	m	S		Digital output 2 pulse width
	MB reg	Reg. number	Data type	MB access	Со	ordinate	Na	ame		Acces	S	Unit	Desci	iption
	521	2	float	RW	B0	5	Flo	ow Rate min.		E		&FlowUnit	Flow r	ate minimum
	523	2	float	RW	B0	6	Flo	ow Rate max.		E		&FlowUnit	Flow r	ate maximum

MB reg	Reg. number	Data type	MB access	Coordinate	Name	Ac	cess	Ur	nit	Description	
527	2	float	RW	B08	QmUg	Е		&F	lowUni		
529	1	unit16	RW	B09	QmMinTime	Е		s			
530	2	float	RW	B10	Coefficient A-2	Е		Am2		Error curve linearization coefficent A-2	
532	2	float	RW	B11	Coefficient A-1	Е		An	า1	Error curve linearization coefficent A-1	
534	2	float	RW	B12	Coefficient A0	Е		A0	I	Error curve linearization coefficent A0	
536	2	float	RW	B13	Coefficient A1	Е		A1		Error curve linearization coefficent A1	
538	2	float	RW	B14	Coefficient A2	Е		A2		Error curve linearization coefficent A2	
540	2	float	RW	B15	KKMaxProz	Е		kkj	C		
MB reg	Reg. num- ber	Data type	MB ac- cess	Coordinate	Name		Acce	SS	Unit	Description	
657	1	menu16	RW	F02	Current Mode		N			Mode current output	
658	1	menu16	RW	F03	Current Source		N			Source current output	
659	2	float	RW	F04	Physical minimum value		N			Current output phys. mini- mum value	
661	2	float	RW	F05	Physical maximum value	۱	N			Current output phys. maxi- mum value	
663	2	float	RW	F06	Current default		Ν		mA	Current output default	
665	2	float	RW	F07	Current Damping		Ν		I-D	Damping current output	
667	2	float	RW	F10	Calibration Value 4m	hΑ	N		mA	Calibration: Actual value 4mA	
669	2	float	RW	F11	Calibration Value 20mA		N		mA	Calibration: Actual value 20mA	
671	4	string8	RW	F12	Module Serial Nun ber	n-	N		SN	Current output module se- rial no.	
675	1	unit16	R	G01	Current Error		A		ERR	Current activated error codes	
676	2	float	R	G02	Software Version		А		Rev	Software version	
MB reg	Reg. num- ber	Data type	MB ac- cess	Coordinate	Name		Acces	SS	Unit	Description	
680	2	int32	RW	G04	Serial number		E		SNr	Serial number	
682	1	unit16	R	G05	Firmware Checksum	ı	А		CRC	Firmware checksum	
683	2	float	R	G10	Pressure Base		А		bar	Pressure at base condition	

APPENDIX



	685	2	float	R	G11	Pressure Range Min.	A	bar	Pre	essure range minimum	
	687	2	float	R	G12	Pressure Range Max	А	bar	Pre	essure range maximum	
	689	6	string12	R	G13	Pressure Sensor Serial Number	А		Se ser	rial number pressure nsor	
	695	2	float	R	G14	Temperature Base	A	TN	Ten	nperature at base condition	
88	697	2	int32	RW	G17	Temp. Sensor Se- rial Number	E	TNr	Se tur	rial number tempera- e sensor	
	699	2	int32	RW	G18	Serial Number Gas Meter	E	ZNr	Se	rial number gas meter	
	701	4	string8	RW	G19	Meter size	E	G	Me	eter size	
	705	3	string8	RW	G20	Date of Battery Exchange	С	Bat	Da	te of battery exchange	
	790	1	unit16	R	G24	Remaining Battery Capacity	A	%	Re pa	maining Battery Ca- city	
	791	1	menu16	RW	G25	Battery Change	С	-	Ba	ttery Change	
	792	2	unit16	R	G26	Operating Hours	А	h	Ор	erating Hours	
	MB	Reg.	Data	MB	Coordinate	Name	Access	Unit	Des	scription	
	reg	number	type	access							
	709	1	menu16	RW	H01	RS485 Baudrate	Ν	Bps	RS	485 interface baudrate	
	710	1	menu16	RW	H02	RS485 Parameter	Ν		RS4	185 interface parameter	
	711	1	menu16	RW	H03	RS485 Protocol	Ν		RS4	185 selection of protocol	
	712	1	unit16	RW	H04	Modbus ID	N	MID	Мо	dbus ID	
	713	1	unit16	RW	H05	Modbus Register Offset	Ν	Mof	Мо	Modbus register offset	
	714	3	string8	RW	X01	Time	E	Т	Time		
	717	3	string8	RW	X02	Date	E	D	Dat	e	
	MB	Reg.	Data	MB	Coordinate	Name	Acces	ss Ur	nit	Description	
	reg	number	type	access							
	722	1	menu16	RW	X10	Delete Parameter Ar- chive	E		,	Delete parameter ar- chive	
	723	1	unit16	R	X11	Fill level Para. Archiv	e A	%		Fill level parameter ar- chive	
	724	1	menu16	RW	X12	Delete Parameter Ar- chive(E)	Е			Delete parameter ar- chive (E)	
	725	1	unit16	R	X13	Fill level Para. Achive (E)	À	%		Fill level parameter ar- chive (E)	
	726	1	menu16	RW	X14	Delete Event Archive	Е			Delete event archive	
	727	1	unit16	R	X15	Fill level Event Archiv	ve A	%		Fill level event archive	
	728	1	menu16	RW	X16	Mode archives	Е			Mode Archives	
	729	1	menu16	RW	X17	Interval Minute Archiv	/e E			Interval minute archiv	



730	1	menu16	RW	X18	Delete Minute Archive	E		Delete minute archive	
731	1	unit16	R	X19	Fill level Minute Archive	А	%	Fill level minute archive	
732	1	menu16	RW	X20	Delete Day Archive	E		Delete day archive	
733	1	unit16	R	X21	Fill level Day Archive	А	%	Fill level day archive	
734	1	menu16	RW	X22	Delete Month archive	E		Delete month archive	
735	1	unit16	R	X23	Fill level Month Archive	А	%	Fill level month archive	89
812	1	menu16	W	X24	Delete all archives	E	-	Deleting of all archives	
MB reg	Reg. number	Data type	MB access	Coordinate	Name	Access	Unit	Description	
775	1	unit16	RW	Z04	X:Y maximum Pulse Errors	E	Х	Pulse compare X:Y max- imum pulse errors	
776	1	unit16	RW	Z05	X:Y maximum Pulses	E	Y	Pulse compare X:Y max- imum pulses	
777	1	unit16	RW	Z15	Code Word Input	Ν	COD	Code word input	
778	1	unit16	RW	Z16	Code Word Change	С	C-V	Code word change	
779	1	menu16	RW	Z17	Device Type	E		Device type	
780	1	menu16	RW	Z24	Display on max.	Ν		Maximum time display on	
781	1	menu16	RW	Z25	Volume Count Mode	E		Selection mode of vol- ume counter	
782	1	menu16	RW	Z26	Curve Linearization	E		Selection curve linearization	
783	1	menu16	RW	Z27	Sensor Type 1	E		Selection turbine sensor channel 1	

784	1	menu16	RW	Z28	Sensor Type 2	E	Selection turbine sensor channel 2
785	1	menu16	RW	Z29	Unit Volume	E	Selection volume unit

The Modbus access has the meaning:

R = no protection RW = calibration button



B Dimensions

TME400-VM

90



Front side

Rear side





8

- 1 -
- 2 Oil pump
- 3
- 4 -

- 5
- 6
- 7 Top view
- 8 Top view for flow direction from bottom top up to DN200



Siz	е	Max. Flow rate	Din	nensions		Weight	
		Qmax					
mm	Inch	m3/h	Length L	Width B	Hight H	kg	
25	1	25	185	135	225	2	
40	1 1/2	70	140	255	225	5	
50	2	100	150	245	265	15	
		160					
80	3	250	120	265	290	18	
		400					
100	4	400	400 150		206	25	
100	4	650	150	200	300	25	
		650					
150	6	1000	175	320	330	40	
		1600					
200	Q	1600	200	370	365	55	
200	0	2500	200	370	303	- 55	
250	10	2500	300	120	400	PN 10 = 60	
230	10	4000	300	430	400	PN 25 = 75	
200	12	4000	300	600	410	PN 25 = 103	
300	12	6500	300	000	410	PN10 = 86	
		6500				PN10 = 190	
400 16	10000	600	640	420	PN16 = 210		
		10000				PN40 = 300	



TME400-VMF

Front view



Rear side



8

- 1 -
- 2 Oil pump
- 3 .
- 4

5	-
---	---

6 -

7 Top view

8 Top view for flow direction from bottom top up to DN200



Si	ze		Max. Flow rate	C	imensions		Weight
			Qmax				
mm	Inch	G-Size	m3/h	Length L	Width B	Hight H	kg
50	2	G65	65	150	320	310	15
		G100	160				
80	3	G160	250	240	270	250	20
		G250	400				
		G160	250				
100	4	G250	400	300	285	254	28
		G400	650				
		G400	650				
150	6	G650	1000	450	310	280	50
		G1000	1600				
200	8	G1000	1600	600	380	320	100
200	0	G1600	2500	000	500	520	100
		G1000	1600				ANSI150 = 160
250	10	G1600	2500	750		345	PN16 = 150
		G2500	4000				PN10 = 150
		G2500	4000				ANSI150 = 250
300	12	G4000	6500	900		360	PN16 = 215
		G4000-45	6500**				PN10 = 210



Remote meter



Cable length:10 mPressure sensor:integrHeight:appro

integrated in the connection head approx. 80 mm less than the "normal" height (see above)



C Type plate

Main type plate TME400-VM for DN25, for Non-Ex, no custody transfer applications

TME400-\	/M			C	F
DN					291
Q max		m³/h	Tmin		°C
Q min		m³/h	Tmax		°C
PS brennbare Gase	5	bar	Inax		0
PS nichtbrennbare Gase non-flammable gas		bar		IP65	i.
SNr./Sno.		and the second			-
Jahr/Year		Otto-Hal 35510 B	esstechnik Gr nn Str. 5 ulzbach / Ger	nbH many	RMG

Main type plate TME400-VM from DN40, for Non-Ex, no custody transfer applications

TME400-	VM	C	€ 0091
DN Q max	m³/h 7	í min	0°C
Q min	m³/h	() wa	
TS	Dar	IP65	
SNr./Sno. Jahr/Year	RMG Messter Otto-Hahn-St 35510 Butzba	chnik GmbH r. 5 ach / Germany	RMG



Main type plate TME400-VM for DN25, for Ex, no custody transfer applications

TME400-V		(E 0158		
DN				200	Ex II 2 G Ex ia IIC T4 Gb
Q max		m³/h _	-	00	$-25^{\circ}C \le T_{amb} \le +55^{\circ}C$
Q min	1	m³/h .			TUV 17 ATEX 207566X
PS brennbare Gese	5	bar	max		IECEX TUN 18,0009 X
PS nichtbrennbare Gase non-flammable gas		bar	IP	55	
SNr./Sno. Jahr/Year	-	RMG Messtechnik GmbH Otlo-Hain-Str. 5 35510 Butzbach / Germany			Elektrische Daten siehe EU- Baumusterprüfbescheinigung Electrical data see certificate

Main type plate TME400-VM from DN40, for Ex, no custody transfer applications

TME400	-VM	C	€ 0091 0158	E II 2 G Ex ia IIC T4 Gb
DN Q max Q min PS	m³/h m³/h bar	T min T max	ວະ ຈະ	-25°C ≤ T _{amb} ≤ +55°C TÜV 17 ATEX 207566X IECEX TUN 18.0009 X
TS SNr./Sno. Jahr/Year	RMG Mes Otto-Hahi 35510 Bu	stechnik GmbH h-Str. 5 tzbach / Germany	RMG	Elektrische Daten siehe EU- Baumusterprüfbescheinigung Electrical data see certificate



D Seal diagrams

RMG

Will be added as soon as available.

Manual TME400-VMF · EN06 · 2019 November 6th



E Certificates and approvals

The **TME400** is approved for custody-transfer measurements. Approvals are available for operation in hazardous environments and for the Pressure Equipment Directive, which are provided as copies in the appendix.

- 1. EU Declaration of Conformity
- 2. ATEX
- 3. IECEx
- 4. EU-Type Examination Certificate Directive 2014/34/EU
- 5. PED Module D
- 6. EU-Type Examination Certificate Module B Directive 2014/68/EU
- 7. Production Quality Assurance





More information

100

If you would like to learn more about the products and solutions from RMG, visit our website:

www.rmg.com

or contact your local sales representative

RMG Messtechnik GmbH

Otto-Hahn-Straße 5 35510 Butzbach, Germany Phone: +49 (0) 6033 897 – 0 Fax: +49 (0) 6033 897 – 130 Email: <u>service@rmg.com</u>

